

TABLE OF CONTENTS

1.0	INTRODUCTION	1
1.1	SYSTEM COVERAGE	1
1.2	SIX-STEP TROUBLESHOOTING PROCEDURE	1
2.0	IDENTIFICATION OF SYSTEM	1
3.0	SYSTEM DESCRIPTION AND FUNCTIONAL OPERATION	1
3.1	GENERAL DESCRIPTION	1
3.2	JTEC + CONTROLLER AND OPERATING MODES	1
3.2.1	Overview	1
3.2.2	Hardware Architecture	2
3.2.3	Software Architecture	2
3.2.4	Spark Control	2
3.2.5	Fuel Control	2
3.2.6	On Board Diagnostics	3
3.2.7	Transmission Control (4.0L - XJ Body Only)	3
3.2.8	Other Controls	3
3.2.9	PCM Operating Modes	4
3.2.10	Non-Monitored Circuits	5
3.2.11	SKIS OVERVIEW	6
3.2.12	SKIS OPERATION	6
3.3	DIAGNOSTIC TROUBLE CODES	7
3.3.1	Hard Code	7
3.3.2	Intermittent Code	7
3.3.3	Reset Counter	7
3.3.4	Handling No Trouble Code Problems	7
3.4	USING THE DRBIII®	7
3.5	DRBIII® ERROR MESSAGES AND BLANK SCREEN	8
3.5.1	DRBIII® Does Not Power Up	8
3.5.2	Display Is Not Visible	8
4.0	SYSTEM COMPONENT LOCATIONS	9
4.1	POWERTRAIN CONTROL MODULE	9
4.2	CONTROLS & SOLENOIDS	11
4.3	DATA LINK CONNECTOR	14
4.4	SENSORS	14
4.5	FUEL SYSTEM	19
4.6	RELAYS	19
4.7	SWITCHES	21
5.0	DISCLAIMERS, SAFETY, WARNINGS	23
5.1	DISCLAIMERS	23
5.2	SAFETY AND WARNINGS	23
5.2.1	Technician Safety Information	23
5.2.2	Vehicle Preparation for Testing	23
5.2.3	Servicing Sub-Assemblies	23
5.2.4	DRBIII® Safety Information	23
5.3	WARNINGS AND CAUTIONS	24
5.3.1	Vehicle Damage Warnings	24
5.3.2	Road Testing a Complaint Vehicle	24

TABLE OF CONTENTS - Continued

7.0	DIAGNOSTIC INFORMATION AND PROCEDURES	25
7.1	GENERAL TROUBLESHOOTING	25
	TROUBLE CODE TEST	
	DTC TEST CHECKING THE SYSTEM FOR DIAGNOSTIC TROUBLE CODES	26
	TROUBLE CODE TESTS	
TC-1A	REPAIRING - NO CAM SIGNAL AT PCM	28
TC-5A	REPAIRING - CHARGING SYSTEM VOLTAGE TOO LOW	36
TC-6A	REPAIRING - CHARGING SYSTEM VOLTAGE TOO HIGH	42
TC-10A	REPAIRING - AUTO SHUTDOWN RELAY CONTROL CIRCUIT ...	50
TC-11A	REPAIRING - GENERATOR FIELD NOT SWITCHING PROPERLY	54
TC-12A	REPAIRING TORQUE CONVERTER CLUTCH/TRANS RELAY CKT (TJ/XJ BODY WITH 3SPD AUTO TRANS)	58
TC-14A	REPAIRING - RADIATOR FAN RELAY CIRCUIT	60
TC-15A	REPAIRING - SPEED CONTROL CIRCUITS	64
TC-16A	REPAIRING - A/C CLUTCH RELAY CIRCUIT	72
TC-18A	REPAIRING - EVAP PURGE SOLENOID CIRCUIT	76
TC-19A	REPAIRING - INJECTOR #3 CONTROL CIRCUIT	82
TC-20A	REPAIRING - INJECTOR #2 CONTROL CIRCUIT	84
TC-21A	REPAIRING - INJECTOR CONTROL CIRCUITS	86
TC-25A	REPAIRING - IDLE AIR CONTROL MOTOR CIRCUITS	92
TC-26A	REPAIRING - THROTTLE POSITION SENSOR VOLTAGE LOW ..	108
TC-27A	REPAIRING - THROTTLE POSITION SENSOR VOLTAGE HIGH ..	112
TC-30A	REPAIRING - ECT SENSOR VOLTAGE TOO LOW	116
TC-31A	REPAIRING - ECT SENSOR VOLTAGE TOO HIGH	120
TC-35A	REPAIRING - NO VEHICLE SPEED SENSOR SIGNAL	124
TC-36A	REPAIRING - MAP SENSOR VOLTAGE TOO LOW/NO 5 VOLTS TO MAP SENSOR	134
TC-37A	REPAIRING - MAP SENSOR VOLTAGE TOO HIGH	140
TC-39A	REPAIRING - NO CHANGE IN MAP FROM START TO RUN	146
TC-40A	REPAIRING - NO CRANK REFERENCE SIGNAL AT PCM	150
TC-43A	REPAIRING - IGNITION COIL #1 PRIMARY CIRCUIT	156
TC-44A	REPAIRING - NO ASD RELAY OUTPUT VOLTAGE AT PCM	160
TC-49A	REPAIRING - PCM FAILURE EEPROM WRITE DENIED	164
TC-57A	REPAIRING - INTAKE AIR TEMP SENSOR VOLTAGE LOW	166
TC-58A	REPAIRING - INTAKE AIR TEMP SENSOR VOLTAGE HIGH	170
TC-61A	REPAIRING - INJECTOR #4 CONTROL CIRCUIT	174
TC-62A	REPAIRING - 1/1 O2 SENSOR SHORTED TO VOLTAGE	176
TC-69A	REPAIRING - INJECTOR #5 CONTROL CIRCUIT	182
TC-70A	REPAIRING - INJECTOR #6 CONTROL CIRCUIT	184
TC-82A	REPAIRING - SPEED CONTROL POWER RELAY OR SPEED CONTROL 12V DRIVER CIRCUIT	186
TC-86A	REPAIRING - SPEED CONTROL SWITCH ALWAYS HIGH	194
TC-87A	REPAIRING - SPEED CONTROL SWITCH ALWAYS LOW	200
TC-101A	REPAIRING - FUEL PUMP (SYSTEM) RELAY CONTROL CIRCUIT	202
TC-114A	REPAIRING - P/N SWITCH STUCK IN PARK OR GEAR	206
TC-115A	REPAIRING - POWER STEERING SWITCH FAILURE	212
TC-118A	REPAIRING - FUEL SYSTEM RICH 1/1 RICH	218
TC-119A	REPAIRING - FUEL SYSTEM LEAN 1/1 LEAN	222
TC-126A	REPAIRING - 1/2 O2 SENSOR SHORTED TO VOLTAGE	226

TABLE OF CONTENTS - Continued

TC-132A	REPAIRING - TPS VOLTAGE DOES NOT AGREE WITH MAP232
TC-148A	REPAIRING - TORQUE CONVERTER CLUTCH - NO RPM DROP AT LOCK-UP (TJ/XJ BODY WITH 3 SPD AUTO TRANS)238
TC-149A	REPAIRING - FUEL LEVEL SENDING UNIT VOLTS TOO LOW . .	.244
TC-150A	REPAIRING - FUEL LEVEL SENDING UNIT VOLTS TOO HIGH .	.248
TC-151A	REPAIRING - FUEL LEVEL SENDING UNIT NO CHANGE OVER TIME.254
TC-153A	REPAIRING - BATTERY TEMP SENSOR VOLTAGE TOO LOW/TOO HIGH258
TC-155A	REPAIRING - 1/1 O2 SENSOR SHORTED TO GROUND264
TC-156A	REPAIRING - 1/2 O2 SENSOR SHORTED TO GROUND268
TC-157A	REPAIRING - INTERMITTENT LOSS OF CMP OR CKP272
TC-225A	REPAIRING - NO CDD BUS MESSAGE FROM THE MIC284
TC-226A	REPAIRING - NO CCD BUS MESSAGE RECEIVED FROM SKIM .	.288
TC-232A	REPAIRING - INVALID OR WRONG KEY MESSAGE FROM SKIM292
TC-235A	REPAIRING - OIL PRESSURE SENSOR LOW EXCEEDED296
TC-236A	REPAIRING OIL PRESSURE SENSOR HIGH EXCEEDED300

SENTRY KEY IMMOBILIZER SYSTEM

SK-1A	IDENTIFYING SENTRY KEY IMMOBILIZER SYSTEM306
SK-2A	REPAIRING - PCM STATUS FAILURE310
SK-3A	REPAIRING - ROLLING CODE FAILURE314
SK-4A	REPAIRING - SERIAL LINK EXTERNAL FAILURE318
SK-5A	REPAIRING - TRANSPONDER COMMUNICATION FAILURE322
SK-6A	REPAIRING - TRANSPONDER CRC (CYCLIC REDUNDANCY CHECK) FAILURE326
SK-7A	REPAIRING - TRANSPONDER ID MISMATCH330
SK-8A	REPAIRING - TRANSPONDER RESPONSE MISMATCH334
SK-9A	REPAIRING - VIN MISMATCH338

NO TROUBLE CODE TESTS

NTC-1A	NO TROUBLE CODE TEST MENU342
NTC-2A	CHECKING SECONDARY IGNITION AND TIMING344
NTC-3A	CHECKING - THE PCM POWER AND GROUND CIRCUITS346
NTC-4A	CHECKING THE ENGINE VACUUM348
NTC-5A	CHECKING THE FUEL DELIVERY350
NTC-6A	CHECKING THE COOLANT SENSOR352
NTC-7A	CHECKING THE THROTTLE POSITION SENSOR354
NTC-8A	CHECKING THE MAP SENSOR356
NTC-10A	CHECKING THE OXYGEN SENSOR SWITCHING358
NTC-11A	CHECKING THE OXYGEN SENSOR HEATER364
NTC-12A	CHECKING THE IDLE AIR CONTROL MOTOR366
NTC-13A	CHECKING THE ENGINE MECHANICAL368
NTC-15A	CHECKING BATTERY TEMP SENSOR370
NTC-17A	CHECKING THE EVAPORATIVE EMISSION SYSTEM372
NTC-19A	CHECKING THE INTAKE AIR TEMPERATURE SENSOR378
NTC-20A	CHECKING THE PARK/NEUTRAL POSITION SWITCH380
NTC-21A	CHECKING THE OIL PRESSURE SENDING UNIT388
NTC-25A	CHECKING THE FUEL LEVEL SENSOR394
NTC-26A	CHECKING THE A/C SYSTEM396
NTC-27A	CHECKING THE RADIATOR FAN OPERATION398

TABLE OF CONTENTS - Continued

SPEED CONTROL TESTS	
SC-1A	CHECKING THE SPEED CONTROL SYSTEM.....402
SC-2A	CHECKING SPEED CONTROL ON/OFF SWITCH.....412
SC-3A	CHECKING THE SPEED CONTROL RESUME SWITCH416
SC-4A	CHECKING THE BRAKE SWITCH SENSE.....418
SC-5A	CHECKING THE SPEED CONTROL OPERATION422
CHARGING TESTS	
CH-1A	CHARGING SYSTEM NO CODE TEST424
NO START TESTS	
NS-SEL	NO START SELECTION MENU.....430
NS-1A	QUALIFYING A NO START CONDITION.....432
NS-2A	CHECKING THE FUEL SYSTEM.....442
NS-3A	CHECKING ENGINE MECHANICAL SYSTEMS.....446
NS-4A	REPAIRING LOW FUEL PRESSURE448
NS-5A	CHECKING THE FUEL PUMP.....450
NS-6A	REPAIRING - NO RESPONSE CONDITION.....454
NS-7A	CHECKING THE IDLE AIR CONTROL MOTOR.....472
NS-8A	REPAIRING A START AND STALL CONDITION.....478
NS-9A	REPAIRING A NO CRANK CONDITION480
VERIFICATION TEST	
VER-1A	NO START VERIFICATION488
VER-2A	ROAD TEST VERIFICATION489
VER-3A	CHARGING VERIFICATION.....491
VER-4A	SPEED CONTROL VERIFICATION.....492
8.0	MAINTENANCE AND SERVICE INFORMATION.....493
8.1	PROGRAMMING THE POWERTRAIN CONTROL MODULE493
8.2	PROGRAMMING THE SENTRY KEY IMMOBILIZER MODULE493
8.3	PROGRAMMING IGNITION KEYS TO THE SENTRY KEY IMMOBILIZER MODULE493
9.0	SPECIFICATIONS.....494
9.1	FUEL SYSTEM RELEASE PROCEDURE (GASOLINE).....494
10.0	SCHEMATIC DIAGRAMS.....495
10.1	TJ BODY 2.5/4.0L JTEC+.....495
10.2	XJ BODY 2.5L JTEC+.....496
10.3	XJ BODY 4.0 JTEC+.....497
11.0	RECOMMENDED TOOLS AND EQUIPMENT498
12.0	GLOSSARY OF TERMS.....498

1.0 INTRODUCTION

The procedures contained in this manual include all the specifications, instructions, and graphics needed to diagnose powertrain control module (PCM) problems; they are no start, diagnostic trouble code, and no trouble code problems for the PCM. The diagnostics in this manual are based on the failure condition or symptom being present at the time of diagnosis.

When repairs are required, refer to the appropriate volume of the service manual for proper removal and repair procedure.

Diagnostic procedures change every year. New diagnostic systems may be added; carryover systems may be enhanced. **READ THE GENERAL INFORMATION SECTIONS IN THIS MANUAL BEFORE TRYING TO DIAGNOSE A VEHICLE TROUBLE CODE.** It is recommended that you review the entire manual to become familiar with all new and changed diagnostic procedures.

This book reflects many suggested changes from readers of past issues. After using this book, if you have any comments or recommendations, please fill out the form at the back of the book and mail it back to us.

1.1 System Coverage

This diagnostic procedures manual covers all 1999 TJ and XJ vehicles equipped with a JTEC PLUS engine controller.

1.2 Six-Step Troubleshooting Procedure

Diagnosis of the powertrain control module (PCM) is done in six basic steps:

- verification of complaint
- verification of any related symptoms
- symptom analysis
- problem isolation
- repair of isolated problem
- verification of proper operation

2.0 IDENTIFICATION OF SYSTEM

The powertrain control module (PCM) monitors and controls the engine, fuel system, ignition system, and automatic transmission.

3.0 SYSTEM DESCRIPTION AND FUNCTIONAL OPERATION

3.1 General Description

The Jeep engine and Auto Transmission systems have the latest in technical advances. The on-board diagnostics incorporated with the PCM controller are intended to assist the field technician in repairing vehicle problems by the quickest means.

3.2 JTEC + Controller and Operating Modes

3.2.1 Overview

The JTEC + PCM features a multi-processor environment (one 16 bit microcomputer, two 8 bit microcomputer) allowing parallel processing of time critical operations. Dedication of one 8 bit processor (K4) to spark control and the other 8 bit processor (D3) to fuel control allows increases in throughput and reduced software complexity in the 16 bit microcomputer (Z2). The result is increased capability in the Z2 to handle overall strategy implementation, and other computation-intensive processes.

3.2.2 Hardware Architecture

The design of the PCM can be broken up into about eight major sections. The main microcontroller, a Motorola MC68HC16Z2, is attached to a 256k byte memory device (flash memory) which is programmed after manufacture of the module. (This memory can be reprogrammed at the factory or at a dealership. The MC68HC11D3 and MC68HC11K4 microcomputers have memories which are permanently programmed during their manufacture, and therefore cannot be reprogrammed.)

The microcomputers communicate over a bus which allows for rapid transmission of high priority messages. The Z2 executes the primary powertrain control strategy; transmits fuel and spark requirements to the D3 and K4; communicates with outside devices; and processes 14 analog inputs and about half of the one bit inputs and outputs. The D3 microcomputer controls fuel injector timing pulses and a small number of one bit inputs and outputs. The K4 controls spark timing pulses, processes 8 analog inputs and a number of one bit inputs and outputs.

Other major sections of the PCM design include the power supply, input conditioning circuits, output driver circuits, serial communication interface circuits, and a device which controls ignition coil currents.

3.2.3 Software Architecture

The 68HC16Z2 microcontroller is the main computing unit of the PCM. The 68HC11D3 and K4 microcontrollers control fuel and spark respectively. They handle the critical timing requirements of their tasks, communicating with the Z2 using high level commands.

The Z2 operating system is the heart of the software and was written expressly for this PCM. Every 500 microseconds the Z2 interrupts what it is doing to perform periodic tasks such as updating sensor inputs values and checking for the occurrence of a crank position pulse. If this pulse is observed, a program known as the decision maker is executed and performs high priority tasks such as fuel and spark calculations, and RPM processing. Low priority tasks (SCI and CCD communications) are executed during the time between crank pulses.

The Z2 software is divided into a main operating strategy and three separate calibration areas. The main strategy contains information specific to the various engines and transmissions supported by this PCM. Once installed, the information contained in this area is fixed for a given engine and transmission. Changes to this data, if required, can be performed only by computer programming personnel. The calibration areas (engine and transmission) contain information relating to emissions, fuel economy and driveability and can be altered directly by calibration personnel.

3.2.4 Spark Control

The K4 microcomputer controls the generation and timing of spark pulses. The spark advance and dwell characteristics are determined by: engine speed, throttle position, MAP, coolant temperature, barometric air pressure, air temperature, and vehicle speed.

3.2.5 Fuel Control

The PCM controls the air/fuel ratio of the engine by varying fuel injector on time. Mass air flow is calculated using the speed density method using engine speed, manifold absolute pressure, and air charge temperature.

Different fuel calculation strategies are used dependent on the operational state of the engine. During crank mode, a prime shot fuel pulse is delivered followed by fuel pulses determined by a crank time strategy. Cold engine operation is determined via an open loop strategy until O2 sensors have reached operating temperature. At this point, the strategy enters a closed loop mode where fuel requirements are based upon the state of the O2 sensors, engine speed, MAP, throttle position, air temperature, battery voltage, and coolant temperature.

Additional factors can influence fuel pulse width. Asynchronous acceleration enrichment is a technique whereby the duration of injector "on" time can be increased for injectors already firing, providing improved acceleration response.

The D3 microcomputer controls fuel injector timing in response to high level commands from the Z2 microcomputer. Injector timing, with respect to engine position, is determined by the D3 and is transparent to the Z2.

3.2.6 On Board Diagnostics

The PCM has been programmed to monitor many different circuits of the fuel injection system. This monitoring is called "on-board diagnosis."

Certain criteria, or "arming conditions," must be met for a trouble code to be entered into the PCM memory. The criteria may be a range of: engine rpm, engine temperature, and/or input voltage to the PCM. If a problem is sensed with a monitored circuit, and all of the criteria or arming conditions are met, a trouble code will be stored in the PCM.

It is possible that a trouble code for a monitored circuit may not be entered into the PCM memory even though a malfunction has occurred. This may happen because one of the trouble code criteria (arming conditions) has not been met.

The PCM compares input signal voltages from each input device with specifications (the established high and low limits of the range) that are programmed into it for that device. If the input voltage is not within specifications and other trouble code criteria (arming conditions) are met, a trouble code will be stored in the PCM memory.

3.2.7 Transmission Control (4.0L - XJ Body Only)

Control of the transmission on this vehicle is done by a separate Transmission Control Module (TCM). The TCM is also called an AW4 TCM. Diagnostics for this TCM are found in another diagnostic manual called, the AW4 Powertrain Diagnostic Manual.

3.2.8 Other Controls

Cruise Control

The PCM controls vehicle speed by operation of the speed control servo vacuum and vent solenoids. Energizing the vacuum solenoid applies vacuum to the servo to increase throttle position. Operation of the vent solenoid slowly releases the vacuum allowing throttle position to decrease. A special dump solenoid allows immediate release of throttle position caused by braking, cruise control turned off, or ignition key off.

Fuel Vapor Recovery System (Duty Cycle Purge Control)

Duty Cycle Purge is a system that feeds fuel gases from the purge canister and gasoline tank into the throttle body for mixing with incoming air. Metering of the gases is performed by duty cycling the purge solenoid by the PCM.

The system is disabled during wide open throttle conditions and while the engine is below a specified coolant temperature. When engine temperature becomes greater than a calibrated parameter, duty cycle purge is delayed for a calibrated time. Once purge delay is over, purge will be ramped into soften the effect of dumping additional fuel into the engine.

The PCM provides a modulated 5 hz signal (at closed throttle) or 10 hz signal (at open throttle) to control this system. Modulation of the signal is based upon a calculated air flow (based upon known fuel flow through the injector at a given pulsewidth and RPM) and is adjusted to compensate for changes in flow due to varying engine vacuum.

3.2.9 PCM Operating Modes

As input signals to the PCM change, the PCM adjusts its response to output devices. For example, the PCM must calculate a different injector pulse width and ignition timing for idle than it does for wide open throttle. There are several different modes of operation that determine how the PCM responds to the various input signals.

There are two types of engine control operation: **open loop** and **closed loop**.

In open loop operation, the PCM receives input signals and responds according to preset programming. Inputs from the heated oxygen sensors are not monitored.

In closed loop operation, the PCM monitors the inputs from the heated oxygen sensors. This input indicates to the PCM whether or not the calculated injector pulse width results in the ideal air-fuel ratio of 14.7 parts air to 1 part fuel. By monitoring the exhaust oxygen content through the oxygen sensor, the PCM can fine tune injector pulse width. Fine tuning injector pulse width allows the PCM to achieve optimum fuel economy combined with low emissions.

The engine start-up (crank), engine warm-up, and wide open throttle modes are open loop modes. Under most operating conditions, the acceleration, deceleration, and cruise modes, with the engine at operating temperature, are closed loop modes.

Ignition Switch On (Engine Off) Mode

When the ignition switch activates the fuel injection system, the following actions occur:

1. The PCM determines atmospheric air pressure from the MAP sensor input to determine basic fuel strategy.
2. The PCM monitors the engine coolant temperature sensor and throttle position sensor input. The PCM modifies fuel strategy based on this input.

When the Ignition key is in the “on” position and the engine is not running (zero rpm), the auto shutdown relay and fuel pump relay are not energized. Therefore, voltage is not supplied to the fuel pump, ignition coil, and fuel injectors.

Engine Start-Up Mode —This is an open loop mode. The following actions occur when the starter motor is engaged:

1. The auto shutdown and fuel pump relays are energized. If the PCM does not receive the camshaft and crankshaft signals within approximately one second, these relays are de-energized.
2. The PCM energizes all fuel injectors until it determines crankshaft position from the camshaft and crankshaft signals. The PCM determines crankshaft position within one engine revolution. After the crankshaft position has been determined, the PCM energizes the fuel injectors in sequences. The PCM adjusts the injector pulse width and synchronizes the fuel injectors by controlling the fuel injectors’ ground paths.

Once the auto shutdown and fuel pump relays have been energized, the PCM determines the fuel injector pulse width based on the following:

- engine coolant temperature
- manifold absolute pressure
- intake air temperature
- engine revolutions
- throttle position

The PCM determines the spark advance based on the following:

- engine coolant temperature
- crankshaft position
- camshaft position

- intake air temperature
- manifold absolute pressure
- throttle position

Engine Warm-Up Mode — This is an open loop mode. The PCM adjusts injector pulse width and controls injector synchronization by controlling the fuel injectors' ground paths. The PCM adjusts ignition timing and engine idle speed. The PCM adjusts the idle speed by controlling the idle air control motor.

Cruise or Idle Mode — When the engine is at normal operating temperature, this is a closed loop mode. During certain idle conditions, the PCM may enter into a variable idle speed strategy. At this time, the PCM adjusts engine speed based on the following inputs:

- throttle position
- battery voltage
- engine coolant temperature

Acceleration Mode — This is a closed loop mode. The PCM recognizes an increase in throttle position and a decrease in Manifold Vacuum as engine load increases. In response, the PCM increases the injector pulse width to meet the increased load.

Deceleration Mode — This is a closed loop mode. The PCM recognizes a decrease in throttle position and an increase in Manifold Vacuum as engine load decreases. In response, the PCM decreases the injector pulse width to meet the decreased load.

Wide Open Throttle Mode — This is an open loop mode. The throttle position sensor notifies the PCM of a wide open throttle condition. The PCM adjusts injector pulse width to supply a predetermined amount of additional fuel.

3.2.10 Non-Monitored Circuits

The PCM does not monitor the following circuits, systems, and conditions even though they could have malfunctions that result in driveability problems. A diagnostic code may not be displayed for the following conditions. However, problems with these systems may cause a diagnostic code to be displayed for other systems. For example, a fuel pressure problem will not register a diagnostic code directly, but could cause a rich or lean condition. This could cause an oxygen sensor, fuel system, or misfire monitor trouble code to be stored in the PCM.

Engine Timing — The PCM cannot detect an incorrectly indexed timing chain, camshaft sprocket, or crankshaft sprocket. The PCM also cannot detect an incorrectly indexed distributor. (*)

Fuel Pressure — Fuel pressure is controlled by the fuel pressure regulator. The PCM cannot detect a clogged fuel pump inlet filter, clogged in-line fuel filter, or a pinched fuel supply. (*)

Fuel Injectors — The PCM cannot detect if the fuel injector is clogged, the pintle is sticking, or the wrong injectors are installed. (*)

Fuel Requirements — Poor quality gasoline can cause problems such as hard starting, stalling, and stumble. Use of methanol-gasoline blends may result in starting and driveability problems. (See individual symptoms and their definitions in Section 12.0 (Glossary of Terms) at the back of this book.)

PCM Grounds — The PCM cannot detect a poor system ground. However, a diagnostic trouble code may be stored in the PCM as a result of this condition.

Throttle Body Air Flow — The PCM cannot detect a clogged or restricted air cleaner inlet or filter element. (*)

Exhaust System — The PCM cannot detect a plugged, restricted, or leaking exhaust system. (*)

Cylinder Compression — The PCM cannot detect uneven, low, or high engine cylinder compression. (*)

Excessive Oil Consumption — Although the PCM monitors the exhaust stream oxygen content through the oxygen sensor when the system is in a closed loop, it cannot determine excessive oil consumption.

(*)**NOTE:** Any of these conditions could result in a rich or lean condition causing an oxygen sensor trouble code to be stored in the PCM, or the vehicle may exhibit one or more of the driveability symptoms listed in TEST NTC-1A – No Trouble Code Test Menu.

3.2.11 SKIS OVERVIEW

The Sentry Key Immobilizer System (SKIS) is an immobilizer system designed to prevent unauthorized vehicle operation. The system consists of a Sentry Key Immobilizer Module (SKIM), ignition key(s) equipped with a transponder chip and powertrain controller. When the ignition switch is turned on, the SKIM interrogates the ignition key. If the ignition key is “Valid” the SKIM sends a CCD Bus message to the powertrain controller indicating the presence of a valid ignition key. With a valid key presence, the PCM allows the engine to continue to operate.

3.2.12 SKIS OPERATION

When ignition power is supplied to the SKIM, the SKIM performs an internal self-test. After the self-test is completed, the SKIM energizes the antenna (this activates the transponder chip) and sends a challenge to the transponder chip. The transponder chip responds to the challenge by generating an encrypted response message using the following:

Secret Key — This is an electronically stored value (identification number) that is unique to each SKIS. The secret key is stored in the SKIM, PCM and all ignition key transponders.

Challenge — This is a random number that is generated by the SKIM at each ignition key cycle.

The secret key and challenge are plugged into an algorithm that produces the encrypted response message. The transponder uses the crypto algorithm to receive, decode and respond to the message sent by SKIM. After responding to the coded message, the transponder sends a transponder ID message to the SKIM. The SKIM compares the transponder ID to the available valid key codes in SKIM memory (8 key maximum). After validating the key the SKIM sends a CCD Bus message called a “Seed Request” to the powertrain controller then waits for a powertrain controller response. If the powertrain controller does not respond, the SKIM will send the seed request again. After three failed attempts the SKIM will stop sending the seed request and store a trouble code. If the powertrain controller sends a seed response, the SKIM sends a valid/invalid key message to the powertrain controller. This is an encrypted message that is generated using the following:

VIN — Vehicle Identification Number

Seed — This is a random number that is generated by the PCM at each ignition key cycle.

The VIN and seed are plugged into a rolling code algorithm that encrypts the “valid/invalid key” message. The powertrain controller uses the rolling code algorithm to receive, decode and respond to the valid/invalid key message sent by SKIM. After sending the valid/invalid key message the SKIM waits 3.5 seconds for an EMS status message from the powertrain controller. If the PCM does not respond with a valid key message to the SKIM, a fault is detected and a trouble code stored.

The SKIS incorporates a yellow warning lamp located in the instrument cluster. The lamp is illuminated when the SKIM sends a CCD Bus message to the instrument cluster requesting the lamp on. The SKIM will request lamp operation for the following:

- bulb check at ignition on
- to alert the vehicle operator to a SKIS malfunction

For all faults except transponder faults and VIN mismatch, the lamp remains on steady. In the event of a transponder fault the light flashes at the rate of 1Hz (once per second). If a fault is present the lamp will remain on or flashing for the complete ignition cycle.

3.3 Diagnostic Trouble Codes

Each diagnostic trouble code is diagnosed by following a specific testing procedure. The diagnostic test procedures contain step-by-step instructions for determining the cause of trouble codes as well as no trouble code problems. It is not necessary to perform all of the tests in this book to diagnose an individual code.

Always begin by reading the diagnostic trouble codes using the DRB. This procedure begins in the DTC TEST Section 7.1 — Checking the System for Diagnostic Trouble Codes. This will direct you to the specific test(s) that must be performed.

3.3.1 Hard Code

A diagnostic trouble code that returns within one cycle of the required parameters is a “hard” code. This means that the defect is there every time the powertrain control module checks that circuit or function. Procedures in this manual verify if the trouble code is a hard code at the beginning of each test. When it is not a hard code, an “intermittent” test must be performed.

3.3.2 Intermittent Code

A diagnostic trouble code that is not there every time the powertrain control module checks the circuit is an “intermittent” code. Most intermittent codes are caused by wiring or connector problems. Defects that come and go like this are the most difficult to diagnose; they must be looked for under specific conditions that cause them. The following checks may assist you in identifying a possible intermittent problem.

- Visually inspect related wire harness connectors. Look for broken, bent, pushed out, or corroded terminals.
- Visually inspect the related harnesses. Look for chafed, pierced, or partially broken wire.
- Refer to any hotlines or technical service bulletins that may apply.

3.3.3 Reset Counter

The reset counter counts the number or times the vehicle has been started since codes were last set, erased, or the battery was disconnected. The reset counter will count up to 255 start counts.

The number of starts helps determine when the trouble code actually happened. This is recorded by the PCM and can be viewed on the DRB as the RESET COUNTER.

When there are no trouble codes stored in memory, the DRB will display “NO TROUBLE CODES FOUND” and the reset counter will show “RESET COUNT = XXX.”

3.3.4 Handling No Trouble Code Problems

After reading Section 3.0 (System Description and Functional Operation), you should have a better understanding of the theory and operation of the on-board diagnostics, and how this relates to the diagnosis of a vehicle that may have a driveability-related symptom or complaint.

The “no code” system is broken down into two test methods:

- No Code Complete Test
- No Code Quick Individual Test

3.4 Using the DRBIII®

Refer to the DRB user's guide for instructions and assistance with reading trouble codes, erasing trouble codes, and other DRB functions.

3.5 DRBIII® Error Messages and Blank Screen

Under normal operation, the DRB will display one of only two error messages:

- User-Requested WARM Boot or User-Requested COLD Boot

This is a sample of such an error message display:

```

ver: 2.14
date: 26 Jul93
file: key_itf.cc
line: 548
err: 0x1
User-Requested COLD Boot

Press MORE to switch between this display
and the application screen.
Press F4 when done noting information.
```


3.5.1 DRBIII® Does Not Power Up

If the LED's do not light or no sound is emitted at start up, check for loose cable connections or a bad cable. Check the vehicle battery voltage (data link connector cavity 16). A minimum of 11 volts is required to adequately power the DRB.

If all connections are proper between the DRB and the vehicle or other devices, and the vehicle battery is fully charged, an inoperative DRB may be the result of faulty cable or vehicle wiring. For a blank screen, refer to the appropriate body diagnostics manual.

3.5.2 Display Is Not Visible

Low temperatures will affect the visibility of the display. Adjust the contrast to compensate for this condition.





24604C3

4.0 SYSTEM COMPONENT LOCATIONS

4.1 Powertrain Control Module


TJ BODY




CAV	CKT/COLOR	FUNCTION
A2	F12 DB	Fused Ignition Switch Output
A4	K167 BR/YL	Sensor Ground
A6	T41 BR/LB	P/N Position Switch Sense
A7	K19 GY	Ignition Coil Driver
A8	K24 GY/BK	Crank Position Sensor Signal
A10	K60 YL/BK	Idle Air Control #3 Driver
A11	K40 BR/WT	Idle Air Control #2 Driver
A12	K10 DB/BR	Power Steering Pressure Switch Sense (2.5L)
A15	K21 BK/RD	Intake Air Temp Sensor Signal
A16	K2 TN/BK	ECT Sensor Signal
A17	K7 OR	5-Volt Supply (Primary)
A18	K44 TN/YL	Camshaft Position Sensor Signal
A19	K39 GY/RD	Idle Air Control #4 Driver
A20	K59 VT/ BK	Idle Air Control #1 Driver
A22	A14 RD/WT	Fused B(+)
A23	K22 OR/DB	Throttle Position Sensor Signal
A24	K41 BK/DG	Upstream O2 Sensor Signal 1/1
A25	K141 TN/WT	Downstream O2 Sensor Signal 1/2
A27	K1 DG/RD	MAP Sensor Signal
A31	Z12 BK/TN	Ground
A32	Z12 BK/TN	Ground
B4	K11 WT/DB	Injector #1 Driver
B5	K13 YL/WT	Injector #3 Driver
B6	K15 PK/BK	Injector #5 Driver
B10	K20 DG	Generator Field Driver (-)

CAV	CKT/COLOR	FUNCTION
B11	T23 OR/LG	TCC Solenoid Control (ATX ONLY)
B12	K16 LG/BK	Injector #6 Driver
B15	K12 TN	Injector #2 Driver
B16	K14 LB/BR	Injector #4 Driver
B23	G60 GY/YL	Oil Pressure Sensor Signal
B27	G7 WT/OR	Vehicle Speed Sensor Signal
B31	K6 VT/OR	5-Volt Supply (Secondary)
C1	C13 DB/OR	A/C Comp Clutch Relay Control
C3	K51 DB/YL	Auto Shutdown Relay Control
C4	V36 TN/RD	Speed Control Vacuum Sol Control
C5	V35 LG/RD	Speed Control Vent Sol Control
C11	V32 YL/RD	S/C 12-Volt Supply
C12	A142 DG/PK	Auto Shutdown Relay Output
C15	K118 PK/YL	Battery Temp Sensor Signal
C19	K31 BR	Fuel Pump Relay Control
C20	K52 PK/BK	Evap Emission Solenoid Control
C22	C22 DB/WT	A/C Switch Sense
C23	C90 LG	A/C Switch Output
C24	K29 WT/PK	Brake Switch Sense
C25	K72 DG/OR	Generator Field Source (+)
C26	K226 DB/LG	Fuel Level Sensor Signal
C27	D21 PK	SCI Transmit
C28	D2 WT/BK	CCD Bus (-)
C29	D20 LG	SCI Receive
C30	D1 VT/BR	CCD Bus (+)
C32	V37 RD/LG	S/C Switch Signal

4.1 Powertrain Control Module (Continued) XJ BODY



POWERTRAIN CONTROL
MODULE CONNECTORS



80a07547


CAV	CKT/COLOR	FUNCTION
A2	F12 DB/WT	Fused Ignition Switch Output
A4	K167 BR/YL	Sensor Ground
A6	T41 BR/LB	PNP Switch Sense (2.5L A/T)
A6	Z1 BK	Ground (2.5L M/T)
A6	T41 BK/WT	Transmission Range Switch Sense (4.0L A/T)
A7	K19 GY	Ign Coil Driver
A8	K24 GY/BK	CKP Sensor Signal
A10	K60 YL/BK	Idle Air Control #3 Driver
A11	K40 BR/WT	Idle Air Control #2 Driver
A12	K10 DB/BR	Power Steering Pressure Switch (2.5L)
A15	K21 BK/RD	IAT Signal
A16	K2 TN/BK	ECT Sensor Signal
A17	K7 OR	5-Volt Supply (Primary)
A18	K44 TN/YL	CMP Sensor Signal
A19	K39 GY/RD	Idle Air Control #4 Driver
A20	K59 VT/BK	Idle Air Control #1 Driver
A22	A61 DG/BK	Fused B(+)
A23	K22 OR/DB	TP Sensor Signal
A24	K41 BK/DG	O2 Sensor 1/1 Signal
A25	K141 TN/WT	O2 Sensor 1/2 Signal
A27	K1 DG/RD	MAP Sensor Signal
A31	Z12 BK/TN	Ground
A32	Z12 BK/TN	Ground
B4	K11 WT/DB	Injector #1 Driver
B5	K13 YL/WT	Injector #3 Driver
B6	K15 PK/BK	Injector #5 Driver

CAV	CKT/COLOR	FUNCTION
B10	K20 DG	Generator Field Driver (-)
B11	K54 OR/BK	TCC Solenoid Control (2.5L A/T)
B12	K16 LG/BK	Injector #6 Driver
B15	K12 TN	Injector #2 Driver
B16	K14 LB/BR	Injector #4 Driver
B23	G60 GY/YL	Oil Press Sensor Signal
B27	G7 WT/OR	Vehicle Speed Sensor Signal
B31	K6 VT/OR	5-Volt Supply (Secondary)
C1	C13 DB/OR	A/C Comp Clutch Relay Control
C2	C27 DB/PK	Rad Fan Relay Control
C3	K51 DB/YL	ASD Relay Control
C4	V36 TN/RD	S/C Vacuum Solenoid Control
C5	V35 LG/RD	S/C Vent Solenoid Control
C11	V32 YL/RD	S/C 12-Volt Supply
C12	A142 DG/OR	ASD Relay Output
C15	K118 PK/YL	Batt Temp Sensor Signal
C19	K31 BR	Fuel Pump Rly Ctrl
C20	K52 PK/BK	EVAP Sol Control
C22	C22 DB/WT	A/C Pressure Switch Output
C23	C90 LG	A/C Select Input
C24	K29 WT/PK	Brake Switch Sense
C25	K72 DG/OR	Generator Field Source (+)
C26	K226 DB/LG	Fuel Level Sensor
C27	D21 PK	SCI Transmit
C28	D2 WT/BK	CCD Bus (-)
C29	D20 LG/BK	SCI Receive
C30	D1 VT/BR	CCD Bus (+)
C32	V37 RD/LG	S/C SW Signal

4.2 Controls & Solenoids

TJ BODY

EVAPORATIVE SOLENOID CONNECTOR




CAV	COLOR	FUNCTION
1	PK/BK	EVAP SOLENOID CONTROL
2	RD/LG	FUSED IGNITION SWITCH OUTPUT

80b6f0e2

XJ BODY

EVAPORATIVE SOLENOID CONNECTOR




CAV	COLOR	FUNCTION
1	PK/BK	EVAP SOLENOID CONTROL
2	WT	FUSE IGNITION SWITCH OUTPUT

80b6f0da

TJ/XJ BODY


GENERATOR FIELD HARNESS CONNECTOR



CAV	COLOR	FUNCTION
1	DG/OR	GENERATOR SOURCE
2	DG	GENERATOR FIELD


80b6b12e

TJ/XJ 2.5L



80a87223


TJ/XJ 4.0L



80aac28d

TJ/XJ BODY

IDLE AIR CONTROL MOTOR CONNECTOR




CAV	COLOR	FUNCTION
1	VT/BK	IDLE AIR CONTROL #1 DRIVER
2	BR/WT	IDLE AIR CONTROL #2 DRIVER
3	YL/BK	IDLE AIR CONTROL #3 DRIVER
4	GY/RD	IDLE AIR CONTROL #4 DRIVER


80b898b2

4.2 Controls & Solenoids (Continued)

TJ/XJ 2.5L BODY




TJ/XJ 4.0L



TJ/XJ 2.5L

INJECTOR #1 CONNECTOR




CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	WT/DB	INJECTOR #1 DRIVER

80b76e62

TJ/XJ 4.0L


INJECTOR #1 CONNECTOR




CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	WT/DG	INJECTOR #1 DRIVER

80b76e67


TJ/XJ 2.5L



TJ/XJ 4.0L




TJ BODY



CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT
2	GY	IGNITION COIL DRIVER

80b6f0e3

XJ BODY




CAV	COLOR	FUNCTION
1	DG/OR	ASD RELAY OUTPUT
2	GY	IGNITION COIL DRIVER

NOTE: WIRES CAN BE IN EITHER CAVITY


80afb591

TJ BODY




80add421

XJ BODY



80add425


TJ/XJ BODY



CAV	COLOR	FUNCTION
1	TN/RD	S/C VACUUM SOLENOID CONTROL
2	LG/RD	S/C VENT SOLENOID CONTROL
3	DB/RD	S/C BRAKE SWITCH OUTPUT
4	BK	GROUND


80b04fe4

4.3 Data Link Connector
TJ BODY



80a4835f


TJ BODY



CAV	COLOR	FUNCTION
3	VT/BR	CCD BUS (+)
4	BK/LB	GROUND
5	BK/TN	GROUND
6	LG	SCI RECEIVE
7	PK	SCI TRANSMIT/ISO 9141K
11	WT/BK	CCD BUS (-)
16	PK/WT	FUSED B(+)


80a4508e

XJ BODY



80524e3d


XJ BODY



CAV	COLOR	FUNCTION
3	VT/BR	CCD BUS (+)
4	BK	GROUND
5	BK/TN	POWER GROUND
6	LG/BK	SCI RECEIVE
7	PK	SCI TRANSMIT
11	WT/BK	CCD BUS (-)
16	TN/BK	FUSED B (+)


80afb698

4.4 Sensors
TJ/XJ BODY



805005a9


TJ/XJ BODY



CAV	COLOR	FUNCTION
1	PK/YL	BATTERY TEMP SENSOR SIGNAL
2	BR/YL	SENSOR GROUND

80a5348d

TJ/XJ BODY




CRANKSHAFT POSITION SENSOR CONNECTOR

1070404

TJ/XJ BODY


CRANKSHAFT POSITION SENSOR CONNECTOR



CAV	COLOR	FUNCTION
1	GY/BK	CRANKSHAFT POSITION SENSOR SIGNAL
2	BR/YL	SENSOR GROUND
3	OR	5-VOLT SUPPLY

80b0995b

TJ/XJ 2.5L & 4.0L




DISTRIBUTOR

CAMSHAFT POSITION SENSOR CONNECTOR

1100106

TJ/XJ BODY


CAMSHAFT POSITION SENSOR CONNECTOR



CAV	COLOR	FUNCTION
1	TN/YL	CAMSHAFT POSITION SENSOR SIGNAL
2	BR/YL	SENSOR GROUND
3	OR	5-VOLT SUPPLY

80afb5cc

TJ/XJ 2.5L & 4.0L




COOLANT TEMPERATURE SENSOR

THERMOSTAT HOUSING

1050203

TJ BODY

ENGINE COOLANT TEMPERATURE SENSOR CONNECTOR




CAV	COLOR	FUNCTION
1	TN/BK	ECT SENSOR SIGNAL
2	BR/YL	SENSOR GROUND

80af15a0

4.4 Sensors (Continued)

XJ BODY


ENGINE COOLANT
TEMP SENSOR
CONNECTOR



CAV	COLOR	FUNCTION
1	BR/YL	SENSOR GROUND
2	TN/BK	ECT SENSOR SIGNAL


80b098a7

TJ/XJ 2.5L



80a87223


TJ/XJ 4.0L



80524e3c

TJ BODY

INTAKE AIR TEMPERATURE SENSOR CONNECTOR




CAV	COLOR	FUNCTION
1	BK/RD	IAT SIGNAL
2	BR/YL	SENSOR GROUND

80aff501

XJ BODY

INTAKE AIR TEMPERATURE SENSOR CONNECTOR




CAV	COLOR	FUNCTION
1	BR/YL	SENSOR GROUND
2	BK/RD	IAT SIGNAL

80b099c6

TJ/XJ BODY

MAP SENSOR
CONNECTOR




CAV	COLOR	FUNCTION
3	OR	5-VOLT SUPPLY
2	DG/RD	MAP SENSOR SIGNAL
1	BR/YL	SENSOR GROUND

80afa155

TJ 2.5L & 4.0L 1/1

JTEC O2 SENSOR CONFIGURATION

TJ2.5L	1/1	UPSTREAM	XJ2.5L	1/1	UPSTREAM
TJ2.5L	1/2	DOWNSTREAM	XJ2.5L	1/2	DOWNSTREAM
TJ4.0L	1/1	UPSTREAM	XJ4.0L	1/1	UPSTREAM
TJ4.0L	1/2	DOWNSTREAM	XJ4.0L	1/2	DOWNSTREAM




UPSTREAM OXYGEN SENSOR

80a410c5

80b76ec3


XJ 2.5L & 4.0L 1/1



OXYGEN SENSOR

J9514-17

TJ 2.5L & 4.0L 1/2




DOWNSTREAM OXYGEN SENSOR

CATALYTIC CONVERTER

80a410c4

TJ BODY 1/1




UPSTREAM OXYGEN SENSOR CONNECTOR (HARNESS SIDE)

CAV	COLOR	FUNCTION
1	OR/DG	ASD Relay Output
2	BK	Ground (Heater)
3	BR/YL	Sensor Ground
4	BK/DG	Oxygen Sensor Signal

80b6f0e5

TJ BODY 1/2




DOWNSTREAM OXYGEN SENSOR CONNECTOR (HARNESS SIDE)

CAV	COLOR	FUNCTION
1	OR/DG	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	TN/WT	OXYGEN SENSOR SIGNAL

80b6f0e6

4.4 Sensors (Continued)


XJ BODY 1/1



CAV	COLOR	FUNCTION
1	DG/WT	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	BK/DG	OXYGEN SENSOR SIGNAL

80b6f0db


XJ BODY 1/2



CAV	COLOR	FUNCTION
1	OR/DG	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	TN/WT	OXYGEN SENSOR SIGNAL


80b6f0dc

TJ/XJ 2.5L




80a87223

TJ/XJ 4.0L



80524e3c


TJ/XJ BODY



CAV	COLOR	FUNCTION
1	BR/YL	SENSOR GROUND
2	OR/DB	TP SENSOR SIGNAL
3	OR	5-VOLT SUPPLY

80b6f0e7

TJ/XJ BODY




CAV	COLOR	FUNCTION
1	VT/OR	5-VOLT SUPPLY
2	BR/YL	SENSOR GROUND
3	WT/OR	VEHICLE SPEED SENSOR SIGNAL

80b0d63c

4.5 Fuel System TJ BODY

FUEL PUMP CONNECTOR




CAV	COLOR	FUNCTION
1	DG/WT	FUEL PUMP RELAY OUTPUT
3	DB/LG	FUEL LEVEL SENSOR SIGNAL (OBD II)
4	BR/YL	SENSOR GROUND
6	BK	GROUND

80b099c8

XJ BODY


FUEL PUMP MODULE CONNECTOR



CAV	COLOR	FUNCTION
1	DG/WT	FUEL PUMP RELAY OUTPUT
3	DB/LG	FUEL LEVEL SENSOR SIGNAL
4	BR/YL	SENSOR GROUND
6	BK	GROUND


80aafa16

TJ BODY




80a43851

XJ BODY



80aac284


4.6 Relays TJ BODY



CAV	COLOR	FUNCTION
6(30)	RD/GY	FUSED B(+)
7(87)	DB/BK	A/C CMP CLUTCH RELAY OUTPUT
8(86)	VT/WT	FUSED IGNITION SWITCH OUTPUT
10(85)	DB/OR	A/C CMP CLUTCH RELAY CONTROL

80b6f108

XJ BODY




CAV	COLOR	FUNCTION
1 (30)	RD/BK	FUSED B(+)
2 (87)	DB/BK	A/C CLUTCH RELAY OUTPUT
3 (85)	DB/OR	A/C CLUTCH RELAY CONTROL
5 (86)	DB/WT	FUSED IGNITION SWITCH OUTPUT

80b6f0de

4.6 Relays (Continued)


TJ BODY



CAV	COLOR	FUNCTION
1(30)	RD/WT	FUSED B(+)
2(87)	DG/PK	AUTO SHUTDOWN RELAY OUTPUT
3(86)	DB	IGNITION SWITCH OUTPUT
5(85)	DB/YL	AUTO SHUTDOWN RELAY CONTROL

80b6f109


XJ BODY



CAV	COLOR	FUNCTION
2 (30)	RD/LG	FUSED B(+)
4 (85)	DB/WT	FUSED IGNITION SWITCH OUTPUT
6 (86)	DB/YL	ASD RELAY CONTROL
8 (87)	RD	ASD RELAY OUTPUT

80b6f0df


TJ BODY



CAV	COLOR	FUNCTION
16(30)	DG/BK	FUSED B(+)
17(87)	DG/WT	FUEL PUMP RELAY OUTPUT
18(86)	DB	FUSED IGNITION SWITCH OUTPUT
20(85)	BR	FUEL PUMP RELAY CONTROL

80b6f0e9


XJ BODY



CAV	COLOR	FUNCTION
2 (30)	DG/BK	FUSED B(+)
8 (87)	DG/WT	FUEL PUMP RELAY OUTPUT
4 (86)	DB/WT	FUSED IGNITION SWITCH OUTPUT
6 (85)	BR	FUEL PUMP RELAY CONTROL

80b6f0e0


TJ BODY



CAV	COLOR	FUNCTION
10(30)	PK/BK	FUSED B(+)
11(85)	YL/RD	IGNITION SWITCH OUTPUT
13(86)	BR/LB	PARK NEUTRAL SWITCH SENSE (AUTO TRANS) GROUND (MANUAL TRANS)
14(87)	BR	STARTER RELAY OUTPUT

80b6f107


XJ BODY




CAV	COLOR	FUNCTION
10 (30)	YL	FUSED B(+)
11 (85)	BK/WT	P/N POSITION SWITCH SENSE (AUTO TRANSMISSION) GROUND (MANUAL TRANSMISSION)
13 (86)	YL	FUSED IGNITION SWITCH OUTPUT
14 (87)	BR	STARTER RELAY OUTPUT

80b6f0e1

POWER DISTRIBUTION CENTER



RADIATOR FAN RELAY CONNECTOR




CAV	COLOR	FUNCTION
10 (30)	LG/RD	FUSED B(+)
11 (86)	WT	FUSED IGNITION SWITCH OUTPUT
13 (85)	DB/PK	RAD FAN RELAY CONTROL
14 (87)	LB	RAD FAN RELAY OUTPUT

80b76e94

4.7 Switches


TJ/XJ BODY



2480302

TJ BODY

BRAKE LAMP SWITCH CONNECTOR




CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SWITCH SENSE
2	BK	GROUND
3	YL/RD	12-VOLT SUPPLY
4	DB/RD	S/C BRAKE SWITCH OUTPUT
5	PK/DB	FUSED B(+)
6	WT/TN	BRAKE LAMP SWITCH OUTPUT

80b099e1

XJ BODY


BRAKE LAMP SWITCH CONNECTOR



CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SWITCH SENSE
2	BK	GROUND
3	YL/RD	12-VOLT SUPPLY
4	DB/RD	S/C BRAKE SWITCH OUTPUT
5	WT/TN	BRAKE LAMP SWITCH OUTPUT
6	PK/DB	FUSED B(+)

80b04fe6

TJ/XJ BODY




80a0754e

4.7 Switches (Continued)

TJ/XJ


SPEED CONTROL SWITCH CONNECTOR



CAV	COLOR	FUNCTION
1	BR/YL	GROUND
2	RD/LG	SPEED CONTROL SIGNAL

80ab3724

PARK/NEUTRAL POSITION SWITCH CONNECTOR



XJ 2.5L A/T

CAV	COLOR	FUNCTION
1	WT	FUSED IGNITION SWITCH OUTPUT
2	BK/WT	PARK/NEUTRAL POSITION SW SENSE
3	BR/LG	BACK-UP LAMPS FEED


TJ 2.5L AND 4.0L A/T

CAV	COLOR	FUNCTION
1	VT/WT	FUSED IGNITION SWITCH OUTPUT
2	BR/LB	PARK/NEUTRAL POSITION SW SENSE
3	VT/BK	BACK-UP LAMPS FEED

80b76f29

XJ BODY 4.0L


TRANSMISSION RANGE SENSOR CONNECTOR



CAV	COLOR	FUNCTION
7	BK/WT	PARK/NEUTRAL POSITION SWITCH SENSE
8	BK	GROUND

80b76f2a

TJ/XJ 2.5L




POWER STEERING PRESSURE SWITCH

ELECTRICAL CONNECTOR

80a4a593

TJ/XJ 2.5L

POWER STEERING SWITCH CONNECTOR



CAV	COLOR	FUNCTION
1	BK	GROUND
2	DB/BR	POWER STEERING PRESSURE SW SENSE (2.5L TJ/XJ)

80b76f27

5.0 DISCLAIMERS, SAFETY, WARNINGS

5.1 Disclaimers

All information, illustrations, and specifications contained in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

5.2 Safety and Warnings

5.2.1 Technician Safety Information

WARNING: Engines produce carbon monoxide that is odorless, causes slower reaction time, and can lead to serious injury. When the engine is operating, keep service areas WELL VENTILATED or attach the vehicle exhaust system to the shop exhaust removal system.

WARNING: Before performing any secondary ignition testing with open sparks, insure there are no fuel leaks or vapors present in the immediate area.

Set the parking brake and block the wheels before testing or repairing the vehicle. It is especially important to block the wheels on front-wheel drive vehicles; the parking brake does not hold the drive wheels.

When servicing a vehicle, always wear eye protection, and remove any metal jewelry such as watchbands or bracelets that might make an inadvertent electrical contact.

When diagnosing a body system problem, it is important to follow approved procedures where applicable. These procedures can be found in General Information Section 9.0 (Specifications) or in service manual procedures. Following these procedures is very important to the safety of individuals performing diagnostic tests.

5.2.2 Vehicle Preparation for Testing

Make sure the vehicle being tested has a fully charged battery. If it does not, false diagnostic codes or error messages may occur.

5.2.3 Servicing Sub-Assemblies

Some components of the powertrain system are intended to be serviced in assembly only. Attempting to remove or repair certain system sub-components may result in personal injury and/or improper system operation. Only those components with approved repair and installation procedures in the service manual should be serviced.

5.2.4 DRBIII® Safety Information

WARNING: Exceeding the limits of the DRBIII® multimeter is dangerous. It can expose you to serious or possibly fatal injury. Carefully read and understand the cautions and the specification limits.

- Follow the vehicle manufacturer's service specifications at all times.
- Do not use the DRB if it has been damaged.
- Do not use the test leads if the insulation is damaged or if metal is exposed.
- To avoid electrical shock, do not touch the test leads, tips, or the circuit being tested.
- Choose the proper range and function for the measurement. Do not try voltage or current measurements that may exceed the rated capacity.

- Do not exceed the limits shown in the table below:

FUNCTION	INPUT LIMIT
Volts	0 - 500 peak volts AC 0 - 500 volts DC
Ohms (resistance)*	0 - 1.12 megohms
Frequency Measured Frequency Generated	0 - 10 kHz
Temperature	-58 - 1100° F -50 - 600° C

* Ohms cannot be measured if voltage is present. Ohms can be measured only in a non-powered circuit.

- Voltage between any terminal and ground must not exceed 500v DC or 500v peak AC.
- Use caution when measuring voltage above 25v DC or 25v AC.
- The circuit being tested must be protected by a 10A fuse or circuit breaker.
- Use the low current shunt to measure circuits up to 10A. Use the high current clamp to measure circuits exceeding 10A.
- When testing for the presence of voltage or current, make sure the meter is functioning correctly. Take a reading of a known voltage or current before accepting a zero reading.
- When measuring current, connect the meter in series with the load.
- Disconnect the live test lead before disconnecting the common test lead.
- When using the meter function, keep the DRB away from spark plug or coil wires to avoid measuring error from outside interference.

5.3 Warnings and Cautions

5.3.1 **Vehicle Damage Warnings**

Before disconnecting any control module, make sure the ignition is “off”. Failure to do so could damage the module.

When testing voltage or continuity at the powertrain control module, use the terminal side (not the wire end) of the connector. Do not probe a wire through the insulation; this will damage it and eventually cause it to fail because of corrosion.

Be careful when performing electrical tests so as to prevent accidental shorting of terminals. Such mistakes can damage fuses or components. Also, a second code could be set, making diagnosis of the original problem more difficult.

5.3.2 **Road Testing a Complaint Vehicle**

Some complaints will require a test drive as part of the repair verification procedure. The purpose of the test drive is to try to duplicate the diagnostic code or symptom condition.

CAUTION: Before road testing a vehicle, be sure that all components are reassembled. During the test drive, do not try to read the DRBIII® screen while in motion. Do not hang the DRB from the rear view mirror or operate it yourself. Have an assistant available to operate the DRBIII®.

7.1 GENERAL TROUBLESHOOTING

DTC TEST

CHECKING THE SYSTEM FOR DIAGNOSTIC TROUBLE CODES

NOTE: For all component locations, REFER TO GENERAL INFORMATION sections 4.0 in this manual.

NOTE: The battery must be fully charged for any test in this manual.

1. Attempt to start the engine. Crank for up to 10 seconds if necessary.
2. Connect the DRB to the engine diagnostic connector. Write down the trouble codes that are displayed.
3. If the DRB screen displays “No Response”, go to the **TEST NS-SEL**.
4. If the DRB screen is blank or has a DRB message, go to **General Information Section 3.5** in this manual.
5. If **trouble code messages** are displayed, refer to the trouble code list below and on the next page for the appropriate test.
6. If there are **no trouble codes** displayed, refer to one of the following:

- For SKIS problemsSK-1A
- For Driveability problemsNTC-1A
- For No Start problemsNS-SEL
- For Speed Control problemsSC-1A
- For Charging problems.CH-1A

NOTE: The decimal test numbers for these trouble codes were derived from the hexadecimal codes as set in the PCM. Therefore, some test numbers will be missing because all codes are not applicable to the vehicles covered in this manual.

TROUBLE CODE DESCRIPTION	TEST #	DTC HEX	SCAN TOOL
A/C CLUTCH RELAY CIRCUIT	TC-16	10	N/A
AISIN AW4 TRANS (TCM) DTC PRESENT	**	89	P 0700
AUTO SHUTDOWN RELAY CONTROL CIRCUIT	TC-10	0A	N/A
BATTERY TEMP SENSOR VOLTAGE TOO HIGH	TC-153	9A	P 1492
BATTERY TEMP SENSOR VOLTAGE TOO LOW	TC-153	99	P 1493
CHARGING SYSTEM VOLTAGE TOO HIGH	TC-6	06	N/A
CHARGING SYSTEM VOLTAGE TOO LOW	TC-5	05	N/A
1/2 02S VOLTS SHORTED TO GND	TC-156	9C	P 0137
1/2 02S SHORTED TO VOLTAGE	TC-126	7E	P 0138
ECT SENSOR VOLTAGE TOO HIGH	TC-31	1F	P 0118
ECT SENSOR VOLTAGE TOO LOW	TC-30	1E	P 0117
ENGINE IS COLD TOO LONG	**	21	P 1281
EVAP PURGE SOLENOID CIRCUIT	TC-18	12	P 0443
FUEL LEVEL SENDING UNIT NO CHANGE OVER TIME	TC-151	F4	P 0461
FUEL LEVEL SENDING UNIT VOLTS TOO HIGH	TC-150	96	N/A
FUEL LEVEL SENDING UNIT VOLTS TOO LOW	TC-149	95	N/A
FUEL PUMP RELAY CONTROL CIRCUIT	TC-101	65	N/A
FUEL SYSTEM LEAN 1/1 LEAN	TC-119	77	P 0171
FUEL SYSTEM RICH 1/1 RICH	TC-118	76	P 0172
GENERATOR FIELD NOT SWITCHING PROPERLY	TC-11	0B	N/A
IDLE AIR CONTROL MOTOR CIRCUIT	TC-25	19	P 0505
IGNITION COIL #1 PRIMARY CIRCUIT	TC-43	2B	P 0351
INJECTOR #1 CONTROL CIRCUIT	TC-21	15	P 0201
INJECTOR #2 CONTROL CIRCUIT	TC-21	14	P 0202
INJECTOR #3 CONTROL CIRCUIT	TC-21	13	P 0203
INJECTOR #4 CONTROL CIRCUIT	TC-21	3D	P 0204
INJECTOR #5 CONTROL CIRCUIT	TC-21	45	P 0205
INJECTOR #6 CONTROL CIRCUIT	TC-21	46	P 0206

DTC TEST		CONTINUED - CHECKING THE SYSTEM FOR DIAGNOSTIC TROUBLE CODES		
TRouble CODE	TEST #	DTC	SCAN TOOL	
DESCRIPTION		HEX		
INTAKE AIR TEMP SENSOR VOLTAGE HIGH	TC-58	3A	P 0113	
INTAKE AIR TEMP SENSOR VOLTAGE LOW	TC-57	39	P 0112	
INTERMITTENT LOSS OF CMP OR CKP	TC-157	9D	P 1391	
INTERNAL CONTROLLER FAILURE	**	02	P 0601	
*MAP SENSOR VOLTAGE TOO HIGH	TC-37	25	P 0108	
*MAP SENSOR VOLTAGE TOO LOW	TC-36	24	P 0107	
NO 5 VOLTS TO MAP SENSOR	TC-36	87	P 1296	
NO ASD RELAY OUTPUT VOLTAGE AT PCM	TC-44	2C	P 1389	
NO CAM SIGNAL AT PCM	TC-1	01	P 0340	
NO CCD BUS MESSAGE RECEIVED FROM TCM	**	60	P 1698	
NO CCD BUS MESSAGE RECEIVED FROM MIC	TC-225	E1	P 1687	
NO CCD BUS MESSAGE RECEIVED FROM SKIM	TC-226	E2	P 1686	
NO CHANGE IN MAP FROM START TO RUN	TC-39	27	P 1297	
NO CRANK REFERENCE SIGNAL AT PCM	TC-40	28	P 0320	
NO VEHICLE SPEED SENSOR SIGNAL	TC-35	23	P 0500	
OIL PRESSURE SENSOR LOW EXCEEDED	TC-235	EB	P 0522	
OIL PRESSURE SENSOR HIGH EXCEEDED	TC-236	EC	P 0523	
P/N SWITCH STUCK IN PARK OR IN GEAR	TC-114	72	P 1899	
PCM FAILURE EEPROM WRITE DENIED	TC-49	31	P 1696	
PCM FAILURE SPI COMMUNICATIONS	**	44	P 0600	
POWER STEERING SWITCH FAILURE	TC-115	73	P 0551	
RADIATOR FAN CONTROL RELAY CIRCUIT	TC-14	OE	P 1491	
SPEED CONTROL POWER RELAY OR S/C 12V DRIVER CKT	TC-82	52	N/A	
SPEED CONTROL SOLENOIDS CIRCUITS	TC-15	OF	N/A	
SPEED CONTROL SWITCH ALWAYS HIGH	TC-86	56	P 1596	
SPEED CONTROL SWITCH ALWAYS LOW	TC-87	57	N/A	
*THROTTLE POSITION SENSOR VOLTAGE HIGH	TC-27	1B	P 0123	
*THROTTLE POSITION SENSOR VOLTAGE LOW	TC-26	1A	P 0122	
TORQ CONV CLU, NO RPM DROP AT LOCKUP	TC-148	94	P 0740	
TORQUE CONVERTER CLUTCH SOLENOID/TRANS RELAY CKT	TC-12	0C	P 0743	
*TPS VOLTAGE DOES NOT AGREE WITH MAP	TC-132	84	P 0121	
1/1 O2S VOLTAGE SHORTED TO GROUND	TC-155	9B	P 0131	
1/1 O2 SENSOR SHORTED TO VOLTAGE	TC-62	3E	P 0132	
WRONG OR INVALID KEY MSG RECEIVED FROM SKIM	TC-232	E8	P 1685	

* = These DTC's can be set by Low Fuel Level, add fuel to 1/4 tank and test for DTC to set again.
** = Trouble code information on last page of DTC test.

For an AISIN TRANS (TCM) DTC PRESENT trouble code, use the appropriate Transmission diagnostic manual, with the DRB read transmission DTC's.

For an ENGINE IS COLD TOO LONG trouble code, the engine does not warm to 176°F while driving for at least 20 minutes after a start. See the service manual for cooling system repair (Thermostat).

For an INTERNAL CONTROLLER FAILURE, replace the Powertrain control module and perform **Verification TEST VER-2A**.


For a NO CCD/PCI BUS MESSAGE FROM TCM trouble code, use the appropriate trans diagnostic manual for testing and repair.

For a PCM FAILURE SPI COMMUNICATIONS trouble code, replace the Powertrain control module and perform **Verification TEST VER-2A**.

TEST TC-1A

REPAIRING - NO CAM SIGNAL AT PCM

Perform TEST DTC Before Proceeding



Name of Code: No Cam Signal at PCM

When monitored: Ignition ON.

Set condition: If 96 crank signals are counted and no signal from the cam position sensor is present the code will set.

Theory of operation: The cam position sensor is a hall effect-type sensor used to detect the camshaft position. The PCM supplies 5 volts and a ground to power up the sensor. The PCM also supplies a 5-volt pull-up voltage. The sensor signal is created by the pulse ring in the distributor passing through the sensor. When the leading edge of the ring is in the sensor, the sensor is high (5.0V); when the trailing edge is clear of the sensor, the signal is low (0.3V).


Possible causes:

- Open 5-volt supply circuit
- Open sensor ground
- Open or shorted signal circuit
- Damaged pulse ring
- Failed sensor
- Failed PCM

80aa4ba4

TJ/XJ BODY

CAMSHAFT POSITION SENSOR CONNECTOR



CAV	COLOR	FUNCTION
1	TN/YL	CAMSHAFT POSITION SENSOR SIGNAL
2	BR/YL	SENSOR GROUND
3	OR	5-VOLT SUPPLY


FIG. 1

80afb5cc

TEST TC-1A

REPAIRING - NO CAM SIGNAL AT PCM

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


TJ/XJ BODY

**CAMSHAFT POSITION
SENSOR CONNECTOR**



CAV	COLOR	FUNCTION
1	TN/YL	CAMSHAFT POSITION SENSOR SIGNAL
2	BR/YL	SENSOR GROUND
3	OR	5-VOLT SUPPLY


**POWERTRAIN
CONTROL MODULE
BLACK CONNECTOR**



CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A17	OR	5-VOLT SUPPLY
A18	TN/YL	CAMSHAFT POSITION SENSOR SIGNAL

80afb5cb

FIG. 1



*Perform Verification TEST VER-2A.

**Check connectors - Clean / repair as necessary.




FIG. 1

1070304

Name of Code: No Cam Signal at PCM

When monitored: Ignition ON.


Set condition: If 96 crank signals are counted and no signal from the cam position sensor is present the code will set.

Theory of operation: The cam position sensor is a hall effect-type sensor used to detect the camshaft position. The PCM supplies 5 volts and a ground to power up the sensor. The PCM also supplies a 5-volt pull-up voltage. The sensor signal is created by the pulse ring in the distributor passing through the sensor. When the leading edge of the ring is in the sensor, the sensor is high (5.0V); when the trailing edge is clear of the sensor, the signal is low (0.3V).

Possible causes:

- Open 5-volt supply circuit
- Open sensor ground
- Open or shorted signal circuit
- Damaged pulse ring
- Failed sensor
- Failed PCM

80aa4ba4



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

Name of Code: No Cam Signal at PCM

When monitored: Ignition ON.

Set condition: If 96 crank signals are counted and no signal from the cam position sensor is present the code will set.

Theory of operation: The cam position sensor is a hall effect-type sensor used to detect the camshaft position. The PCM supplies 5 volts and a ground to power up the sensor. The PCM also supplies a 5-volt pull-up voltage. The sensor signal is created by the pulse ring in the distributor passing through the sensor. When the leading edge of the ring is in the sensor, the sensor is high (5.0V); when the trailing edge is clear of the sensor, the signal is low (0.3V).


Possible causes:

- Open 5-volt supply circuit
- Open sensor ground
- Open or shorted signal circuit
- Damaged pulse ring
- Failed sensor
- Failed PCM

80aa4ba4

FIG. 1


TJ/XJ BODY



80a4eff4

TEST TC-1C

REPAIRING - NO CAM SIGNAL AT PCM



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TEST TC-5A

REPAIRING - CHARGING SYSTEM VOLTAGE TOO LOW

Perform TEST DTC Before Proceeding

Name of code: Charging System Voltage Too Low

When monitored: With the ignition key on and the engine running over 1500 RPM after 25 seconds.

Set condition: When the PCM regulates the generator field and there are no detected field problems but the voltage output does not increase.


Theory of operation: The PCM tries to maintain a system voltage between 12.9 volts and 15.0 volts. The voltage determined by the PCM as the final goal for the charging system is called "control" voltage. This control voltage is determined from the battery temp sensor (ambient sensor). The control voltage is compared to the sensed voltage continuously during running. The PCM controls battery voltage by energizing and de-energizing the alternator field winding. When the battery voltage falls below a setpoint voltage, the generator field winding is energized until the battery voltage exceeds a setpoint voltage.

Possible causes:

- > Defects in generator drive belt or adjustment
- > High resistance between battery (+) and generator (+)
- > High resistance between battery (-) and generator ground
- > PCM failure

80aa0ff4


TJ/XJ BODY



80b6f0cd

TJ/XJ BODY

BATTERY TEMPERATURE SENSOR CONNECTOR



CAV	COLOR	FUNCTION
1	PK/YL	BATTERY TEMP SENSOR SIGNAL
2	BR/YL	SENSOR GROUND


FIG. 1

80aaf127

TEST TC-5A


REPAIRING - CHARGING SYSTEM VOLTAGE TOO LOW

Perform TEST DTC Before Proceeding



***Perform Verification TEST VER-3A.**


****Check connectors - Clean / repair as necessary.**



CAV	COLOR	FUNCTION
1	DG/OR	GENERATOR SOURCE
2	DG	GENERATOR FIELD
*	BK/GY	B(+)

80b6b36c

FIG. 1



*Perform Verification TEST VER-3A.

**Check connectors - Clean / repair as necessary.


TEST TC-5B

REPAIRING - CHARGING SYSTEM VOLTAGE TOO LOW

Perform TEST TC-5A Before Proceeding

TJ/XJ BODY


GENERATOR FIELD HARNESS CONNECTOR




CAV	COLOR	FUNCTION
1	DG/OR	GENERATOR SOURCE
2	DG	GENERATOR FIELD DRIVER

POWERTRAIN CONTROL MODULE CONNECTORS

GREY



WHITE




CAV	COLOR	FUNCTION
B10	DG	GENERATOR FIELD DRIVER
C25	DG/OR	GENERATOR FIELD SOURCE

FIG. 1

80b6b37b

TJ/XJ BODY

GENERATOR FIELD HARNESS CONNECTOR



CAV	COLOR	FUNCTION
1	DG/OR	GENERATOR SOURCE
2	DG	GENERATOR FIELD

FIG. 2


80b6b12e

TEST TC-5B

REPAIRING - CHARGING SYSTEM VOLTAGE TOO LOW

TROUBLE CODE TESTS

Perform TEST TC-5A Before Proceeding



***Perform Verification TEST VER-3A.**


****Check connectors - Clean / repair as necessary.**

TEST TC-6A

REPAIRING - CHARGING SYSTEM VOLTAGE TOO HIGH

Perform TEST DTC Before Proceeding

TJ/XJ BODY



80b6f0cd

Name of code: Charging System Voltage Too High

When monitored: With the ignition key on and the engine speed greater than 0 RPM.

Set condition: When the PCM regulates the generator field and there are no detected field problems but the voltage output does not decrease.


Theory of operation: The PCM tries to maintain a system voltage between 12.9 volts and 15.0 volts. The voltage determined by the PCM as the final goal for the charging system is called "control" voltage. This control voltage is determined from the battery temp sensor (ambient sensor). The control voltage is compared to the sensed voltage continuously during running. The PCM controls battery voltage by energizing and de-energizing the alternator field winding. When the battery voltage falls below a setpoint voltage, the generator field winding is energized until the battery voltage exceeds a setpoint voltage.

Possible causes:

- > Generator internal short
- > Generator field driver short to ground
- > PCM failure

80aa0ff2

GENERATOR FIELD HARNESS CONNECTOR



CAV	COLOR	FUNCTION
1	DG/OR	GENERATOR SOURCE
2	DG	GENERATOR FIELD


FIG. 1

80b6b12e

TEST TC-6A


REPAIRING - CHARGING SYSTEM VOLTAGE TOO HIGH

Perform TEST DTC Before Proceeding



***Perform Verification TEST VER-3A.**

****Check connectors - Clean / repair as necessary.**




CAV	COLOR	FUNCTION
1	DG/OR	GENERATOR SOURCE
2	DG	GENERATOR FIELD
*	BK/GY	B(+)

80b6b36c

FIG. 1

TJ BODY

POWERTRAIN CONTROL MODULE CONNECTORS




CAV	COLOR	FUNCTION
A22	RD/WT	FUSED B (+)
B10	DG	GENERATOR FIELD DRIVER
C12	DG/PK	AUTO SHUTDOWN RELAY

80b099df

FIG. 2

XJ BODY


POWERTRAIN CONTROL MODULE CONNECTORS



CAV	COLOR	FUNCTION
A22	DG/BK	FUSED B(+)
B10	DG	GENERATOR FIELD DRIVER
C12	DG/OR	AUTO SHUTDOWN RELAY

80b04fdf

FIG. 3



***Perform Verification TEST VER-3A.**


****Check connectors - Clean / repair as necessary.**

TEST TC-6B

REPAIRING - CHARGING SYSTEM VOLTAGE TOO HIGH

Perform TEST TC-6A Before Proceeding

TJ/XJ BODY




80b6f0cd

TEST TC-6B

REPAIRING - CHARGING SYSTEM VOLTAGE TOO HIGH

Perform TEST TC-6A Before Proceeding



***Perform Verification TEST VER-3A.**


****Check connectors - Clean / repair as necessary.**

T
R
O
U
B
L
E
C
O
D
E
T
E
S
T
S

TEST TC-6B

CONTINUED - REPAIRING - CHARGING SYSTEM VOLTAGE TOO HIGH

NOTES



*Perform Verification TEST VER-3A.


**Check connectors - Clean / repair as necessary.

TEST TC-10A

REPAIRING - AUTO SHUTDOWN RELAY CONTROL CIRCUIT


Perform TEST DTC Before Proceeding

TJ BODY



80b6f0d0

XJ BODY



80b04fe0

Name of code: Auto Shutdown Relay Control Circuit**When monitored:** With ignition key on and battery voltage greater than 10.4 volts.

Theory of operation: The Automatic Shutdown Relay (ASD) controls the 12-volt source to the fuel injectors, ignition coil(s), and the oxygen heaters. (And low pressure shutoff solenoid on CNG). The relay is located in the Power Distribution Center (PDC). One side of the relay control coil is supplied with battery voltage when the ignition switch is in the start or run position. The circuit is completed when the other side of the relay coil is grounded by the Powertrain Control Module (PCM). The PCM grounds the control circuit when the ignition switch is in the start or run position and engine RPM is detected. If engine RPM is not detected, the PCM will remove the ASD relay control circuit ground.

Possible causes:

- > Relay coil open or shorted.
- > Fused ignition switch output circuit open.
- > Auto shutdown relay control circuit open or shorted.
- > Inoperative circuit driver in PCM (PCM Failure)
- > Connector terminals


FIG. 1

80a9b324

TEST TC-10A

REPAIRING - AUTO SHUTDOWN RELAY CONTROL CIRCUIT

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


TJ BODY

**AUTO SHUTDOWN RELAY CONNECTOR
(IN PDC)**

CAV	COLOR	FUNCTION
1 (30)	RD/WT	FUSED B+
2 (87)	DG/PK	AUTO SHUTDOWN RELAY OUTPUT
3 (86)	DB	IGNITION SWITCH OUTPUT
5 (85)	DB/YL	AUTO SHUTDOWN RELAY CONTROL



**POWERTRAIN
CONTROL MODULE
GREY CONNECTOR**



CAV	COLOR	FUNCTION
C3	DB/YL	AUTO SHUTDOWN RELAY CONTROL
C12	DG/PK	AUTO SHUTDOWN RELAY OUTPUT


80b76e90

FIG. 1


XJ BODY

**AUTO SHUTDOWN RELAY CONNECTOR
(IN PDC)**

CAV	COLOR	FUNCTION
2 (30)	RD/LG	FUSED B(+)
4 (85)	DB/WT	FUSED IGNITION SWITCH OUTPUT
6 (86)	DB/YL	ASD RELAY CONTROL
8 (87)	RD	ASD RELAY OUTPUT



**POWERTRAIN
CONTROL MODULE
GREY CONNECTOR**




CAV	COLOR	FUNCTION
C3	DB/YL	AUTO SHUTDOWN RELAY CONTROL
C12	DG/OR	AUTO SHUTDOWN RELAY OUTPUT

80b76e93

FIG. 2


TJ BODY



80b76e97


FIG. 3

XJ BODY



80b76e98

FIG. 4



*Perform Verification TEST VER-2A.


**Check connectors - Clean / repair as necessary.

TEST TC-11A

REPAIRING - GENERATOR FIELD NOT SWITCHING PROPERLY


Perform TEST DTC Before Proceeding

TJXJ BODY



80b6f0cd

GENERATOR FIELD HARNESS CONNECTOR



CAV	COLOR	FUNCTION
1	DG/OR	GENERATOR SOURCE
2	DG	GENERATOR FIELD

FIG. 1

80b6b12e

Name of code: Generator Field Not Switching Properly

When monitored: With the ignition key on and the engine running.

Set condition: When the PCM tries to regulate the generator field with no result during monitoring.

Theory of operation: The PCM tries to maintain a system voltage between 12.9 volts and 15.0 volts. The voltage determined by the PCM as the final goal for the charging system is called "control" voltage. This control voltage is determined from the battery temp sensor (ambient sensor). The control voltage is compared to the sensed voltage continuously during running. If the sensed voltage is less than the control voltage, the PCM will supply more ground to the field circuit. If the sensed voltage is more than the control voltage, the PCM will supply less ground to the field circuit.

Possible causes:

- > Field driver circuit open or shorted
- > Generator internal open or short
- > PCM failed


FIG. 2

2360602

TEST TC-11A

REPAIRING - GENERATOR FIELD NOT SWITCHING PROPERLY


Perform TEST DTC Before Proceeding



***Perform Verification TEST VER-3A.**

****Check connectors - Clean / repair as necessary.**


GENERATOR FIELD HARNESS CONNECTOR



CAV	COLOR	FUNCTION
1	DG/OR	GENERATOR SOURCE
2	DG	GENERATOR FIELD DRIVER


POWERTRAIN CONTROL MODULE CONNECTORS

GREY



C25

WHITE




B10

CAV	COLOR	FUNCTION
B10	DG	GENERATOR FIELD DRIVER
C25	DG/OR	GENERATOR FIELD SOURCE

80b6b37b


FIG. 1



CAV	COLOR	FUNCTION
1	DG/OR	GENERATOR SOURCE
2	DG	GENERATOR FIELD
*	BK/GY	B(+)

80b6b36c

FIG. 2



*Perform Verification TEST VER-3A.


**Check connectors - Clean / repair as necessary.

TEST TC-12A

REPAIRING TORQUE CONVERTER CLUTCH/TRANS RELAY CKT (TJ/XJ BODY WITH 3SPD AUTO TRANS)

Perform TEST DTC Before Proceeding


TJ/XJ BODY WITH 3 SPD AUTO TRANS



407C105

TJ/XJ BODY WITH 3 SPD AUTO TRANS

TORQUE CONVERTER CLUTCH SOLENOID CONNECTOR




CAV	COLOR	FUNCTION
A	RD/LG	FUSED IGNITION SWITCH OUTPUT (TJ ALL A/T)
A	WT	FUSED IGNITION SWITCH OUTPUT (XJ 2.5L A/T)
B	OR/LG	TCC SOLENOID CONTROL (TJ ALL A/T)
B	OR/BK	TCC SOLENOID CONTROL (XJ 2.5L A/T)

FIG. 1

80b76f2b

TJ/XJ BODY WITH 3 SPD AUTO TRANS



CAV	COLOR	FUNCTION
B11	OR/LG	TCC SOLENOID CONTROL (TJ ALL A/T)
B11	OR/BK	TCC SOLENOID CONTROL (XJ 2.5L A/T)


CAV	COLOR	FUNCTION
A	RD/LG	FUSED IGNITION SWITCH OUTPUT (TJ ALL A/T)
A	WT	FUSED IGNITION SWITCH OUTPUT (XJ 2.5L A/T)
B	OR/LG	TCC SOLENOID CONTROL (TJ ALL A/T)
B	OR/BK	TCC SOLENOID CONTROL (XJ 2.5L A/T)

FIG. 2

80b6b1ca

TEST TC-12A REPAIRING TORQUE CONVERTER CLUTCH/TRANS RELAY CKT (TJ/XJ BODY WITH 3SPD AUTO TRANS)

Perform TEST DTC Before Proceeding



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

TEST TC-14A

REPAIRING - RADIATOR FAN RELAY CIRCUIT

Perform TEST DTC Before Proceeding

XJ BODY



80b6f0d3

XJ BODY

Name of Code: Rad Fan Control Relay Circuit**When monitored:** With the ignition key on and battery voltage greater than 10.4 volts.**Set condition:** An open or shorted condition is detected in the radiator fan relay control circuit.

Theory of operation: The radiator fan relay controls the operation of the radiator fan. The relay is located in the power distribution center. One side of the relay control coil is supplied with 12 volts when the ignition switch is turned to the "run" position. The circuit is completed when the other side of the relay coil is grounded by the powertrain control module (PCM). The PCM grounds the relay control circuit depending on coolant temperature. When the engine coolant temperature has reached the maximum temperature parameter, the relay will be grounded. Conversely, when the engine coolant temperature has acquired the minimum temperature parameter, the relay will remove the ground.

Possible causes:

- > Relay coil open or shorted
- > Fused ignition switch output circuit open
- > Low speed radiator fan relay control circuit open or shorted
- > PCM failure
- > Connector terminals
- > Connector wires


80aa4c32

FIG. 1

TEST TC-14A

REPAIRING - RADIATOR FAN RELAY CIRCUIT

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

XJ BODY

POWER DISTRIBUTION CENTER



RADIATOR FAN RELAY CONNECTOR



CAV	COLOR	FUNCTION
10 (30)	LG/RD	FUSED B(+)
11 (86)	WT	FUSED IGNITION SWITCH OUTPUT
13 (85)	DB/PK	RAD FAN RELAY CONTROL
14 (87)	LB	RAD FAN RELAY OUTPUT

FIG. 1

80b76e94

XJ BODY





FIG. 2

80b76e98

XJ BODY



POWERTRAIN CONTROL MODULE GREY CONNECTOR

CAV	COLOR	FUNCTION
C2	DB/PK	RAD FAN RELAY CONTROL

RADIATOR FAN RELAY CONNECTOR (IN PDC)

CAV	COLOR	FUNCTION
10 (30)	LG/RD	FUSED B(+)
11 (86)	WT	FUSED IGNITION SWITCH OUTPUT
13 (85)	DB/PK	RAD FAN RELAY CONTROL
14 (87)	LB	RAD FAN RELAY OUTPUT





FIG. 3

80b76e99



*Perform Verification TEST VER-2A.

**Check connectors - Clean / repair as necessary.

TEST TC-15A

REPAIRING - SPEED CONTROL CIRCUITS

Perform TEST DTC Before Proceeding

Name of code: Speed Control Solenoid Circuits

When monitored: Engine running, speed control switch on and battery voltage greater than 10.4 volts.

Set condition: The powertrain control module actuates the vacuum and vent solenoids but they do not respond.

Theory of operation: When the SET switch is pressed, the vehicle must be moving forward at a speed between 35-85 mph, with the transmission gear selector in other than park or neutral. The PCM locks in a set speed. Then the PCM energizes the vacuum solenoid to open the throttle and actuates the vent solenoid to close the throttle. These actuations are dependent on power supplied to the servo from the PCM or speed control relay through the brake switch. The system is deactivated by pressing the brake, turning the on/off switch off, or vehicle speed falling below the minimum. Reactivation can be done by repeating the previous steps or pressing resume with the vehicle speed between 35-85 mph.


Possible causes:

- > Solenoid control circuit open or shorted
- > Vacuum or vent solenoid shorted or open
- > Open or shorted speed control power supply circuit
- > PCM failure

80abff10

TJ/XJ BODY

SPEED CONTROL SERVO CONNECTOR




CAV	COLOR	FUNCTION
1	TN/RD	S/C VACUUM SOLENOID CONTROL
2	LG/RD	S/C VENT SOLENOID CONTROL
3	DB/RD	S/C BRAKE SWITCH OUTPUT
4	BK	GROUND

FIG. 1

80b0d705

TJ BODY

BRAKE LAMP SWITCH CONNECTOR




CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SWITCH SENSE
2	BK	GROUND
3	YL/RD	12-VOLT SUPPLY
4	DB/RD	S/C BRAKE SWITCH OUTPUT
5	PK/DB	FUSED B(+)
6	WT/TN	BRAKE LAMP SWITCH OUTPUT

80b099e1

FIG. 2

XJ BODY

BRAKE LAMP SWITCH CONNECTOR




CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SWITCH SENSE
2	BK	GROUND
3	YL/RD	12-VOLT SUPPLY
4	DB/RD	S/C BRAKE SWITCH OUTPUT
5	WT/TN	BRAKE LAMP SWITCH OUTPUT
6	PK/DB	FUSED B(+)

80b04fe6

FIG. 3


TJ BODY

POWERTRAIN CONTROL MODULE GREY CONNECTOR



CAV	COLOR	FUNCTION
C4	TN/RD	S/C VAC SOL CONTROL
C5	LG/RD	S/C VENT SOL CONTROL
C11	YL/RD	S/C POWER SUPPLY
C24	WT/PK	BRAKE SW SENSE

BRAKE LAMP SWITCH CONNECTOR




CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SW SENSE
2	BK	GROUND
3	YL/RD	S/C POWER SUPPLY
4	DB/RD	S/C BRAKE SW OUTPUT
5	PK/DB	FUSED B(+)
6	WT/TN	STOP LAMP SW OUTPUT

80b01d73

FIG. 4

XJ BODY

POWERTRAIN CONTROL MODULE CONNECTORS



CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
C4	TN/RD	S/C VACUUM SOLENOID CONTROL
C5	LG/RD	S/C VENT SOLENOID
C11	YL/RD	S/C POWER SUPPLY
C24	WT/PK	BRAKE SWITCH SENSE
C32	RD/LG	S/C SWITCH SIGNAL

BRAKE LAMP SWITCH CONNECTOR


CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SWITCH SENSE
2	BK	GROUND
3	YL/RD	S/C POWER SUPPLY
4	DB/RD	S/C BRAKE SWITCH OUTPUT
5	WT/TN	BRAKE LAMP SWITCH OUTPUT
6	PK/DB	FUSED B(+)

80ab5ce9

FIG. 5

TEST TC-15A REPAIRING - SPEED CONTROL CIRCUITS

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-4A.**

****Check connectors - Clean / repair as necessary.**

TJ BODY

BRAKE LAMP SWITCH CONNECTOR




CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SWITCH SENSE
2	BK	GROUND
3	YL/RD	12-VOLT SUPPLY
4	DB/RD	S/C BRAKE SWITCH OUTPUT
5	PK/DB	FUSED B(+)
6	WT/TN	BRAKE LAMP SWITCH OUTPUT

80b099e1

FIG. 1

XJ BODY

BRAKE LAMP SWITCH CONNECTOR




CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SWITCH SENSE
2	BK	GROUND
3	YL/RD	12-VOLT SUPPLY
4	DB/RD	S/C BRAKE SWITCH OUTPUT
5	WT/TN	BRAKE LAMP SWITCH OUTPUT
6	PK/DB	FUSED B(+)

80b04fe6

FIG. 2


TJ BODY

BRAKE LAMP SWITCH CONNECTOR



CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SWITCH SENSE
2	BK	GROUND
3	YL/RD	12-VOLT SUPPLY
4	DB/RD	S/C BRAKE SWITCH OUTPUT
5	PK/DB	FUSED B (+)
6	WT/TN	BRAKE LAMP SWITCH OUTPUT

SPEED CONTROL SERVO CONNECTOR




CAV	COLOR	FUNCTION
1	TN/RD	S/C VACUUM SOLENOID CONTROL
2	LG/RD	S/C VENT SOLENOID CONTROL
3	DB/RD	S/C BRAKE SWITCH OUTPUT
4	BK	GROUND

80b09a9f

FIG. 3


XJ BODY

BRAKE LAMP SWITCH CONNECTOR



CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SWITCH SENSE
2	BK	GROUND
3	YL/RD	12-VOLT SUPPLY
4	DB/RD	S/C BRAKE SWITCH OUTPUT
5	WT/TN	BRAKE LAMP SWITCH OUTPUT
6	PK/DB	FUSED B (+)

SPEED CONTROL SERVO CONNECTOR




CAV	COLOR	FUNCTION
1	TN/RD	S/C VACUUM SOLENOID CONTROL
2	LG/RD	S/C VENT SOLENOID CONTROL
3	DB/RD	S/C BRAKE SWITCH OUTPUT
4	BK	GROUND

80b0981c

FIG. 4

TEST TC-15A

CONTINUED - REPAIRING - SPEED CONTROL CIRCUITS



***Perform Verification TEST VER-4A.**

****Check connectors - Clean / repair as necessary.**


TEST TC-15B

REPAIRING - SPEED CONTROL CIRCUITS

Perform TEST TC-15A Before Proceeding

TJ/XJ BODY

SPEED CONTROL SERVO CONNECTOR




CAV	COLOR	FUNCTION
1	TN/RD	S/C VACUUM SOLENOID CONTROL
2	LG/RD	S/C VENT SOLENOID CONTROL
3	DB/RD	S/C BRAKE SWITCH OUTPUT
4	BK	GROUND

FIG. 1

80b0d705

TJ/XJ BODY

POWERTRAIN CONTROL MODULE CONNECTORS




CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
C4	TN/RD	S/C VACUUM SOL CONTROL
C5	LG/RD	S/C VENT SOL CONTROL
C11	YL/RD	12-VOLT SUPPLY
C24	WT/PK	BRAKE SWITCH SENSE
C32	RD/LG	S/C SWITCH SIGNAL

FIG. 2

80b6b1cb

TEST TC-15B REPAIRING - SPEED CONTROL CIRCUITS

Perform TEST TC-15A Before Proceeding




***Perform Verification TEST VER-4A.**

****Check connectors - Clean / repair as necessary.**


TJ/XJ BODY

BLACK



A4

C11 GREY



C32

C5

C4

C24

4

3

2

1

POWERTRAIN CONTROL MODULE CONNECTORS

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
C4	TN/RD	S/C VACUUM SOL CTRL
C5	LG/RD	S/C VENT SOL CONTROL
C11	YL/RD	12-VOLT SUPPLY
C24	WT/PK	BRAKE SWITCH SENSE
C32	RD/LG	S/C SWITCH SIGNAL

SPEED CONTROL SERVO CONNECTOR


CAV	COLOR	FUNCTION
1	TN/RD	S/C VACUUM SOL CTRL
2	LG/RD	S/C VENT SOLENOID CTRL
3	DB/RD	S/C BRAKE SW OUTPUT
4	BK	GROUND

80b04fe5

FIG. 1

TEST TC-15B

CONTINUED - REPAIRING - SPEED CONTROL CIRCUITS




***Perform Verification TEST VER-4A.**

****Check connectors - Clean / repair as necessary.**


TEST TC-16A

REPAIRING - A/C CLUTCH RELAY CIRCUIT

Perform TEST DTC Before Proceeding

TJ BODY

80b6f0d1

XJ BODY

80b0983e

Name of code: A/C Clutch Relay Circuit**When monitored:** With the ignition key in the run position and battery voltage above 10.4 volts.**Set condition:** An open or shorted condition is detected in the A/C clutch relay control circuit.

Theory of operation: The A/C compressor clutch relay controls the 12-volt source for the A/C clutch. The relay is located in the power distribution center. One side of the relay control coil is supplied with 12 volts when the ignition switch is turned to the run position. The circuit is completed when the other side of the relay coil is grounded by the powertrain control module (PCM). When A/C is requested, the PCM adjusts the idle speed to accommodate the A/C compressor load on the engine. The PCM grounds the relay control circuit after the PCM receives an A/C request and adjustment of the idle speed has been implemented.

Possible causes:

- > Relay coil open or shorted
- > Fused ignition switch output circuit open
- > Compressor clutch relay control circuit open or shorted
- > Inoperative circuit driver in powertrain control module


FIG. 1

80aa4c18

TEST TC-16A

REPAIRING - A/C CLUTCH RELAY CIRCUIT

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

TJ BODY

A/C CLUTCH RELAY CONNECTOR



CAV	COLOR	FUNCTION
6 (30)	RD/GY	FUSED B(+)
7 (87)	DB/BK	A/C CMP CLUTCH RELAY OUTPUT
8 (86)	VT/WT	FUSED IGNITION SWITCH OUTPUT
10 (85)	DB/OR	A/C CMP CLUTCH RELAY CONTROL



POWERTRAIN CONTROL MODULE GREY CONNECTOR


CAV	COLOR	FUNCTION
C1	DB/OR	A/C CMP CLUTCH RELAY CONTROL

FIG. 1


80b76e91

XJ BODY

A/C CLUTCH RELAY CONNECTOR (IN PDC)



CAV	COLOR	FUNCTION
1 (30)	RD/BK	FUSED B(+)
2 (87)	DB/BK	A/C CMP CLUTCH RELAY OUTPUT
3 (85)	DB/OR	A/C CMP CLUTCH RELAY CONTROL
5 (86)	DB/WT	FUSED IGNITION SWITCH OUTPUT



POWERTRAIN CONTROL MODULE GREY CONNECTOR

CAV	COLOR	FUNCTION
C1	DB/OR	A/C CMP CLUTCH RELAY CONTROL

FIG. 2

80b76e95





FIG. 3

80b76e97

TEST TC-16A

CONTINUED - REPAIRING - A/C CLUTCH RELAY CIRCUIT



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


TEST TC-18A

REPAIRING - EVAP PURGE SOLENOID CIRCUIT

Perform TEST DTC Before Proceeding

TJ BODY


POWERTRAIN CONTROL MODULE



80d09ab9

XJ BODY


POWERTRAIN CONTROL MODULE



80b6fd5

TJ BODY

EVAPORATIVE SOLENOID CONNECTOR




CAV	COLOR	FUNCTION
1	PK/BK	EVAP SOLENOID CONTROL
2	RD/LG	FUSED IGNITION SWITCH OUTPUT

80b6f0e2

FIG. 1

XJ BODY

EVAPORATIVE SOLENOID CONNECTOR



CAV	COLOR	FUNCTION
1	PK/BK	EVAP SOLENOID CONTROL
2	WT	FUSE IGNITION SWITCH OUTPUT


80b6f0da

FIG. 2

TJ BODY

EVAPORATIVE SOLENOID CONNECTOR

CAV	COLOR	FUNCTION
1	PK/BK	EVAP SOLENOID CONTROL
2	RD/LG	FUSED IGNITION SWITCH OUTPUT



CAV	COLOR	FUNCTION
C20	PK/BK	EVAP SOLENOID CONTROL


80b76e92

FIG. 3

XJ BODY

EVAPORATIVE SOLENOID CONNECTOR

CAV	COLOR	FUNCTION
1	PK/BK	EVAP SOLENOID CONTROL
2	WT	FUSED IGNITION SWITCH OUTPUT



CAV	COLOR	FUNCTION
C20	PK/BK	EVAP SOLENOID CONTROL


80b76e96

FIG. 4

TEST TC-18A


REPAIRING - EVAP PURGE SOLENOID CIRCUIT

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**



80b27d34

FIG. 1



*Perform Verification TEST VER-2A.

**Check connectors - Clean / repair as necessary.

Name of code: Evap Purge Solenoid Circuit

When monitored: At ignition key on and battery voltage greater than 10.4 volts.

Set condition: After the arming conditions are satisfied: not powering down, not already in limp-in, time since the last solenoid activation > 72 micro seconds. The powertrain control module will set a trouble code if the actual state of the solenoid does not match the intended state.


Theory of operation: Its purpose is to regulate, by means of a duty cycle, the flow of vapors from the evap canister to the throttle body. The PCM controls the time the solenoid is on during a duty cycle. During off idle operations (higher flows), higher percentages of duty cycle are used. At idle (lower flow), lower percentages of duty cycle are used.

Possible causes:

- > Open or shorted control circuit
- > Open fused ignition switch output circuit
- > Open or shorted solenoid control coil
- > Powertrain control module failure
- > Connector terminals
- > Connector wires


80aa0f82

FIG. 1



TEST TC-18A

CONTINUED - REPAIRING - EVAP PURGE SOLENOID CIRCUIT



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


TEST TC-19A

REPAIRING - INJECTOR #3 CONTROL CIRCUIT

Perform TEST TC-21A Before Proceeding

2.5L

INJECTOR #1 CONNECTOR




CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	WT/DB	INJECTOR #1 DRIVER

80b76e62

FIG. 1

4.0L

INJECTOR #1 CONNECTOR




CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	WT/DG	INJECTOR #1 DRIVER

80b76e67

FIG. 2


2.5L

INJECTOR #1 CONNECTOR



CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	WT/DB	INJECTOR #1 DRIVER

POWERTRAIN CONTROL MODULE CONNECTORS




CAV	COLOR	FUNCTION
B4	WT/DB	INJECTOR #1 DRIVER
C12	DG/PK	ASD RELAY OUTPUT (TJ)
C12	DG/OR	ASD RELAY OUTPUT (XJ)

80b76ea2

FIG. 3


4.0L

INJECTOR #1 CONNECTOR



CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	WT/DB	INJECTOR #1 DRIVER

POWERTRAIN CONTROL MODULE CONNECTORS



CAV	COLOR	FUNCTION
B4	WT/DB	INJECTOR #1 DRIVER
C12	DG/PK	ASD RELAY OUTPUT (TJ)
C12	DG/OR	ASD RELAY OUTPUT (XJ)


80b76ea6

FIG. 4

TEST TC-19A

REPAIRING - INJECTOR #3 CONTROL CIRCUIT

Perform TEST TC-21A Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


TEST TC-20A

REPAIRING - INJECTOR #2 CONTROL CIRCUIT

Perform TEST TC-21A Before Proceeding

2.5L

INJECTOR #2 CONNECTOR




CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	TN	INJECTOR #2 DRIVER

80b76e64

FIG. 1

4.0L

INJECTOR #2 CONNECTOR




CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	TN	INJECTOR #2 DRIVER

80b76e68

FIG. 2


2.5L

INJECTOR #2 CONNECTOR



CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	TN	INJECTOR #2 DRIVER

POWERTRAIN CONTROL MODULE CONNECTORS




CAV	COLOR	FUNCTION
B15	TN	INJECTOR #2 DRIVER
C12	DG/PK	ASD RELAY OUTPUT (TJ)
C12	DG/OR	ASD RELAY OUTPUT (XJ)

80b76ea3

FIG. 3


4.0L

INJECTOR #2 CONNECTOR



CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	TN	INJECTOR #2 DRIVER

POWERTRAIN CONTROL MODULE CONNECTORS



CAV	COLOR	FUNCTION
B15	TN	INJECTOR #2 DRIVER
C12	DG/PK	ASD RELAY OUTPUT (TJ)
C12	DG/OR	ASD RELAY OUTPUT (XJ)


80b76ea7

FIG. 4

TEST TC-20A

REPAIRING - INJECTOR #2 CONTROL CIRCUIT

Perform TEST TC-21A Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

Perform TEST DTC Before Proceeding

Name of code: Injector Control Circuit

When monitored: With battery voltage greater than 10.4 volts, the auto shutdown relay energized, injector pulse width less than 10ms, and engine speed less than 3000 rpm.

Set condition: This trouble code takes .64 to 10.0 seconds to set when no inductive kick is sensed. 18ms after injector turn off, and with no other injectors on.


Theory of operation: Fuel injectors are high-impedance solenoids controlled by the PCM. Battery voltage is supplied by the ASD relay. The injector on time (pulse width) is controlled by the amount of time the PCM grounds the injector control circuit. By varying this time, more or less fuel is allowed to flow through the injector.

Possible causes:

- > Open or shorted injector driver circuit
- > Open injector
- > Open ASD supply at injector
- > PCM failure
- > Connector terminals
- > Connector wires


80aa4c19

FIG. 1



TEST TC-21A **REPAIRING - INJECTOR CONTROL CIRCUITS**

Perform TEST DTC Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

T
R
O
U
B
L
E
C
O
D
E
T
E
S
T
S

TEST TC-21A

CONTINUED - REPAIRING - INJECTOR CONTROL CIRCUITS

NOTES

TEST TC-21A

CONTINUED - REPAIRING - INJECTOR CONTROL CIRCUITS

Refer to the chart below and perform the diagnostic test that corresponds to the trouble code displayed on the DRB.

TROUBLE CODE	DIAGNOSTIC TEST
INJECTOR #1 CONTROL CIRCUIT	TC-21B
INJECTOR #2 CONTROL CIRCUIT	TC-20A
INJECTOR #3 CONTROL CIRCUIT	TC-19A
INJECTOR #4 CONTROL CIRCUIT	TC-61A
INJECTOR #5 CONTROL CIRCUIT	TC-69A
INJECTOR #6 CONTROL CIRCUIT	TC-70A


TEST TC-21B

REPAIRING - INJECTOR #1 CONTROL CIRCUIT

Perform TEST TC-21A Before Proceeding

2.5L

INJECTOR #3 CONNECTOR




CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	YL/WT	INJECTOR #3 DRIVER

80b76e65

FIG. 1

4.0L

INJECTOR #3 CONNECTOR




CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	YL/WT	INJECTOR #3 DRIVER

80b76e69

FIG. 2


2.5L

INJECTOR #3 CONNECTOR



CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	YL/WT	INJECTOR #3 DRIVER

POWERTRAIN CONTROL MODULE CONNECTORS




CAV	COLOR	FUNCTION
B5	YL/WT	INJECTOR #3 DRIVER
C12	DG/PK	ASD RELAY OUTPUT (TJ)
C12	DG/OR	ASD RELAY OUTPUT (XJ)

80b76ea4

FIG. 3


4.0L

INJECTOR #3 CONNECTOR



CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	YL/WT	INJECTOR #3 DRIVER

POWERTRAIN CONTROL MODULE CONNECTORS




CAV	COLOR	FUNCTION
B5	YL/WT	INJECTOR #3 DRIVER
C12	DG/PK	ASD RELAY OUTPUT (TJ)
C12	DG/OR	ASD RELAY OUTPUT (XJ)

80b76ea8

FIG. 4

TEST TC-21B REPAIRING - INJECTOR #1 CONTROL CIRCUIT

Perform TEST TC-21A Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TEST TC-25A

REPAIRING - IDLE AIR CONTROL MOTOR CIRCUITS

Perform TEST DTC Before Proceeding

TJ/XJ BODY**POWERTRAIN
CONTROL
MODULE**

80b6f0d8

Name of code: Idle Air Control Motor Circuits**When monitored:** At key on and battery voltage greater than 11.5 volts.**Set condition:** The PCM senses a short to ground or battery voltage on any of the four IAC driver circuits for 2.75 seconds while the IAC motor is active.**Theory of operation:** The idle air control motor is used by the PCM to help regulate idle speed. The motor controls the amount of air allowed to bypass the throttle blade. The PCM controls the motor using four driver circuits to position the stepper motor.**Possible causes:**

- Driver circuit shorted to ground
- Driver circuit shorted to battery
- Driver circuits shorted together
- Failed PCM
- Shorted IAC motor
- Connector terminals
- Connector wires


80aa4ba1

FIG. 1

TEST TC-25A

REPAIRING - IDLE AIR CONTROL MOTOR CIRCUITS

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ/XJ BODY


IDLE AIR CONTROL MOTOR CONNECTOR




CAV	COLOR	FUNCTION
1	VT/BK	IDLE AIR CONTROL #1 DRIVER
2	BR/WT	IDLE AIR CONTROL #2 DRIVER
3	YL/BK	IDLE AIR CONTROL #3 DRIVER
4	GY/RD	IDLE AIR CONTROL #4 DRIVER

80b898b2

POWERTRAIN CONTROL MODULE



80b6f0d8




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ/XJ BODY


IDLE AIR CONTROL MOTOR CONNECTOR




CAV	COLOR	FUNCTION
1	VT/BK	IDLE AIR CONTROL #1 DRIVER
2	BR/WT	IDLE AIR CONTROL #2 DRIVER
3	YL/BK	IDLE AIR CONTROL #3 DRIVER
4	GY/RD	IDLE AIR CONTROL #4 DRIVER

80b898b2

POWERTRAIN CONTROL MODULE



80b6f0d8




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ/XJ BODY


IDLE AIR CONTROL MOTOR CONNECTOR




CAV	COLOR	FUNCTION
1	VT/BK	IDLE AIR CONTROL #1 DRIVER
2	BR/WT	IDLE AIR CONTROL #2 DRIVER
3	YL/BK	IDLE AIR CONTROL #3 DRIVER
4	GY/RD	IDLE AIR CONTROL #4 DRIVER

80b898b2

POWERTRAIN CONTROL MODULE



80b6f0d8



*Perform Verification TEST VER-2A.

**Check connectors - Clean / repair as necessary.


TEST TC-25B

REPAIRING - IDLE AIR CONTROL MOTOR CIRCUITS

Perform TEST TC-25A Before Proceeding


TJ/XJ BODY

POWERTRAIN CONTROL MODULE BLACK CONNECTOR



CAV	COLOR	FUNCTION
A10	YL/BK	IAC #3 DRIVER
A11	BR/WT	IAC #2 DRIVER
A19	GY/RD	IAC #4 DRIVER
A20	VT/BK	IAC #1 DRIVER

IDLE AIR CONTROL MOTOR CONNECTOR




CAV	COLOR	FUNCTION
1	VT/BK	IAC #1 DRIVER
2	BR/WT	IAC #2 DRIVER
3	YL/BK	IAC #3 DRIVER
4	GY/RD	IAC #4 DRIVER

FIG. 1

80b898b3

POWERTRAIN CONTROL MODULE




80b6f0d8

TEST TC-25B

REPAIRING - IDLE AIR CONTROL MOTOR CIRCUITS

Perform TEST TC-25A Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


TEST TC-25C

REPAIRING - IDLE AIR CONTROL MOTOR CIRCUITS

Perform TEST TC-25A Before Proceeding


TJ/XJ BODY

POWERTRAIN CONTROL MODULE BLACK CONNECTOR



CAV	COLOR	FUNCTION
A10	YL/BK	IAC #3 DRIVER
A11	BR/WT	IAC #2 DRIVER
A19	GY/RD	IAC #4 DRIVER
A20	VT/BK	IAC #1 DRIVER

IDLE AIR CONTROL MOTOR CONNECTOR




CAV	COLOR	FUNCTION
1	VT/BK	IAC #1 DRIVER
2	BR/WT	IAC #2 DRIVER
3	YL/BK	IAC #3 DRIVER
4	GY/RD	IAC #4 DRIVER

FIG. 1

80b898b3

POWERTRAIN CONTROL MODULE




80b6f0d8

TEST TC-25C

REPAIRING - IDLE AIR CONTROL MOTOR CIRCUITS

Perform TEST TC-25A Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


TEST TC-25D

REPAIRING - IDLE AIR CONTROL MOTOR CIRCUITS

Perform TEST TC-25A Before Proceeding


TJ/XJ BODY

POWERTRAIN CONTROL MODULE BLACK CONNECTOR



CAV	COLOR	FUNCTION
A10	YL/BK	IAC #3 DRIVER
A11	BR/WT	IAC #2 DRIVER
A19	GY/RD	IAC #4 DRIVER
A20	VT/BK	IAC #1 DRIVER

IDLE AIR CONTROL MOTOR CONNECTOR




CAV	COLOR	FUNCTION
1	VT/BK	IAC #1 DRIVER
2	BR/WT	IAC #2 DRIVER
3	YL/BK	IAC #3 DRIVER
4	GY/RD	IAC #4 DRIVER

FIG. 1

80b898b3

POWERTRAIN CONTROL MODULE




80b6f0d8

TEST TC-25D

REPAIRING - IDLE AIR CONTROL MOTOR CIRCUITS

Perform TEST TC-25A Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


TEST TC-25E

REPAIRING - IDLE AIR CONTROL MOTOR CIRCUITS

Perform TEST TC-25A Before Proceeding

TJ/XJ BODY

IDLE AIR CONTROL MOTOR CONNECTOR




CAV	COLOR	FUNCTION
1	VT/BK	IDLE AIR CONTROL #1 DRIVER
2	BR/WT	IDLE AIR CONTROL #2 DRIVER
3	YL/BK	IDLE AIR CONTROL #3 DRIVER
4	GY/RD	IDLE AIR CONTROL #4 DRIVER

FIG. 1

80b898b2

POWERTRAIN CONTROL MODULE




80b6f0d8

TEST TC-25E

REPAIRING - IDLE AIR CONTROL MOTOR CIRCUITS

Perform TEST TC-25A Before Proceeding



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

TEST TC-26A

REPAIRING - THROTTLE POSITION SENSOR VOLTAGE LOW

Perform TEST DTC Before Proceeding

TJ/XJ BODY



80b0d637

Name of code: Throttle Position Sensor Voltage Low

When monitored: With the ignition on, and battery voltage above 10.4 volts.

Set condition: TP sensor voltage at PCM .1 volt for 3.2 seconds.

Theory of operation: The throttle position sensor contains a potentiometer that is operated by the throttle blade shaft. As the throttle plate rotates, the TP sensor provides a variable 0 to 5-volt signal to PCM. The voltage is directly proportional to throttle angle. When the throttle plate is at rest, the voltage is low. When the throttle is fully open, the voltage is high. With this signal, the PCM can determine precise throttle position under all operating conditions. The TP sensor receives a 5-volt supply from PCM. The sensor ground is provided by PCM.

Possible causes:

- > Sensor signal circuit shorted to ground
- > Throttle position sensor failure
- > Loss of 5-volt supply


FIG. 1

80aa4b9b

TEST TC-26A

REPAIRING - THROTTLE POSITION SENSOR VOLTAGE LOW

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ/XJ BODY

**THROTTLE POSITION
SENSOR CONNECTOR**




CAV	COLOR	FUNCTION
1	BR/YL	SENSOR GROUND
2	OR/DB	TP SENSOR SIGNAL
3	OR	5-VOLT SUPPLY

80b6f0e7

FIG. 1

TEST TC-26A

CONTINUED - REPAIRING - THROTTLE POSITION SENSOR VOLTAGE LOW



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

TEST TC-27A

REPAIRING - THROTTLE POSITION SENSOR VOLTAGE HIGH

Perform TEST DTC Before Proceeding

TJ/XJ BODY



80b098a4

Name of code: Throttle Position Sensor Voltage High

When monitored: With the ignition on, and battery voltage above 10.4 volts.

Set condition: TP sensor voltage at PCM goes above 4.9 volts for 3.2 seconds.

Theory of operation: The throttle position sensor contains a potentiometer that is operated by the throttle blade shaft. As the throttle plate rotates, the TP sensor provides a variable 0 to 5-volt signal to PCM. The voltage is directly proportional to throttle angle. When the throttle plate is at rest, the voltage is low. When the throttle is fully open, the voltage is high. With this signal, the PCM can determine precise throttle position under all operating conditions. The TP sensor receives a 5-volt supply from PCM. The sensor ground is provided by PCM.

Possible causes:

- > Sensor signal circuit open
- > Throttle position sensor failure
- > Sensor ground circuit open


80aa4b9c

FIG. 1

TEST TC-27A

REPAIRING - THROTTLE POSITION SENSOR VOLTAGE HIGH

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ/XJ BODY

**THROTTLE POSITION
SENSOR CONNECTOR**




CAV	COLOR	FUNCTION
1	BR/YL	SENSOR GROUND
2	OR/DB	TP SENSOR SIGNAL
3	OR	5-VOLT SUPPLY

80b610e7

FIG. 1


TJ/XJ BODY

**POWERTRAIN
CONTROL MODULE
BLACK CONNECTOR**



CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A17	OR	5-VOLT SUPPLY
A23	OR/DB	THROTTLE POSITION SENSOR SIGNAL


**THROTTLE
POSITION SENSOR
CONNECTOR**



CAV	COLOR	FUNCTION
1	BR/YL	SENSOR GROUND
2	OR/DB	TP SENSOR SIGNAL
3	OR	5-VOLT SUPPLY

80b098a6

FIG. 2



*Perform Verification TEST VER-2A.


**Check connectors - Clean / repair as necessary.

TEST TC-30A

REPAIRING - ECT SENSOR VOLTAGE TOO LOW

Perform TEST DTC Before Proceeding

TJ/XJ BODY



80b0d638

Name of code: ECT Sensor Voltage Too High**When monitored:** With the ignition on and battery voltage greater than 10.4 volts.**Set condition:** The engine coolant temperature sensor circuit voltage at the PCM goes below .8 volt for more than 3 seconds.**Theory of operation:** The engine coolant temperature sensor is a negative temperature coefficient (NTC) thermistor-type sensor (resistance varies inversely with temperature). This means at cold temperatures its resistance is high so the voltage signal will be high. As coolant temperature increases, resistance decreases and the voltage will be low. This allows the sensor to provide an analog voltage signal (0 to 5-volt) to the PCM.**Possible causes:**

- > Sensor signal shorted to ground
- > Sensor internally shorted
- > PCM failure
- > Connector terminals
- > Connector wires


FIG. 1

80aa4c21

TEST TC-30A

REPAIRING - ECT SENSOR VOLTAGE TOO LOW

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ BODY

**ENGINE COOLANT
TEMPERATURE SENSOR
CONNECTOR**




CAV	COLOR	FUNCTION
1	TN/BK	ECT SENSOR SIGNAL
2	BR/YL	SENSOR GROUND

FIG. 1

80aff5a0

XJ BODY


**ENGINE COOLANT
TEMP SENSOR
CONNECTOR**



CAV	COLOR	FUNCTION
1	BR/YL	SENSOR GROUND
2	TN/BK	ECT SENSOR SIGNAL

FIG. 2

80b098a7



*Perform Verification TEST VER-2A.


**Check connectors - Clean / repair as necessary.

TEST TC-31A

REPAIRING - ECT SENSOR VOLTAGE TOO HIGH

Perform TEST DTC Before Proceeding

TJ/XJ BODY



80b0d638

Name of code: ECT Sensor Voltage Too High

When monitored: With the ignition on and battery voltage greater than 10.4 volts.

Set condition: The engine coolant temperature sensor circuit voltage at the PCM goes above 4.98 volts for more than 3 seconds.

Theory of operation: The engine coolant temperature sensor is a negative temperature coefficient (NTC) thermistor-type sensor (resistance varies inversely with temperature). This means at cold temperatures its resistance is high so the voltage signal will be high. As coolant temperature increases, resistance decreases and the voltage will be low. This allows the sensor to provide an analog voltage signal (0 to 5-volt) to the PCM.

Possible causes:

- > Sensor signal circuit open or shorted
- > Sensor internally open
- > Sensor ground circuit open
- > PCM failure
- > Connector terminals
- > Connector wires


FIG. 1

80b04fd9

TEST TC-31A

REPAIRING - ECT SENSOR VOLTAGE TOO HIGH

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ BODY

ENGINE COOLANT TEMPERATURE SENSOR CONNECTOR




CAV	COLOR	FUNCTION
1	TN/BK	ECT SENSOR SIGNAL
2	BR/YL	SENSOR GROUND

80aff5a0

FIG. 1

XJ BODY

ENGINE COOLANT TEMP SENSOR CONNECTOR




CAV	COLOR	FUNCTION
1	BR/YL	SENSOR GROUND
2	TN/BK	ECT SENSOR SIGNAL

80b098a7

FIG. 2


TJ BODY

POWERTRAIN CONTROL MODULE BLACK CONNECTOR



CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A16	TN/BK	ECT SENSOR SIGNAL

ENGINE COOLANT TEMPERATURE SENSOR CONNECTOR




CAV	COLOR	FUNCTION
1	TN/BK	ECT SENSOR SIGNAL
2	BR/YL	SENSOR GROUND

80afb69f

FIG. 3


XJ BODY

POWERTRAIN CONTROL MODULE BLACK CONNECTOR



CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A16	TN/BK	ECT SENSOR SIGNAL


ENGINE COOLANT TEMPERATURE SENSOR CONNECTOR



CAV	COLOR	FUNCTION
1	BR/YL	SENSOR GROUND
2	TN/BK	ECT SENSOR SIGNAL

80b0995a

FIG. 4



*Perform Verification TEST VER-2A.


**Check connectors - Clean / repair as necessary.

TEST TC-35A

REPAIRING - NO VEHICLE SPEED SENSOR SIGNAL

Perform TEST DTC Before Proceeding

TJ/XJ BODY

POWERTRAIN
CONTROL
MODULE

80b0d639

Name of Code: No Vehicle Speed Sensor Signal

When monitored: With engine temperature greater than 104°F, MAP approximately 350 torr, (or MAP vacuum 15 to 16"), and engine speed between 1400 and 3000 RPM.

Set condition: No signal from the vehicle speed sensor for more than 15 seconds on two (2) consecutive trips.

Theory of operation: The vehicle speed sensor is a hall-effect type sensor used to detect the vehicle speed. The PCM calculates the vehicle speed based on the VSS signal. The PCM supplies 5 volts to power up the sensor. Sensor ground is supplied by the PCM. The PCM also supplies a 5-volt pull-up voltage to the sensor. The VSS signal is created with the sensor alternates the 5-volt pull-up from high to low.

Possible causes:

- > VSS adapter misaligned or not seated properly
- > Open or shorted signal circuit
- > Speedometer pinion damaged
- > Open 5-volt supply circuit
- > Open sensor ground circuit
- > Failed vehicle speed sensor
- > Failed PCM


80a5573b

FIG. 1

TEST TC-35A


REPAIRING - NO VEHICLE SPEED SENSOR SIGNAL

Perform TEST DTC Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ/XJ BODY**VEHICLE
SPEED SENSOR
HARNESS
CONNECTOR**


CAV	COLOR	FUNCTION
1	VT/OR	5-VOLT SUPPLY
2	BR/YL	SENSOR GROUND
3	WT/OR	VEHICLE SPEED SENSOR SIGNAL

80b0d63c

FIG. 1

TEST TC-35A

CONTINUED - REPAIRING - NO VEHICLE SPEED SENSOR SIGNAL




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ/XJ BODY

VEHICLE SPEED SENSOR HARNESS CONNECTOR




CAV	COLOR	FUNCTION
1	VT/OR	5-VOLT SUPPLY
2	BR/YL	SENSOR GROUND
3	WT/OR	VEHICLE SPEED SENSOR SIGNAL

80b0d63c

FIG. 1


TJ/XJ BODY

VSS CIRCUIT CHECK



CAV	COLOR	FUNCTION
1	VT/OR	5-VOLT SUPPLY
2	BR/YL	SENSOR GROUND
3	WT/OR	VEHICLE SPEED SENSOR SIGNAL


POWERTRAIN CONTROL MODULE CONNECTORS



CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
B27	WT/OR	VEHICLE SPEED SENSOR SIGNAL
B31	VT/OR	5-VOLT SUPPLY

80b0d6de

FIG. 2



*Perform Verification TEST VER-2A.

**Check connectors - Clean / repair as necessary.


TEST TC-35B

REPAIRING - NO VEHICLE SPEED SENSOR SIGNAL

Perform TEST TC-35A Before Proceeding

TJ/XJ BODY

**VEHICLE
SPEED SENSOR
HARNESS
CONNECTOR**



CAV	COLOR	FUNCTION
1	VT/OR	5-VOLT SUPPLY
2	BR/YL	SENSOR GROUND
3	WT/OR	VEHICLE SPEED SENSOR SIGNAL


80b0d63c

FIG. 1

TEST TC-35B

REPAIRING - NO VEHICLE SPEED SENSOR SIGNAL

Perform TEST TC-35A Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


TEST TC-35C

REPAIRING - NO VEHICLE SPEED SENSOR SIGNAL

Perform TEST TC-35A Before Proceeding


TJ/XJ BODY

VSS CIRCUIT CHECK



CAV	COLOR	FUNCTION
1	VT/OR	5-VOLT SUPPLY
2	BR/YL	SENSOR GROUND
3	WT/OR	VEHICLE SPEED SENSOR SIGNAL

POWERTRAIN CONTROL MODULE CONNECTORS




CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
B27	WT/OR	VEHICLE SPEED SENSOR SIGNAL
B31	VT/OR	5-VOLT SUPPLY

80b0d6de

FIG. 1

TEST TC-35C **REPAIRING - NO VEHICLE SPEED SENSOR SIGNAL**

Perform TEST TC-35A Before Proceeding



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

TEST TC-36A

REPAIRING - MAP SENSOR VOLTAGE TOO LOW/NO 5 VOLTS TO MAP SENSOR

Perform TEST DTC Before Proceeding

TJ/XJ BODY



80a4d2e2

Name of code: MAP Sensor Voltage Too Low**When monitored:** With engine rpm above 416 but less than 3520 and the TP sensor voltage less than 1.13 volt and battery voltage greater than 10.4 volts.**Set condition:** The MAP sensor signal voltage is below .1 volt for 2.0 seconds with engine running.**Theory of operation:** This sensor measures manifold absolute pressure and ambient barometric pressure within the manifold. It provides a 0 to 5-volt signal to PCM. The MAP sensor puts out a low voltage signal (0.5 to 1.8 volts) at idle when the manifold vacuum is high, and a higher voltage signal (3.9 to 4.8 volts) at deep throttle when the manifold vacuum is low. The MAP receives a 5-volt supply from PCM; voltage may vary from 4.8 to 5.1 volts. The sensor ground is provided by PCM.**Possible causes:**

- > Signal circuit shorted to ground
- > Failed sensor
- > Failed PCM

FIG. 1

80aa0f80

Name of code: No 5 Volts to MAP Sensor**When monitored:** With the ignition off and battery voltage greater than 10.4 volts.**Set condition:** The MAP sensor signal voltage goes below 2.35 volts with key off for 5.0 seconds.**Theory of operation:** This sensor measures manifold absolute pressure and ambient barometric pressure within the manifold. It provides a 0 to 5-volt signal to PCM. The MAP sensor puts out a low voltage signal (0.5 to 1.8 volts) at idle when the manifold vacuum is high, and a higher voltage signal (3.9 to 4.8 volts) at deep throttle when the manifold vacuum is low. The MAP receives a 5-volt supply from PCM; voltage may vary from 4.8 to 5.1 volts. The sensor ground is provided by PCM.**Possible causes:**

- > Open 5-volt supply
- > MAP sensor failure


FIG. 2

80aa0f81

TEST TC-36A

REPAIRING - MAP SENSOR VOLTAGE TOO LOW/NO 5 VOLTS TO MAP SENSOR

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ/XJ BODY


MAP SENSOR CONNECTOR



CAV	COLOR	FUNCTION
3	OR	5-VOLT SUPPLY
2	DG/RD	MAP SENSOR SIGNAL
1	BR/YL	SENSOR GROUND

80afa155

FIG. 1




*Perform Verification TEST VER-2A.

**Check connectors - Clean / repair as necessary.

TJ/XJ BODY


MAP SENSOR CONNECTOR

CAV	COLOR	FUNCTION
3	OR	5-VOLT SUPPLY
2	DG/RD	MAP SENSOR SIGNAL
1	BR/YL	SENSOR GROUND




POWERTRAIN CONTROL MODULE BLACK CONNECTOR

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A17	OR	5-VOLT SUPPLY
A27	DG/RD	MAP SENSOR SIGNAL



80afa154

FIG. 1



*Perform Verification TEST VER-2A.


**Check connectors - Clean / repair as necessary.

TEST TC-37A

REPAIRING - MAP SENSOR VOLTAGE TOO HIGH

Perform TEST DTC Before Proceeding

TJ/XJ BODY



80a4d2e2

Name of code: Map Sensor Voltage Too High

When monitored: With engine rpm above 400 but less than 3520 and the TP sensor voltage less than 1.13 volt and battery voltage greater than 10.4 volts.

Set condition: The MAP sensor signal voltage is greater than 4.88 volts at start or with the engine running for 2.2 seconds.

Theory of operation: This sensor measures manifold absolute pressure and ambient barometric pressure within the manifold. It provides a 0 to 5-volt signal to PCM. The MAP sensor puts out a low voltage signal (0.5 to 1.8 volts) at idle when the manifold vacuum is high, and a higher voltage signal (3.9 to 4.8 volts) at deep throttle when the manifold vacuum is low. The MAP receives a 5-volt supply from PCM. Voltage may vary from 4.8 to 5.1 volts. The sensor ground is provided by PCM.

Possible causes:

- > Signal circuit open
- > Sensor open internally
- > Sensor ground circuit
- > Sensor signal circuit shorted to voltage
- > Failed PCM


FIG. 1

80aa0f83

TEST TC-37A


REPAIRING - MAP SENSOR VOLTAGE TOO HIGH

Perform TEST DTC Before Proceeding



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

TJ/XJ BODY**MAP SENSOR
CONNECTOR**

CAV	COLOR	FUNCTION
3	OR	5-VOLT SUPPLY
2	DG/RD	MAP SENSOR SIGNAL
1	BR/YL	SENSOR GROUND

80afa155

FIG. 1




*Perform Verification TEST VER-2A.

**Check connectors - Clean / repair as necessary.

TJ/XJ BODY


MAP SENSOR CONNECTOR

CAV	COLOR	FUNCTION
3	OR	5-VOLT SUPPLY
2	DG/RD	MAP SENSOR SIGNAL
1	BR/YL	SENSOR GROUND




POWERTRAIN CONTROL MODULE BLACK CONNECTOR

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A17	OR	5-VOLT SUPPLY
A27	DG/RD	MAP SENSOR SIGNAL



80afa154

FIG. 1



**Perform Verification TEST VER-2A.*


***Check connectors - Clean / repair as necessary.*

TEST TC-39A

REPAIRING - NO CHANGE IN MAP FROM START TO RUN

Perform TEST DTC Before Proceeding

TJ/XJ BODY



80a4d2e2

Name of code: No Change in MAP From Start to Run

When monitored: With engine rpm above 400 but less than 1500 and the throttle body at closed throttle.

Set condition: To small a difference is seen between barometric pressure at ignition on and manifold vacuum (engine running) for 1.72 seconds.

Theory of operation: This sensor measures manifold absolute pressure and ambient barometric pressure within the manifold. It provides a 0 to 5-volt signal to PCM cavity A27. The MAP sensor puts out a low voltage signal (0.5 to 1.8 volts) at idle when the manifold vacuum is high, and a higher voltage signal (3.9 to 4.8 volts) at deep throttle when the manifold vacuum is low. The MAP receives a 5-volt supply from PCM cavity A17 voltage may vary from 4.8 to 5.1 volts. The sensor ground is provided by PCM cavity A4.

Possible causes:

- > Restricted or leaking vacuum/pressure to MAP sensor
- > Ice in sensor or passage
- > Failed sensor
- > Failed PCM


3470403

FIG. 1

TEST TC-39A


REPAIRING - NO CHANGE IN MAP FROM START TO RUN

Perform TEST DTC Before Proceeding



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

TJ/XJ BODY**MAP SENSOR
CONNECTOR**

CAV	COLOR	FUNCTION
3	OR	5-VOLT SUPPLY
2	DG/RD	MAP SENSOR SIGNAL
1	BR/YL	SENSOR GROUND

80afa155

FIG. 1



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

TEST TC-40A

REPAIRING - NO CRANK REFERENCE SIGNAL AT PCM

Perform TEST DTC Before Proceeding

TJ/XJ BODY



80a4eff4

Name of code: No Crank Reference Signal at PCM

When monitored: During engine cranking.

Set condition: No signal from the crank position sensor is present during engine cranking, and at least 3 cam position signals have occurred.


Theory of operation: The crank position sensor is a hall effect-type sensor used to detect the crankshaft speed and position. The PCM supplies 5 volts and a ground to power up the sensor. The PCM also supplies a 5-volt pull up voltage. The sensor signal is created by the slots passing under the sensor. When a slot is under the sensor the signal is high (5.0V); when the metal between the slots is under the sensor, the signal is low (.03V).

Probable causes:

- Open or shorted 5-volt supply circuit
- Open sensor ground
- Open or shorted signal circuit
- Excessive clearance between the sensor and flywheel or crankshaft
- Damaged flywheel
- Failed sensor
- Failed PCM
- Shorted VSS 5-volt supply circuit

80aa4bdf

CRANKSHAFT POSITION SENSOR CONNECTOR



CAV	COLOR	FUNCTION
1	GY/BK	CRANKSHAFT POSITION SENSOR SIGNAL
2	BR/YL	SENSOR GROUND
3	OR	5-VOLT SUPPLY


FIG. 1

80b0995b

TEST TC-40A

REPAIRING - NO CRANK REFERENCE SIGNAL AT PCM

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ/XJ BODY

CRANKSHAFT POSITION SENSOR CONNECTOR




CAV	COLOR	FUNCTION
1	GY/BK	CRANKSHAFT POSITION SENSOR SIGNAL
2	BR/YL	SENSOR GROUND
3	OR	5-VOLT SUPPLY

FIG. 1

80b0995b


TJ/XJ BODY

CRANKSHAFT POSITION SENSOR CONNECTOR



CAV	COLOR	FUNCTION
1	GY/BK	CRANKSHAFT POSITION SENSOR SIGNAL
2	BR/YL	SENSOR GROUND
3	OR	5-VOLT SUPPLY


POWERTRAIN CONTROL MODULE BLACK CONNECTOR



CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A8	GY/BK	CRANKSHAFT POSITION SENSOR SIGNAL
A17	OR	5-VOLT SUPPLY

FIG. 2

80b0d6e0



*Perform Verification TEST VER-2A.


**Check connectors - Clean / repair as necessary.

TEST TC-40B

REPAIRING - NO CRANK REFERENCE SIGNAL AT PCM

Perform TEST TC-40A Before Proceeding

TJ/XJ BODY



TJ/XJ BODY

Name of code: No Crank Reference Signal at PCM**When monitored:** During engine cranking.**Set condition:** No signal from the crank position sensor is present during engine cranking, and at least 3 cam position signals have occurred.**Theory of operation:** The crank position sensor is a hall effect-type sensor used to detect the crankshaft speed and position. The PCM supplies 5 volts and a ground to power up the sensor. The PCM also supplies a 5-volt pull up voltage. The sensor signal is created by the slots passing under the sensor. When a slot is under the sensor the signal is high (5.0V); when the metal between the slots is under the sensor, the signal is low (.03V).**Probable causes:**


- Open or shorted 5-volt supply circuit
- Open sensor ground
- Open or shorted signal circuit
- Excessive clearance between the sensor and flywheel or crankshaft
- Damaged flywheel
- Failed sensor
- Failed PCM
- Shorted VSS 5-volt supply circuit

80aa4bdf

FIG. 1

TEST TC-40B **REPAIRING - NO CRANK REFERENCE SIGNAL AT PCM**

Perform TEST TC-40A Before Proceeding



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

TEST TC-43A

REPAIRING - IGNITION COIL #1 PRIMARY CIRCUIT


Perform TEST DTC Before Proceeding

TJ BODY




80b6f0cf

XJ BODY



80b0995c



80a2432e

FIG. 1

Name of code: Ignition Coil Primary Circuit

When monitored: With battery voltage greater than 8 volts during engine cranking or greater than 12 volts with engine running, and with engine rpm less than 2016, and none of the coils in dwell when checked.

Set condition: Peak current is not achieved with battery based dwell plus 1.5 msec of diagnostic offset. It takes less than 3 seconds during cranking or up to 6 seconds while running to set.

Theory of operation: The ignition coil is supplied 12 volts from ASD relay. The PCM controls the individual primary circuits, which fires the individual coils. The amount of dwell time is based on crankshaft speed and camshaft position.

Possible causes:

- > Open or shorted ignition coil driver circuit
- > Open ignition coil primary
- > Open ASD output circuit
- > Failed PCM


3470203

FIG. 2

TEST TC-43A

REPAIRING - IGNITION COIL #1 PRIMARY CIRCUIT

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ BODY

IGNITION COIL CONNECTOR




CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT
2	GY	IGNITION COIL DRIVER

80b610e3

FIG. 1

XJ BODY




CAV	COLOR	FUNCTION
1	DG/OR	ASD RELAY OUTPUT
2	GY	IGNITION COIL DRIVER

80afb391

NOTE: WIRES CAN BE IN EITHER CAVITY
FIG. 2


TJ BODY

POWERTRAIN CONTROL MODULE BLACK CONNECTOR



CAV	COLOR	FUNCTION
A7	GY	IGNITION COIL DRIVER

IGNITION COIL CONNECTOR




CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT
2	GY	IGNITION COIL DRIVER

80b76ec0

FIG. 3


XJ BODY

POWERTRAIN CONTROL MODULE BLACK CONNECTOR



CAV	COLOR	FUNCTION
A7	GY	IGNITION COIL DRIVER

IGNITION COIL CONNECTOR




CAV	COLOR	FUNCTION
1	DG/OR	ASD RELAY OUTPUT
2	GY	IGNITION COIL DRIVER

80c098be

FIG. 4


IGNITION COIL



TYPICAL VIEW

FIG. 5

80b46afc




*Perform Verification TEST VER-2A.

**Check connectors - Clean / repair as necessary.


TEST TC-44A

REPAIRING - NO ASD RELAY OUTPUT VOLTAGE AT PCM

Perform TEST DTC Before Proceeding

TJ BODY

80b6f0d0

XJ BODY

80b04fe0

Name of code: Auto Shutdown Relay Control Circuit**When monitored:** With ignition key on and battery voltage greater than 10.4 volts.

Theory of operation: The Automatic Shutdown Relay (ASD) controls the 12-volt source to the fuel injectors, ignition coil(s), and the oxygen heaters sensor. The relay is located in the Power Distribution Center (PDC). One side of the relay control coil is supplied with battery voltage when the ignition switch is in the start or run position. The circuit is completed when the other side of the relay coil is grounded by the Powertrain Control Module (PCM). The PCM grounds the control circuit when the ignition switch is in the start or run position and engine RPM is detected. If engine RPM is not detected, the PCM will remove the ASD relay control circuit ground.

Possible causes:

- > Relay coil open or shorted.
- > Fused ignition switch output circuit open.
- > Auto shutdown relay control circuit open or shorted.
- > Inoperative circuit driver in PCM (PCM Failure)
- > Connector terminals


80afb5d2

FIG. 1

TEST TC-44A

REPAIRING - NO ASD RELAY OUTPUT VOLTAGE AT PCM

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


TJ BODY

**AUTO SHUTDOWN RELAY CONNECTOR
(IN PDC)**

CAV	COLOR	FUNCTION
1 (30)	RD/WT	FUSED B+
2 (87)	DG/PK	AUTO SHUTDOWN RELAY OUTPUT
3 (86)	DB	IGNITION SWITCH OUTPUT
5 (85)	DB/YL	AUTO SHUTDOWN RELAY CONTROL



**POWERTRAIN
CONTROL MODULE
GREY CONNECTOR**



CAV	COLOR	FUNCTION
C3	DB/YL	AUTO SHUTDOWN RELAY CONTROL
C12	DG/PK	AUTO SHUTDOWN RELAY OUTPUT


80b76e90

FIG. 1


XJ BODY

**AUTO SHUTDOWN RELAY CONNECTOR
(IN PDC)**

CAV	COLOR	FUNCTION
2 (30)	RD/LG	FUSED B(+)
4 (85)	DB/WT	FUSED IGNITION SWITCH OUTPUT
6 (86)	DB/YL	ASD RELAY CONTROL
8 (87)	RD	ASD RELAY OUTPUT




**POWERTRAIN
CONTROL MODULE
GREY CONNECTOR**



CAV	COLOR	FUNCTION
C3	DB/YL	AUTO SHUTDOWN RELAY CONTROL
C12	DG/OR	AUTO SHUTDOWN RELAY OUTPUT

80b76e93

FIG. 2



*Perform Verification TEST VER-2A.

**Check connectors - Clean / repair as necessary.

**T
R
O
U
B
L
E
C
O
D
E
T
E
S
T
S**

TEST TC-49A

REPAIRING - PCM FAILURE EEPROM WRITE DENIED


Perform TEST DTC Before Proceeding

NOTES

TEST TC-49A

REPAIRING - PCM FAILURE EEPROM WRITE DENIED

Perform TEST DTC Before Proceeding



**Perform Verification TEST VER-2A.*

***Check connectors - Clean / repair as necessary.*

TEST TC-57A

REPAIRING - INTAKE AIR TEMP SENSOR VOLTAGE LOW

Perform TEST DTC Before Proceeding

Name of code: Intake Air Temp Sensor Voltage Low

When monitored: With the ignition on and battery voltage greater than 10.4 volts.

Set condition: The intake air sensor circuit voltage at the PCM goes below .08 volt.

Theory of operation: The intake air temperature sensor (IAT) is located in the intake manifold where it measures the temperature of the air that is about to enter the combustion chambers. The IAT is a negative temperature coefficient (NTC) thermistor-type sensor (resistance varies inversely with temperature). This means at cold temperatures its resistance is high so the voltage signal will be high. At high temperatures, resistance decreases and the voltage signal will decrease. This allows the sensor to provide an analog voltage signal to the PCM. The PCM uses this signal to compensate for changes in air density due to temperature.


Possible causes:

- > Sensor signal circuit shorted to ground
- > Sensor internally shorted
- > Powertrain control module failure
- > Connector terminals
- > Connector wires

FIG. 1

80aa0f76

TJ/XJ BODY




80b118a4

TEST TC-57A

REPAIRING - INTAKE AIR TEMP SENSOR VOLTAGE LOW

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ BODY

**INTAKE AIR
TEMPERATURE SENSOR
CONNECTOR**




CAV	COLOR	FUNCTION
1	BK/RD	IAT SIGNAL
2	BR/YL	SENSOR GROUND

80b6f0e4

FIG. 1

XJ BODY


INTAKE AIR TEMPERATURE SENSOR CONNECTOR



CAV	COLOR	FUNCTION
1	BR/YL	SENSOR GROUND
2	BK/RD	IAT SIGNAL

80b099c6

FIG. 2



*Perform Verification TEST VER-2A.

**Check connectors - Clean / repair as necessary.

TEST TC-58A

REPAIRING - INTAKE AIR TEMP SENSOR VOLTAGE HIGH

Perform TEST DTC Before Proceeding

Name of code: Intake Air Temp Sensor Voltage High

When monitored: With the ignition on and battery voltage greater than 10.4 volts.

Set condition: The intake air sensor circuit voltage at the PCM goes above 4.9 volts.

Theory of operation: The intake air temperature sensor (IAT) is located in the intake manifold where it measures the temperature of the air that is about to enter the combustion chambers. The IAT is a negative temperature coefficient (NTC) thermistor-type sensor (resistance varies inversely with temperature). This means at cold temperatures its resistance is high so the voltage signal will be high. At high temperatures, resistance decreases and the voltage signal will decrease. This allows the sensor to provide an analog voltage signal to the PCM. The PCM uses this signal to compensate for changes in air density due to temperature.


Possible causes:

- > Sensor signal circuit open or shorted
- > Sensor internally open
- > Sensor ground circuit open
- > PCM failure
- > Connector terminals
- > Connector wires

FIG. 1

80b04fda

TJ/XJ BODY




80b118a4

TEST TC-58A

REPAIRING - INTAKE AIR TEMP SENSOR VOLTAGE HIGH

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ BODY

INTAKE AIR TEMPERATURE SENSOR CONNECTOR




CAV	COLOR	FUNCTION
1	BK/RD	IAT SIGNAL
2	BR/YL	SENSOR GROUND

80b6f0e4

FIG. 1

XJ BODY

INTAKE AIR TEMPERATURE SENSOR CONNECTOR




CAV	COLOR	FUNCTION
1	BR/YL	SENSOR GROUND
2	BK/RD	IAT SIGNAL

80b099c6

FIG. 2


TJ BODY

INTAKE AIR TEMPERATURE SENSOR CONNECTOR



CAV	COLOR	FUNCTION
1	BK/RD	IAT SIGNAL
2	BR/YL	SENSOR GROUND

POWERTRAIN CONTROL MODULE BLACK CONNECTOR




CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A15	BK/RD	IAT SIGNAL

80b118a3

FIG. 3


XJ BODY

INTAKE AIR TEMPERATURE SENSOR CONNECTOR



CAV	COLOR	FUNCTION
1	BR/YL	SENSOR GROUND
2	BK/RD	IAT SIGNAL


POWERTRAIN CONTROL MODULE BLACK CONNECTOR



CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A15	BK/RD	IAT SIGNAL

80b76ec2

FIG. 4



*Perform Verification TEST VER-2A.

**Check connectors - Clean / repair as necessary.


TEST TC-61A

REPAIRING - INJECTOR #4 CONTROL CIRCUIT

Perform TEST TC-21A Before Proceeding

2.5L

INJECTOR #4 CONNECTOR




CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	LB/BR	INJECTOR #4 DRIVER

80b76e66

FIG. 1

4.0L

INJECTOR #4 CONNECTOR




CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	LB/BR	INJECTOR #4 DRIVER

80b76e6a

FIG. 2


2.5L

INJECTOR #4 CONNECTOR



CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	LB/BR	INJECTOR #4 DRIVER

POWERTRAIN CONTROL MODULE CONNECTORS




CAV	COLOR	FUNCTION
B16	LB/BR	INJECTOR #4 DRIVER
C12	DG/PK	ASD RELAY OUTPUT (TJ)
C12	DG/OR	ASD RELAY OUTPUT (XJ)

80b76ea5

FIG. 3


4.0L

INJECTOR #4 CONNECTOR



CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	LB/BR	INJECTOR #4 DRIVER

POWERTRAIN CONTROL MODULE CONNECTORS



CAV	COLOR	FUNCTION
B16	LB/BR	INJECTOR #4 DRIVER
C12	DG/PK	ASD RELAY OUTPUT (TJ)
C12	DG/OR	ASD RELAY OUTPUT (XJ)


80b76ea9

FIG. 4

TEST TC-61A

REPAIRING - INJECTOR #4 CONTROL CIRCUIT

Perform TEST TC-21A Before Proceeding



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

TEST TC-62A


REPAIRING - 1/1 O2 SENSOR SHORTED TO VOLTAGE

Perform TEST DTC Before Proceeding

TJ BODY



XJ BODY



JTEC O2 SENSOR CONFIGURATION

TJ2.5L	1/1	UPSTREAM	XJ2.5L	1/1	UPSTREAM
TJ2.5L	1/2	DOWNSTREAM	XJ2.5L	1/2	DOWNSTREAM
TJ4.0L	1/1	UPSTREAM	XJ4.0L	1/1	UPSTREAM
TJ4.0L	1/2	DOWNSTREAM	XJ4.0L	1/2	DOWNSTREAM

80b76ec3

Name of code: O2 Sensor Shorted To Voltage

When monitored: With the engine running for more than 2 minutes and coolant temperature above 170°F.

Set condition: The oxygen sensor voltage is above 1.2 volts.

Theory of operation: Effective control of exhaust emissions is achieved by an oxygen feedback system. The oxygen sensor (O2S), which is located in the exhaust path, monitors the exhaust emissions. Once the sensor reaches its normal operating temperature of 300°-350°C (572°-662°F), it generates a voltage inversely proportional to the amount of oxygen in the exhaust.

Possible causes:

- > Sensor output wire shorted to a power circuit
- > O2 sensor failure
- > Powertrain control module failure
- > Connector terminals
- > Connector wires
- > Open O2 sensor signal circuit


80b01cfe

FIG. 1

TEST TC-62A

REPAIRING - 1/1 O2 SENSOR SHORTED TO VOLTAGE

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ BODY

**UPSTREAM
OXYGEN SENSOR
CONNECTOR
(HARNES SIDE)**




CAV	COLOR	FUNCTION
1	OR/DG	ASD Relay Output
2	BK	Ground (Heater)
3	BR/YL	Sensor Ground
4	BK/DG	Oxygen Sensor Signal

80b6f0e5

FIG. 1

XJ BODY


**UPSTREAM
OXYGEN SENSOR
CONNECTOR
(HARNES SIDE)**



CAV	COLOR	FUNCTION
1	DG/WT	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	BK/DG	OXYGEN SENSOR SIGNAL

80b6f0db

FIG. 2




*Perform Verification TEST VER-2A.



**Check connectors - Clean / repair as necessary.

TJ BODY

BLACK



GREY



80b76ec5

POWERTRAIN CONTROL MODULE CONNECTORS

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A24	BK/DG	UPSTREAM OXYGEN SENSOR SIGNAL
C12	DG/PK	ASD RELAY OUTPUT


UPSTREAM OXYGEN SENSOR CONNECTOR (HARNES SIDE)

CAV	COLOR	FUNCTION
1	OR/DG	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	BK/DG	OXYGEN SENSOR SIGNAL



FIG. 1

XJ BODY

BLACK



GREY



80b76ec4

POWERTRAIN CONTROL MODULE CONNECTORS

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A24	BK/DG	UPSTREAM OXYGEN SENSOR SIGNAL
C12	DG/OR	ASD RELAY OUTPUT


UPSTREAM OXYGEN SENSOR CONNECTOR (HARNES SIDE)

CAV	COLOR	FUNCTION
1	DG/WT	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	BK/DG	OXYGEN SENSOR SIGNAL

FIG. 2

TEST TC-62A

CONTINUED - REPAIRING - 1/1 O2 SENSOR SHORTED TO VOLTAGE




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

Perform TEST TC-21A Before Proceeding

4.0L

INJECTOR #5 CONNECTOR




CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	PK/BK	INJECTOR #5 DRIVER

80b76e6b

FIG. 1

4.0L


INJECTOR #5 CONNECTOR




CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	PK/BK	INJECTOR #5 DRIVER

POWERTRAIN CONTROL MODULE CONNECTORS

WHITE



GREY



CAV	COLOR	FUNCTION
B6	PK/BK	INJECTOR #5 DRIVER
C12	DG/PK	ASD RELAY OUTPUT (TJ)
C12	DG/OR	ASD RELAY OUTPUT (XJ)


80b76eaa

FIG. 2

TEST TC-69A

REPAIRING - INJECTOR #5 CONTROL CIRCUIT

Perform TEST TC-21A Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


TEST TC-70A

REPAIRING - INJECTOR #6 CONTROL CIRCUIT

Perform TEST TC-21A Before Proceeding

4.0L

INJECTOR #6 CONNECTOR




CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	LG/BK	INJECTOR #6 DRIVER

80b76e6c

FIG. 1

4.0L


INJECTOR #6 CONNECTOR




CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT (TJ)
1	DG/OR	ASD RELAY OUTPUT (XJ)
2	LG/BK	INJECTOR #6 DRIVER

POWERTRAIN CONTROL MODULE CONNECTORS

WHITE



GREY



CAV	COLOR	FUNCTION
B12	LG/BK	INJECTOR #6 DRIVER
C12	DG/PK	ASD RELAY OUTPUT (TJ)
C12	DG/OR	ASD RELAY OUTPUT (XJ)


80b76eab

FIG. 2

TEST TC-70A

REPAIRING - INJECTOR #6 CONTROL CIRCUIT

Perform TEST TC-21A Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TEST TC-82A

REPAIRING - SPEED CONTROL POWER RELAY OR SPEED CONTROL 12V DRIVER CIRCUIT

Perform TEST DTC Before Proceeding

Name of code: Speed Control Power Relay Circuit

When monitored: With the ignition key on, speed control switched on.

Set condition: The speed control power supply circuit is either open or shorted to ground.

Theory of operation: The PCM monitors the voltage drop across all speed control solenoids and the power supply circuit.


Possible causes:

- > Open and shorted power supply circuit
- > Failed dump solenoid (S/C servo)

80aa0165

TJ/XJ BODY

SPEED CONTROL SERVO CONNECTOR




CAV	COLOR	FUNCTION
1	TN/RD	S/C VACUUM SOLENOID CONTROL
2	LG/RD	S/C VENT SOLENOID CONTROL
3	DB/RD	S/C BRAKE SWITCH OUTPUT
4	BK	GROUND

FIG. 1

80b04fe4

TJ BODY

BRAKE LAMP SWITCH CONNECTOR




CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SWITCH SENSE
2	BK	GROUND
3	YL/RD	12-VOLT SUPPLY
4	DB/RD	S/C BRAKE SWITCH OUTPUT
5	PK/DB	FUSED B(+)
6	WT/TN	BRAKE LAMP SWITCH OUTPUT

80b099e1

FIG. 2

XJ BODY

BRAKE LAMP SWITCH CONNECTOR




CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SWITCH SENSE
2	BK	GROUND
3	YL/RD	12-VOLT SUPPLY
4	DB/RD	S/C BRAKE SWITCH OUTPUT
5	WT/TN	BRAKE LAMP SWITCH OUTPUT
6	PK/DB	FUSED B(+)

80b04fe6

FIG. 3


TJ BODY

POWERTRAIN CONTROL MODULE GREY CONNECTOR



CAV	COLOR	FUNCTION
C4	TN/RD	S/C VAC SOL CONTROL
C5	LG/RD	S/C VENT SOL CONTROL
C11	YL/RD	12-VOLT SUPPLY
C24	WT/PK	BRAKE SW SENSE

BRAKE LAMP SWITCH CONNECTOR




CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SW SENSE
2	BK	GROUND
3	YL/RD	12-VOLT SUPPLY
4	DB/RD	S/C BRAKE SW OUTPUT
5	PK/DB	FUSED B(+)
6	WT/TN	STOP LAMP SW OUTPUT

80b6b1cc

FIG. 4

XJ BODY

BLACK POWERTRAIN CONTROL MODULE CONNECTORS



CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
C4	TN/RD	S/C VACUUM SOLENOID CONTROL
C5	LG/RD	S/C VENT SOLENOID
C11	YL/RD	S/C POWER SUPPLY
C24	WT/PK	BRAKE SWITCH SENSE
C32	RD/LG	S/C SWITCH SIGNAL

BRAKE LAMP SWITCH CONNECTOR

CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SWITCH SENSE
2	BK	GROUND
3	YL/RD	S/C POWER SUPPLY
4	DB/RD	S/C BRAKE SWITCH OUTPUT
5	WT/TN	BRAKE LAMP SWITCH OUTPUT
6	PK/DB	FUSED B(+)


80ab5ce9

FIG. 5

TEST TC-82A


REPAIRING - SPEED CONTROL POWER RELAY OR SPEED CONTROL 12V DRIVER CIRCUIT

Perform TEST DTC Before Proceeding



***Perform Verification TEST VER-4A.**

****Check connectors - Clean / repair as necessary.**



80b099e0

Name of code: Speed Control Power Relay Circuit

When monitored: With the ignition key on, speed control switched on.

Set condition: The speed control power supply circuit is either open or shorted to ground.


Theory of operation: The PCM monitors the voltage drop across all speed control solenoids and the power supply circuit.

Possible causes:

- > Open and shorted power supply circuit
- > Failed dump solenoid (S/C servo)

80aa0f65

TJ/XJ BODY




CAV	COLOR	FUNCTION
1	TN/RD	S/C VACUUM SOLENOID CONTROL
2	LG/RD	S/C VENT SOLENOID CONTROL
3	DB/RD	S/C BRAKE SWITCH OUTPUT
4	BK	GROUND

80b04fe4

FIG. 1


TJ/XJ BODY



CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
C4	TN/RD	S/C VACUUM SOL CONTROL
C5	LG/RD	S/C VENT SOL CONTROL
C11	YL/RD	12-VOLT SUPPLY
C24	WT/PK	BRAKE SWITCH SENSE
C32	RD/LG	S/C SWITCH SIGNAL

80b651cb

FIG. 2




*Perform Verification TEST VER-4A.

**Check connectors - Clean / repair as necessary.


TJ/XJ BODY

BLACK



A4

C11 GREY



C32

C5

C4

C24

4

3

2

1

POWERTRAIN CONTROL MODULE CONNECTORS

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
C4	TN/RD	S/C VACUUM SOL CTRL
C5	LG/RD	S/C VENT SOL CONTROL
C11	YL/RD	12-VOLT SUPPLY
C24	WT/PK	BRAKE SWITCH SENSE
C32	RD/LG	S/C SWITCH SIGNAL


SPEED CONTROL SERVO CONNECTOR

CAV	COLOR	FUNCTION
1	TN/RD	S/C VACUUM SOL CTRL
2	LG/RD	S/C VENT SOLENOID CTRL
3	DB/RD	S/C BRAKE SW OUTPUT
4	BK	GROUND

80b04fe5

FIG. 1

TEST TC-82A CONTINUED - REPAIRING - SPEED CONTROL POWER RELAY OR SPEED CONTROL 12V DRIVER CIRCUIT



***Perform Verification TEST VER-4A.**

****Check connectors - Clean / repair as necessary.**

TEST TC-82B


REPAIRING - SPEED CONTROL POWER RELAY OR SPEED CONTROL 12V DRIVER CIRCUIT

Perform TEST TC-82A Before Proceeding

TJ BODY

BRAKE LAMP SWITCH CONNECTOR

CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SWITCH SENSE
2	BK	GROUND
3	YL/RD	12-VOLT SUPPLY
4	DB/RD	S/C BRAKE SWITCH OUTPUT
5	PK/DB	FUSED B (+)
6	WT/TN	BRAKE LAMP SWITCH OUTPUT



SPEED CONTROL SERVO CONNECTOR

CAV	COLOR	FUNCTION
1	TN/RD	S/C VACUUM SOLENOID CONTROL
2	LG/RD	S/C VENT SOLENOID CONTROL
3	DB/RD	S/C BRAKE SWITCH OUTPUT
4	BK	GROUND





FIG. 1

80b09a9f

XJ BODY

BRAKE LAMP SWITCH CONNECTOR

CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SWITCH SENSE
2	BK	GROUND
3	YL/RD	12-VOLT SUPPLY
4	DB/RD	S/C BRAKE SWITCH OUTPUT
5	WT/TN	BRAKE LAMP SWITCH OUTPUT
6	PK/DB	FUSED B (+)



SPEED CONTROL SERVO CONNECTOR

CAV	COLOR	FUNCTION
1	TN/RD	S/C VACUUM SOLENOID CONTROL
2	LG/RD	S/C VENT SOLENOID CONTROL
3	DB/RD	S/C BRAKE SWITCH OUTPUT
4	BK	GROUND





FIG. 2

80b0981c

TEST TC-82B

REPAIRING - SPEED CONTROL POWER RELAY OR SPEED CONTROL 12V DRIVER CIRCUIT

Perform TEST TC-82A Before Proceeding



**Perform Verification TEST VER-4A.*

***Check connectors - Clean / repair as necessary.*

TEST TC-86A

REPAIRING - SPEED CONTROL SWITCH ALWAYS HIGH

Perform TEST DTC Before Proceeding

Name of Code: Speed Control Switch Always High

When monitored: With the ignition key on.


Set condition: An open condition is detected in the speed control on/off switch circuit.

Theory of operation: This circuit is monitored continuously by the PCM whenever the ignition is turned on. The trouble code sets if the voltage in this circuit is above 4.7 volts for more than 1 second.

Possible causes:


- > Mux switch circuit shorted to power
- > Mux switch circuit open
- > Open on/off switch
- > PCM failure

805005a6



80b099e0


SPEED CONTROL SWITCH CONNECTOR



CAV	COLOR	FUNCTION
1	BR/YL	GROUND
2	RD/LG	SPEED CONTROL SIGNAL


80ab3724

FIG. 1



POWERTRAIN CONTROL MODULE CONNECTORS

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
C4	TN/RD	S/C VACUUM SOL CONTROL
C5	LG/RD	S/C VENT SOL CONTROL
C11	YL/RD	12-VOLT SUPPLY
C24	WT/PK	BRAKE SWITCH SENSE
C32	RD/LG	S/C SWITCH SIGNAL



SPEED CONTROL SWITCH CONNECTOR

CAV	COLOR	FUNCTION
1	BR/YL	GROUND
2	RD/LG	SPEED CONTROL SIGNAL


80b6b36a

FIG. 2

TEST TC-86A


REPAIRING - SPEED CONTROL SWITCH ALWAYS HIGH

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-4A.**

****Check connectors - Clean / repair as necessary.**



80b099e0

FIG. 1




**Perform Verification TEST VER-4A.*

***Check connectors - Clean / repair as necessary.*

TEST TC-86B

REPAIRING - SPEED CONTROL SWITCH ALWAYS HIGH

Perform TEST TC-86A Before Proceeding



80b099e0

Name of Code: Speed Control Switch Always High

When monitored: With the ignition key on.

Set condition: An open condition is detected in the speed control on/off switch circuit.

Theory of operation: This circuit is monitored continuously by the PCM whenever the ignition is turned on. The trouble code sets if the voltage in this circuit is above 4.7 volts for more than 1 second.

Possible causes:

- > Mux switch circuit shorted to power
- > Mux switch circuit open
- > Open on/off switch
- > PCM failure


805005a6

FIG. 1

TEST TC-86B

REPAIRING - SPEED CONTROL SWITCH ALWAYS HIGH

Perform TEST TC-86A Before Proceeding



***Perform Verification TEST VER-4A.**

****Check connectors - Clean / repair as necessary.**

TEST TC-87A

REPAIRING - SPEED CONTROL SWITCH ALWAYS LOW

Perform TEST DTC Before Proceeding

Name of code: Speed Control Switches

When monitored: With the ignition key on, and battery voltage greater than 10.4 volts.


Set condition: When switch voltage is less than 4.5 volts for 2 minutes.

Theory of operation: A single wire referenced to sensor return ground is used to sense steering wheel mounted switches. Each switch has an associated resistance valve. The switch resistance forms a voltage divider with the PCM's internal pull up resistor to 5 volts. The resistor divider creates a unique voltage at the PCM's input pin thereby allowing multiple switches to be "multiplexed" on a single input.

Possible causes:

- > Switch circuit shorted
- > PCM failure
- > Shorted S/C switch
- > One or more switch stuck or held closed


80aff507



80b099e0

TJ/XJ BODY

SPEED CONTROL SWITCH CONNECTOR




CAV	COLOR	FUNCTION
1	BR/YL	GROUND
2	RD/LG	SPEED CONTROL SIGNAL

80ab3724

FIG. 1

TJ/XJ BODY

POWERTRAIN CONTROL MODULE CONNECTORS



CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
C4	TN/RD	S/C VACUUM SOL CONTROL
C5	LG/RD	S/C VENT SOL CONTROL
C11	YL/RD	12-VOLT SUPPLY
C24	WT/PK	BRAKE SWITCH SENSE
C32	RD/LG	S/C SWITCH SIGNAL


80b6s1cb

FIG. 2

TEST TC-87A

REPAIRING - SPEED CONTROL SWITCH ALWAYS LOW

Perform TEST DTC Before Proceeding



***Perform Verification TEST VER-4A.**


****Check connectors - Clean / repair as necessary.**

TEST TC-101A

REPAIRING - FUEL PUMP (SYSTEM) RELAY CONTROL CIRCUIT


Perform TEST DTC Before Proceeding

TJ BODY



80b6f0ce

XJ BODY



80b6f0d4

Name of code: Fuel Pump Relay Control Circuit**When monitored:** With the ignition key on and battery voltage greater than 10 volts.**Set condition:** An open or shorted condition is detected in the fuel pump relay control circuit.**Theory of operation:** The fuel pump relay controls the 12-volt source to the fuel pump. The relay is located in the power distribution center (PDC). One side of the relay control coil is supplied with 12 volts when the ignition switch is turned to the "run" position. The circuit is completed when the other side of the relay coil is grounded by the powertrain control module. The PCM grounds the relay when the ignition switch is in either the run or crank position and engine RPM is detected. If engine RPM is not detected, the PCM will remove the fuel pump relay control circuit ground.**Possible causes:**

- > Relay coil open or shorted
- > Fused ignition switch output circuit open
- > Fuel pump relay control circuit is open or shorted
- > Inoperative circuit driver in powertrain control module
- > Connector terminals
- > Connector wires


3350206

FIG. 1

TEST TC-101A

REPAIRING - FUEL PUMP (SYSTEM) RELAY CONTROL CIRCUIT

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ BODY

**POWER DISTRIBUTION CENTER (PDC)
(RELAY SECTION)**




CAV	COLOR	FUNCTION
16(30)	DG/BK	FUSED B(+)
17(87)	DG/WT	FUEL PUMP RELAY OUTPUT
18(86)	DB	FUSED IGNITION SWITCH OUTPUT
20(85)	BR	FUEL PUMP RELAY CONTROL

80b6f0e9

FIG. 1

XJ BODY

**POWER DISTRIBUTION CENTER (PDC)
(RELAY SECTION)**




CAV	COLOR	FUNCTION
2 (30)	DG/BK	FUSED B(+)
8 (87)	DG/WT	FUEL PUMP RELAY OUTPUT
4 (86)	DB/WT	FUSED IGNITION SWITCH OUTPUT
6 (85)	BR	FUEL PUMP RELAY CONTROL

80b6f0e0

FIG. 2


TJ BODY



80b76e97

FIG. 3


XJ BODY



80b76e98


FIG. 4

TJ BODY



**POWERTRAIN CONTROL MODULE
GREY CONNECTOR**

CAV	COLOR	FUNCTION
C19	BR	FUEL PUMP RELAY CONTROL




FUEL PUMP RELAY CONNECTOR (IN PDC)

CAV	COLOR	FUNCTION
16 (30)	DG/BK	FUSED B(+)
17 (87)	DG/WT	FUEL PUMP RELAY OUTPUT
18 (86)	DB	FUSED IGNITION SWITCH OUTPUT
20 (85)	BR	FUEL PUMP RELAY CONTROL

80b76ec6


FIG. 5

XJ BODY



**POWERTRAIN CONTROL MODULE
GREY CONNECTOR**

CAV	COLOR	FUNCTION
C19	BR	FUEL PUMP RELAY CONTROL



FUEL PUMP RELAY CONNECTOR (IN PDC)


CAV	COLOR	FUNCTION
2 (30)	DG/BK	FUSED B(+)
4 (86)	DB/WT	FUSED IGNITION SWITCH OUTPUT
6 (85)	BR	FUEL PUMP RELAY CONTROL
8 (87)	DG/WT	FUEL PUMP RELAY OUTPUT

80b76ec7

FIG. 6

TEST TC-101A

CONTINUED - REPAIRING - FUEL PUMP (SYSTEM) RELAY CONTROL CIRCUIT



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

TEST TC-114A

REPAIRING - P/N SWITCH STUCK IN PARK OR GEAR


Perform TEST DTC Before Proceeding

XJ BODY (2.5L)




80b6f0d6

TJ BODY (2.5L AND 4.0L)



80b11885

XJ BODY (4.0L)



80b76ec9

Name of code: Park/Neutral Switch Failure (Sense Circuit)

When monitored: With the transmission in park, neutral, or drive and not in limp-in mode.

Set condition: This code is set if the PCM detects an incorrect park/neutral switch state for a given mode of vehicle operation.

Theory of operation: The park/neutral position switch is used to communicate whether or not the transmission is in park or neutral to the PCM. When the transmission is in park or neutral, the park/neutral position switch sense circuit is grounded.

Probable causes:

- > Connector terminals and/or wires
- > Park/neutral switch failure
- > Mechanical transmission problem
- > PCM failure


80aa0f39

FIG. 1

TEST TC-114A

REPAIRING - P/N SWITCH STUCK IN PARK OR GEAR


Perform TEST DTC Before Proceeding



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

ALL OTHERS



POWERTRAIN CONTROL MODULE BLACK CONNECTOR

CAV	COLOR	FUNCTION
A6	BK/WT	PARK/NEUTRAL POSITION SW SENSE (XJ 2.5L)
A6	BR/LB	PARK/NEUTRAL POSITION SW SENSE (TJ 2.5L, 4.0L)



PARK/NEUTRAL POSITION SWITCH CONNECTOR

XJ 2.5L A/T

CAV	COLOR	FUNCTION
1	WT	FUSED IGNITION SWITCH-I OUTPUT
2	BK/WT	PARK/NEUTRAL POSITION SW SENSE
3	BR/LG	BACK-UP LAMPS FEED

TJ 2.5L AND 4.0L A/T


CAV	COLOR	FUNCTION
1	VT/WT	FUSED IGNITION SWITCH-I OUTPUT
2	BR/LB	PARK/NEUTRAL POSITION SW SENSE
3	VT/BK	BACK-UP LAMPS FEED

FIG. 1

80b76ec8

XJ BODY 4.0L

POWERTRAIN CONTROL MODULE BLACK CONNECTOR



CAV	COLOR	FUNCTION
A6	BK/WT	PARK/NEUTRAL POSITION SWITCH SENSE

TRANSMISSION RANGE SENSOR CONNECTOR

CAV	COLOR	FUNCTION
7	BK/WT	PARK/NEUTRAL POSITION SWITCH SENSE
8	BK	GROUND





FIG. 2


80ab373a



*Perform Verification TEST VER-2A.


**Check connectors - Clean / repair as necessary.

ALL OTHERS



POWERTRAIN CONTROL MODULE BLACK CONNECTOR

CAV	COLOR	FUNCTION
A6	BK/WT	PARK/NEUTRAL POSITION SW SENSE (XJ 2.5L)
A6	BR/LB	PARK/NEUTRAL POSITION SW SENSE (TJ 2.5L, 4.0L)



PARK/NEUTRAL POSITION SWITCH CONNECTOR

XJ 2.5L A/T

CAV	COLOR	FUNCTION
1	WT	FUSED IGNITION SWITCH-I OUTPUT
2	BK/WT	PARK/NEUTRAL POSITION SW SENSE
3	BR/LG	BACK-UP LAMPS FEED

TJ 2.5L AND 4.0L A/T


CAV	COLOR	FUNCTION
1	VT/WT	FUSED IGNITION SWITCH-I OUTPUT
2	BR/LB	PARK/NEUTRAL POSITION SW SENSE
3	VT/BK	BACK-UP LAMPS FEED

FIG. 1

80b76ec8

XJ BODY 4.0L


POWERTRAIN CONTROL MODULE BLACK CONNECTOR



CAV	COLOR	FUNCTION
A6	BK/WT	PARK/NEUTRAL POSITION SWITCH SENSE


TRANSMISSION RANGE SENSOR CONNECTOR

CAV	COLOR	FUNCTION
7	BK/WT	PARK/NEUTRAL POSITION SWITCH SENSE
8	BK	GROUND



80ab373a

FIG. 2




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TEST TC-115A REPAIRING - POWER STEERING SWITCH FAILURE

Perform TEST DTC Before Proceeding

2.5L TJ/XJ

4070103

Name of code: Power Steering Switch Failure

When monitored: With the ignition key on and engine running.

Set condition: With the vehicle above 40 mph for over 30 seconds, the power steering pressure switch remains open.

Theory of operation: The PCM monitors the power steering pressure switch for a high pressure condition. The power steering pressure switch signals the PCM whenever there is a power steering load (pressure exceeding 500 psi). During this condition, the PCM will adjust the RPM to prevent a possible stall. The power steering switch is a normally closed switch.

Possible causes:


- > An open power steering switch
- > Powertrain control module failure
- > Connector terminals
- > Connector wires

3220603

TEST TC-115A

REPAIRING - POWER STEERING SWITCH FAILURE

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

2.5L TJ/XJ

POWER STEERING SWITCH CONNECTOR




CAV	COLOR	FUNCTION
1	BK	GROUND
2	DB/BR	POWER STEERING PRESSURE SW SENSE (2.5L TJ/XJ)

80b76f27

FIG. 1


2.5L TJ/XJ

POWER STEERING SWITCH CONNECTOR



CAV	COLOR	FUNCTION
1	BK	GROUND
2	DB/BR	POWER STEERING PRESSURE SW SENSE

POWERTRAIN CONTROL MODULE BLACK CONNECTOR




CAV	COLOR	FUNCTION
A12	DB/BR	POWER STEERING PRESSURE SW SENSE (2.5L TJ/XJ)

80b76f28


FIG. 2

TEST TC-115A CONTINUED - REPAIRING POWER STEERING SWITCH FAILURE



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**



4070103

2.5L TJ/XJ


POWER STEERING SWITCH CONNECTOR



CAV	COLOR	FUNCTION
1	BK	GROUND
2	DB/BR	POWER STEERING PRESSURE SW SENSE (2.5L TJ/XJ)

80b76f27

FIG. 1



**Perform Verification TEST VER-2A.*

***Check connectors - Clean / repair as necessary.*

Perform TEST DTC Before Proceeding

Name of Code: Fuel System Rich

When monitored: With the engine running in closed loop mode and the ambient/battery temperature above 20°F and altitude < 8000 ft.

Set condition: The PCM conducts a test to determine whether the fuel system is running too rich. If this happens for 2 trips, the MIL illuminates and a trouble code is stored. The MIL remains on for more than one trip but goes out if the conditions that set the code are not found on subsequent trips.

Theory of operation: The catalytic converter works best when the air/fuel (A/F) ratio is at or near the optimum of 14.7 to 1. The PCM maintains this optimum air/fuel ratio by making short-term corrections in the fuel injector pulse width based on the upstream O₂ sensor output. The PCM uses the programmed memory as a self-calibration tool to compensate for variations in engine specifications, sensor tolerances, and engine fatigue over the life span of the engine. Monitoring the actual air/fuel ratio with the upstream O₂ sensor (short term) and comparing it to the program (long-term or adaptive) memory determines whether the fuel system is operating within the limits needed to pass an emission test. If a malfunction prevents the PCM from maintaining the optimum A/F ratio, the MIL illuminates.

Possible causes:


- > Catalyst plugged
- > Powertrain control module
- > Engine parts tolerance
- > Injectors stuck open
- > MAP sensor
- > O₂ sensor (upstream)
- > Fuel pressure regulator
- > Wiring harness/connectors

80660077

FIG. 1

TEST TC-118A REPAIRING - FUEL SYSTEM RICH 1/1 RICH

Perform TEST DTC Before Proceeding



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

TEST TC-118B **REPAIRING - FUEL SYSTEM RICH 1/1 RICH**

Perform TEST TC-118A Before Proceeding

TJ BODY


POWERTRAIN CONTROL MODULE



80b118a1

XJ BODY

POWERTRAIN CONTROL MODULE



80b118a2

TEST TC-118B

REPAIRING - FUEL SYSTEM RICH 1/1 RICH

Perform TEST TC-118A Before Proceeding

Using the test schematic as a guide, make sure all the wiring and connectors are okay.

Perform each of the following tests in the order listed below. If a test passes, continue to the next until the problem is found.

- Fuel PressureTEST NTC-5A
- Coolant Temperature SensorTEST NTC-6A
- Throttle Position SensorTEST NTC-7A
- MAP SensorTEST NTC-8A
- Engine Mechanical SystemsTEST NTC-13A
- Evaporative Emission SensorTEST NTC-17A

TEST TC-119A REPAIRING - FUEL SYSTEM LEAN 1/1 LEAN

Perform TEST DTC Before Proceeding

Name of Code: Fuel System Lean

When monitored: With the engine running in closed loop mode and the ambient/battery temperature above 20°F and altitude < 8000 ft.

Set condition: The PCM conducts a test to determine whether the fuel system is running too lean. If this happens for 2 trips, the MIL illuminates and a trouble code is stored. The MIL remains on for more than one trip but goes out if the conditions that set the code are not found on subsequent trips.

Theory of operation: The catalytic converter works best when the air/fuel (A/F) ratio is at or near the optimum of 14.7 to 1. The PCM maintains this optimum air/fuel ratio by making short-term corrections in the fuel injector pulse width based on the upstream O₂ sensor output. The PCM uses the programmed memory as a self-calibration tool to compensate for variations in engine specifications, sensor tolerances, and engine fatigue over the life span of the engine. Monitoring the actual air/fuel ratio with the upstream O₂ sensor (short-term) and comparing it to the program (long-term or adaptive) memory determines whether the fuel system is operating within the limits needed to pass an emission test. If a malfunction prevents the PCM from maintaining the optimum A/F ratio, the MIL illuminates.

Possible causes:


- | | |
|-----------------------------|------------------------------------|
| > Ignition coil | > Injectors stuck closed |
| > Powertrain control module | > MAP sensor |
| > Engine parts tolerance | > O ₂ sensor (upstream) |
| > Exhaust pipe manifold | > Fuel pressure regulator |
| > Fuel pump | > Fuel pump relay |
| > Fuel pump inlet filter | > Spark plugs |
| > Ignition secondary wires | > Wiring harness/connectors |
| > Low fuel level | |

80660063

FIG. 1

TEST TC-119A REPAIRING - FUEL SYSTEM LEAN 1/1 LEAN

Perform TEST DTC Before Proceeding



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

TEST TC-119B **REPAIRING - FUEL SYSTEM LEAN 1/1 LEAN**

Perform TEST TC-119A Before Proceeding

TJ BODY


POWERTRAIN CONTROL MODULE



80b118a1

XJ BODY

POWERTRAIN CONTROL MODULE



80b118a2

TEST TC-119B

REPAIRING - FUEL SYSTEM LEAN 1/1 LEAN

Perform TEST TC-119A Before Proceeding

Using the test schematic as a guide, make sure all the wiring and connectors are okay.

Perform each of the following tests in the order listed below. If a test passes, continue to the next until the problem is found.


- Fuel PressureTEST NTC-5A
- Coolant Temperature SensorTEST NTC-6A
- Throttle Position SensorTEST NTC-7A
- MAP SensorTEST NTC-8A
- Engine Mechanical SystemsTEST NTC-13A

TEST TC-126A

REPAIRING - 1/2 O2 SENSOR SHORTED TO VOLTAGE


Perform TEST DTC Before Proceeding

TJ BODY



80b118a1

XJ BODY



80b118a2

JTEC O2 SENSOR CONFIGURATION

TJ2.5L	1/1	UPSTREAM	XJ2.5L	1/1	UPSTREAM
TJ2.5L	1/2	DOWNSTREAM	XJ2.5L	1/2	DOWNSTREAM
TJ4.0L	1/1	UPSTREAM	XJ4.0L	1/1	UPSTREAM
TJ4.0L	1/2	DOWNSTREAM	XJ4.0L	1/2	DOWNSTREAM

80b76ec3

Name of code: Downstream O2 Sensor Shorted To Voltage

When monitored: With the engine running and coolant temperature at 180° F for 4 minutes or more.

Set condition: The downstream oxygen sensor signal is above 1.5 volts. Two trips are required with the condition present to set the code.

Theory of operation: Effective control of exhaust emissions is achieved by an oxygen feedback system. The downstream oxygen sensor (O2S), which is located in the exhaust path after the catalyst. It monitors the oxygen content of the exhaust gas as it leaves the catalyst. Once the sensor reaches its normal operating temperature of 300 - 350 degrees Celsius, it generates a voltage inversely proportional to the amount of oxygen in the exhaust. The PCM uses this voltage along with that of the upstream oxygen sensor to calculate the efficiency of the catalytic converter.

Possible causes:

- Sensor output wire shorted to a power circuit
- O2 sensor failure
- Powertrain control module failure
- Connector terminal/wires
- Open O2 sensor signal circuit


80aa4b9e

FIG. 1

TEST TC-126A

REPAIRING - 1/2 O2 SENSOR SHORTED TO VOLTAGE

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ BODY

**DOWNSTREAM OXYGEN
SENSOR CONNECTOR
(HARNESS SIDE)**




CAV	COLOR	FUNCTION
1	OR/DG	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	TN/WT	OXYGEN SENSOR SIGNAL

80b6f0e6

FIG. 1

XJ BODY


**DOWNSTREAM OXYGEN
SENSOR CONNECTOR
(HARNESS SIDE)**



CAV	COLOR	FUNCTION
1	OR/DG	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	TN/WT	OXYGEN SENSOR SIGNAL

80b6f0dc

FIG. 2




*Perform Verification TEST VER-2A.



**Check connectors - Clean / repair as necessary.

TJ BODY

BLACK



GREY



POWERTRAIN CONTROL MODULE CONNECTORS

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A25	TN/WT	DOWNSTREAM OXYGEN SENSOR SIGNAL
C12	DG/PK	ASD RELAY OUTPUT

DOWNSTREAM OXYGEN SENSOR CONNECTOR (HARNESS SIDE)


CAV	COLOR	FUNCTION
1	OR/DG	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	TN/WT	DOWNSTREAM OXYGEN SENSOR SIGNAL

80b118a8



FIG. 1

XJ BODY

BLACK



GREY



POWERTRAIN CONTROL MODULE CONNECTORS

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A25	TN/WT	DOWNSTREAM OXYGEN SENSOR SIGNAL
C12	DG/OR	ASD RELAY OUTPUT

DOWNSTREAM OXYGEN SENSOR CONNECTOR (HARNESS SIDE)


CAV	COLOR	FUNCTION
1	DG/WT	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	TN/WT	DOWNSTREAM OXYGEN SENSOR SIGNAL

80b118a9

FIG. 2

TEST TC-126A

CONTINUED - REPAIRING - 1/2 O2 SENSOR SHORTED TO VOLTAGE



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

Perform TEST DTC Before Proceeding

Name of Code: TPS Voltage Does Not Agree with MAP

When monitored: With the engine running and no MAP sensor or TP sensor trouble codes.

Set condition: Engine speed must be greater than 1600 RPM for all TPS testing.

Theory of operation: The TP sensor contains a potentiometer that is operated by the throttle blade shaft. As a throttle plate rotates, the TP sensor provides a variable 0 to 5-volt signal to PCM. The voltage is directly proportional to throttle angle. When the throttle plate is at rest, the voltage is low. When the throttle is fully open, the voltage is high. With this signal, the PCM can determine precise throttle position under all operating conditions. The TP sensor receives a 5-volt supply from the PCM. The sensor ground is provided by the PCM.

Possible causes:

- > Failed powertrain control module
- > TP sensor failure
- > Mechanical failure
- > Connector terminals
- > Connector wires
- > Vehicle speed
- > MAP sensor


80660065

FIG. 1

TEST TC-132A


REPAIRING - TPS VOLTAGE DOES NOT AGREE WITH MAP

Perform TEST DTC Before Proceeding



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

TJ/XJ BODY**THROTTLE POSITION
SENSOR CONNECTOR**

CAV	COLOR	FUNCTION
1	BR/YL	SENSOR GROUND
2	OR/DB	TP SENSOR SIGNAL
3	OR	5-VOLT SUPPLY


80b6f0e7

FIG. 1



*Perform Verification TEST VER-2A.


**Check connectors - Clean / repair as necessary.



80b0d637

TEST TC-132A

CONTINUED - REPAIRING - TPS VOLTAGE DOES NOT AGREE WITH MAP



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TEST TC-148A

REPAIRING - TORQUE CONVERTER CLUTCH - NO RPM DROP AT LOCK-UP (TJ/XJ BODY WITH 3 SPD AUTO TRANS)

Perform TEST DTC Before Proceeding

TJ/XJ BODY WITH 3 SPD AUTO TRANSMISSION**Name of code:** Torq Conv Clu, No RPM Drop at Lockup**When monitored:** When all of the following steps are taken.

1. None of the following matured or maturing trouble code conditions:
 - a) TCC solenoid circuit
 - b) Any cam/crank-related code
 - c) Vehicle speed signal
 - d) Any TPS-related code
2. Battery voltage > 11.0 volts
3. Vehicle speed < 60 mph during step 5.
4. Run vehicle in third gear at about 40 mph with torque converter unlocked for at least 10 seconds.
5. Apply 1/3 throttle while making sure transmission does not downshift. Back off on the throttle slightly until the torque converter locks. Keep the torque converter locked for at least 5 seconds by holding the throttle and vehicle speed constant.


Set condition: Torque converter malfunctions that are detected are the torque converter not locking up properly when desired, and the torque converter not unlocking properly when desired. A minimum amount of improvement in torque converter efficiency is expected after the torque converter is locked. This expected minimum improvement will not be seen when the torque converter is malfunctioning. Three consecutive test failures over one trip will store the trouble code.

Theory of operation: The torque converter lock-up system locks the crankshaft to the output shaft of the transmission when vehicle road load is stable and transmission is in third gear. This action reduces transmission oil heating, and improves fuel economy. The lock-up system is controlled by the powertrain control module.

Possible causes:


- > Drive wheel size is bigger than standard wheel size or smaller than spare wheel size
- > Low transmission oil level or pressure
- > Debris in transmission oil
- > Incorrect speedo gear for the front wheels
- > PTU solenoid not securely connected or stuck
- > Malfunctioning lock-up valve in transmission
- > Hydraulic leak at torque converter lock-up clutch
- > Worn out friction material on friction disc in torque converter
- > Failed gear box or differential
- > Powertrain control module failure
- > Worn out connector terminals/wires

3380104

TJ/XJ BODY WITH 3 SPD AUTO TRANSMISSIONPOWERTRAIN
CONTROL
MODULE

TO
FUUSED
IGN SW

Fused Ign
Sw Output


TORQUE
CONVERTER
CLUTCH
SOLENOIDTCC Solenoid/
Relay Control

4070105

TEST TC-148A

REPAIRING - TORQUE CONVERTER CLUTCH - NO RPM DROP AT LOCK-UP (TJ/XJ BODY WITH 3 SPD AUTO TRANS)

Perform TEST DTC Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ/XJ BODY WITH 3 SPD AUTO TRANSMISSION

Name of code: Torq Conv Clu, No RPM Drop at Lockup

When monitored: When all of the following steps are taken.

1. None of the following matured or maturing trouble code conditions:
 - a) TCC solenoid circuit
 - b) Any cam/crank-related code
 - c) Vehicle speed signal
 - d) Any TPS-related code
2. Battery voltage > 11.0 volts
3. Vehicle speed < 60 mph during step 5.
4. Run vehicle in third gear at about 40 mph with torque converter unlocked for at least 10 seconds.
5. Apply 1/3 throttle while making sure transmission does not downshift. Back off on the throttle slightly until the torque converter locks. Keep the torque converter locked for at least 5 seconds by holding the throttle and vehicle speed constant.


Set condition: Torque converter malfunctions that are detected are the torque converter not locking up properly when desired, and the torque converter not unlocking properly when desired. A minimum amount of improvement in torque converter efficiency is expected after the torque converter is locked. This expected minimum improvement will not be seen when the torque converter is malfunctioning. Three consecutive test failures over one trip will store the trouble code.

Theory of operation: The torque converter lock-up system locks the crankshaft to the output shaft of the transmission when vehicle road load is stable and transmission is in third gear. This action reduces transmission oil heating, and improves fuel economy. The lock-up system is controlled by the powertrain control module.

Possible causes:

- > Drive wheel size is bigger than standard wheel size or smaller than spare wheel size
- > Low transmission oil level or pressure
- > Debris in transmission oil
- > Incorrect speedo gear for the front wheels
- > PTU solenoid not securely connected or stuck
- > Malfunctioning lock-up valve in transmission
- > Hydraulic leak at torque converter lock-up clutch
- > Worn out friction material on friction disc in torque converter
- > Failed gear box or differential
- > Powertrain control module failure
- > Worn out connector terminals/wires


3380104

TJ/XJ BODY WITH 3 SPD AUTO TRANSMISSION

4070105

TEST TC-148A

CONTINUED - REPAIRING - TORQUE CONVERTER CLUTCH - NO RPM DROP AT LOCK-UP (TJ/XJ BODY WITH 3 SPD AUTO TRANS)



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

**T
R
O
U
B
L
E
C
O
D
E
T
E
S
T
S**


TEST TC-148A

CONTINUED - REPAIRING - TORQUE CONVERTER CLUTCH - NO RPM DROP AT LOCK-UP (TJ/XJ BODY WITH 3 SPD AUTO TRANS)

NOTES

TEST TC-148A

CONTINUED - REPAIRING - TORQUE CONVERTER CLUTCH - NO RPM DROP AT LOCK-UP (TJ/XJ BODY WITH 3 SPD AUTO TRANS)




**Perform Verification TEST VER-2A.*

***Check connectors - Clean / repair as necessary.*


TEST TC-149A

REPAIRING - FUEL LEVEL SENDING UNIT VOLTS TOO LOW

Perform TEST DTC Before Proceeding

TJ BODY

80b6f0ce

XJ BODY

80b6f0d4

Name of code: Fuel Level Sending Unit Volts Too Low**When monitored:** Ignition on and battery voltage above 10.4 volts.**Set condition:** The fuel level sensor signal circuit voltage at the PCM goes below .4 volts for 90 seconds.

Theory of operation: The fuel sending unit provides a variable voltage signal to the powertrain control module to indicate fuel level. The purpose of this feature is to prevent false setting of misfire and fuel system monitor codes when the vehicle is operating at low fuel levels. When the fault is detected by the PCM, the PCM will default the fuel gauge to an empty reading. This will alert the driver of a malfunction in the fuel level sending unit system.

Possible causes:

- > Sensor signal circuit shorted to ground
- > Fuel pump module failure
- > Powertrain control module failure
- > Connector wires
- > Connector terminals


FIG. 1

80b7700c

TEST TC-149A

REPAIRING - FUEL LEVEL SENDING UNIT VOLTS TOO LOW

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ BODY

FUEL PUMP CONNECTOR




CAV	COLOR	FUNCTION
1	DG/WT	FUEL PUMP RELAY OUTPUT
3	DB/LG	FUEL LEVEL SENSOR SIGNAL
4	BR/YL	SENSOR GROUND
6	BK	GROUND

80b6f0e8

FIG. 1

XJ BODY

FUEL PUMP MODULE CONNECTOR




CAV	COLOR	FUNCTION
1	DG/WT	FUEL PUMP RELAY OUTPUT
3	DB/LG	FUEL LEVEL SENSOR SIGNAL
4	BR/YL	SENSOR GROUND
6	BK	GROUND

80aafa16

FIG. 2

TEST TC-149A

CONTINUED - REPAIRING - FUEL LEVEL SENDING UNIT VOLTS TOO LOW




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


TEST TC-150A

REPAIRING - FUEL LEVEL SENDING UNIT VOLTS TOO HIGH

Perform TEST DTC Before Proceeding

TJ BODY

80b6f0ce

XJ BODY

80b6f0d4

TJ/XJ BODY**Name of code:** Fuel Level Sending Unit Volts Too High**When monitored:** Ignition on and battery voltage above 10.4 volts.**Set condition:** The fuel level sensor signal circuit voltage at the PCM goes above 9.9 volts for 90 seconds.**Theory of operation:** The fuel sending unit provides a variable voltage signal to the powertrain control module to indicate fuel level. The purpose of this feature is to prevent false setting of misfire and fuel system monitor codes when the vehicle is operating at low fuel levels. When the fault is detected by the PCM, the PCM will default the fuel gauge to an empty reading. This will alert the driver of a malfunction in the fuel level sending unit system.**Possible causes:**

- > Open sensor signal circuit
- > Open sensor ground circuit
- > Fuel level sending unit failure
- > Powertrain control module failure
- > Connector wires
- > Connector terminals


FIG. 1

80b7700b

TEST TC-150A

REPAIRING - FUEL LEVEL SENDING UNIT VOLTS TOO HIGH

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ BODY

FUEL PUMP CONNECTOR




CAV	COLOR	FUNCTION
1	DG/WT	FUEL PUMP RELAY OUTPUT
3	DB/LG	FUEL LEVEL SENSOR SIGNAL
4	BR/YL	SENSOR GROUND
6	BK	GROUND

80b6f0e8

FIG. 1

XJ BODY

FUEL PUMP MODULE CONNECTOR




CAV	COLOR	FUNCTION
1	DG/WT	FUEL PUMP RELAY OUTPUT
3	DB/LG	FUEL LEVEL SENSOR SIGNAL
4	BR/YL	SENSOR GROUND
6	BK	GROUND

80aafa16

FIG. 2

TEST TC-150A

CONTINUED - REPAIRING - FUEL LEVEL SENDING UNIT VOLTS TOO HIGH




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


TJ BODY

GREY



**POWERTRAIN CONTROL MODULE
GREY CONNECTORS**


CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
C19	BR	FUEL PUMP RELAY CONTROL
C26	DB/LG	FUEL LEVEL SENSOR SIGNAL



BLACK

A4

**FUEL PUMP
CONNECTOR**




CAV	COLOR	FUNCTION
1	DG/WT	FUEL PUMP RELAY OUTPUT
3	DB/LG	FUEL LEVEL SENSOR SIGNAL (GAUGE)
4	BR/YL	GROUND (GAUGE)
6	BK	GROUND (PUMP)

80b76eee

FIG. 1


XJ BODY

GREY



**POWERTRAIN CONTROL MODULE
GREY CONNECTORS**


CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
C19	BR	FUEL PUMP RELAY CONTROL
C26	DB/LG	FUEL LEVEL SENSOR SIGNAL



BLACK

A4

**FUEL PUMP
CONNECTOR**




CAV	COLOR	FUNCTION
1	DG/WT	FUEL PUMP RELAY OUTPUT
3	DB/LG	FUEL LEVEL SENSOR SIGNAL (GAUGE)
4	BR/YL	GROUND (GAUGE)
6	BK	GROUND (PUMP)

80b76e10

FIG. 2

TEST TC-150A

CONTINUED - REPAIRING - FUEL LEVEL SENDING UNIT VOLTS TOO HIGH




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


TEST TC-151A

REPAIRING - FUEL LEVEL SENDING UNIT NO CHANGE OVER TIME

Perform TEST DTC Before Proceeding

TJ BODY

80b6f0ce

XJ BODY

80b6f0d4

TJ/XJ BODY**Name of code:** Fuel Level Sending Unit No Change Over Time**When monitored:** Ignition on, vehicle running at normal operating temperature.**Set condition:** The PCM sees the fuel level between 9.4 and 9.9 for 4.5 minutes.**Theory of operation:** The fuel sending unit provides a variable voltage signal to the powertrain control module to indicate fuel level. The purpose of this feature is to prevent false setting of misfire and fuel system monitor codes when the vehicle is operating at low fuel levels. When the fault is detected by the PCM, the PCM will default the fuel gauge to an empty reading. This will alert the driver of a malfunction in the fuel level sending unit system.**Possible causes:**

- > Sensor signal circuit high resistance
- > Fuel level sending unit failure
- > Connector wires
- > Connector terminals


FIG. 1

80b6f010

TEST TC-151A

REPAIRING - FUEL LEVEL SENDING UNIT NO CHANGE OVER TIME

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ BODY

FUEL PUMP CONNECTOR




CAV	COLOR	FUNCTION
1	DG/WT	FUEL PUMP RELAY OUTPUT
3	DB/LG	FUEL LEVEL SENSOR SIGNAL
4	BR/YL	SENSOR GROUND
6	BK	GROUND

80b6f0e8

FIG. 1

XJ BODY

FUEL PUMP MODULE CONNECTOR



CAV	COLOR	FUNCTION
1	DG/WT	FUEL PUMP RELAY OUTPUT
3	DB/LG	FUEL LEVEL SENSOR SIGNAL
4	BR/YL	SENSOR GROUND
6	BK	GROUND


80aafa16

FIG. 2


TJ BODY

GREY


POWERTRAIN CONTROL MODULE GREY CONNECTORS



CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
C19	BR	FUEL PUMP RELAY CONTROL
C26	DB/LG	FUEL LEVEL SENSOR SIGNAL



BLACK



FUEL PUMP CONNECTOR

CAV	COLOR	FUNCTION
1	DG/WT	FUEL PUMP RELAY OUTPUT
3	DB/LG	FUEL LEVEL SENSOR SIGNAL (GAUGE)
4	BR/YL	GROUND (GAUGE)
6	BK	GROUND (PUMP)


80b76eee

FIG. 3


XJ BODY

GREY


POWERTRAIN CONTROL MODULE GREY CONNECTORS



CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
C19	BR	FUEL PUMP RELAY CONTROL
C26	DB/LG	FUEL LEVEL SENSOR SIGNAL



BLACK



FUEL PUMP CONNECTOR


CAV	COLOR	FUNCTION
1	DG/WT	FUEL PUMP RELAY OUTPUT
3	DB/LG	FUEL LEVEL SENSOR SIGNAL (GAUGE)
4	BR/YL	GROUND (GAUGE)
6	BK	GROUND (PUMP)

80b76e10

FIG. 4

TEST TC-151A

CONTINUED - REPAIRING - FUEL LEVEL SENDING UNIT SENDING UNIT NO CHANGE OVER TIME



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TEST TC-153A

REPAIRING - BATTERY TEMP SENSOR VOLTAGE TOO LOW/TOO HIGH

Perform TEST DTC Before Proceeding

Name of code: Battery Temp Sensor Voltage
Either Too High or Too Low

When monitored: With the ignition key on.

Set condition: The PCM senses the voltage from the BTS to be either below 0.5 volts or above 4.9 volts for 3 seconds.


Theory of operation: The battery temp sensor voltage is used by the PCM to determine what the charging system goal should be. The PCM uses that goal to determine the charging output level. The battery temp sensor is external to the PCM.

Possible causes:

- > Battery temp sensor failure
- > Open circuit in battery temp sensor signal circuit
- > Short circuit in battery temp sensor signal circuit
- > PCM failure
- > Connector terminals
- > Connector wires

805e2a55

FIG. 1


TJ/XJ BODY

80b118ad

TEST TC-153A

REPAIRING - BATTERY TEMP SENSOR VOLTAGE TOO LOW/TOO HIGH


Perform TEST DTC Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


TJ/XJ BODY



CAV	COLOR	FUNCTION
1	PK/YL	BATTERY TEMP SENSOR SIGNAL
2	BR/YL	SENSOR GROUND

80a5348d

FIG. 1



**Perform Verification TEST VER-2A.*


***Check connectors - Clean / repair as necessary.*

TEST TC-153B

REPAIRING - BATTERY TEMP SENSOR VOLTAGE TOO LOW/TOO HIGH

Perform TEST TC-153A Before Proceeding

TJ/XJ BODY




CAV	COLOR	FUNCTION
1	PK/YL	BATTERY TEMP SENSOR SIGNAL
2	BR/YL	SENSOR GROUND

80a5348d


FIG. 1

TJ/XJ BODY



**BATTERY TEMPERATURE
SENSOR CONNECTOR**

CAV	COLOR	FUNCTION
1	PK/YL	Battery Temp Sensor Signal
2	BR/YL	Sensor Ground



**POWERTRAIN
CONTROL MODULE
CONNECTORS**

CAV	COLOR	FUNCTION
A4	BR/YL	Sensor Ground
C15	PK/YL	BTS Signal


80a9b344

FIG. 2

TEST TC-153B

REPAIRING - BATTERY TEMP SENSOR VOLTAGE TOO LOW/TOO HIGH

Perform TEST TC-153A Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

Perform TEST DTC Before Proceeding

Name of Code: O2S Voltage Shorted To Ground

When monitored: With engine coolant temperature above 170°F on the previous key on, after a cold start, engine coolant below 98°F, and ambient/battery sensor reading within 27°F of engine coolant.

Set condition: The oxygen sensor signal voltage is below 0.156 volts for 28 seconds after starting engine.

Theory of operation: The oxygen sensor is a voltage generating device. The PCM receives exhaust gas information from this O2 sensor. The sensor detects exhaust gas content by a galvanic reaction within the sensor that produces a voltage. After measuring the amount of oxygen in the exhaust gases, the oxygen sensor tells the PCM how well its output signals are controlling the air/fuel ratio. Variations in the signal from this O2 sensor serve as air/fuel ratio indicators. Changes in the sensor signal occur because the air/fuel ratio is constantly changing. When oxygen content is low (rich mixture), the voltage signal will be low, approximately 0.1 volt.

Possible causes:

- > Sensor output wire shorted to ground
- > Dirty/wet connection causing voltage tracking in connector
- > O2 sensor failure
- > Powertrain control module failure
- > Connector terminals
- > Connector wires

80b01cfc


JTEC O2 SENSOR CONFIGURATION

TJ2.5L	1/1	UPSTREAM	XJ2.5L	1/1	UPSTREAM
TJ2.5L	1/2	DOWNSTREAM	XJ2.5L	1/2	DOWNSTREAM
TJ4.0L	1/1	UPSTREAM	XJ4.0L	1/1	UPSTREAM
TJ4.0L	1/2	DOWNSTREAM	XJ4.0L	1/2	DOWNSTREAM


80b76ec3

FIG. 1

TJ BODY




XJ BODY



TEST TC-155A

REPAIRING - 1/1 O2 SENSOR SHORTED TO GROUND

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**



****Check connectors - Clean / repair as necessary.**

TJ BODY

BLACK



GREY



80b76ec5

POWERTRAIN CONTROL MODULE CONNECTORS

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A24	BK/DG	UPSTREAM OXYGEN SENSOR SIGNAL
C12	DG/PK	ASD RELAY OUTPUT


UPSTREAM OXYGEN SENSOR CONNECTOR (HARNES SIDE)

CAV	COLOR	FUNCTION
1	OR/DG	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	BK/DG	OXYGEN SENSOR SIGNAL



FIG. 1

XJ BODY

BLACK



GREY



80b76ec4


POWERTRAIN CONTROL MODULE CONNECTORS

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A24	BK/DG	UPSTREAM OXYGEN SENSOR SIGNAL
C12	DG/OR	ASD RELAY OUTPUT

UPSTREAM OXYGEN SENSOR CONNECTOR (HARNES SIDE)

CAV	COLOR	FUNCTION
1	DG/WT	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	BK/DG	OXYGEN SENSOR SIGNAL

FIG. 2



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TEST TC-156A

REPAIRING - 1/2 O2 SENSOR SHORTED TO GROUND

Perform TEST DTC Before Proceeding

Name of code: Downstream O2S Voltage Shorted To Ground

When monitored: With engine coolant temperature above 170°F on the previous key on, after a cold start, engine coolant below 90°F, and ambient sensor reading within +/-59°F of engine coolant.

Set condition: The downstream oxygen sensor signal voltage is below 0.156 volt prior to O2 sensor heater test.

Theory of operation: The downstream oxygen sensor is a voltage generating device. The PCM receives exhaust gas information from this O2 sensor. The sensor detects exhaust gas content by a galvanic reaction within the sensor that produces a voltage. After measuring the amount of oxygen in the exhaust gases. Variations in the signals from this O2 sensor serve as an indicator of oxygen content.

Possible causes:

- > Sensor output wire shorted to ground
- > Dirty/wet connection causing voltage tracking in connector
- > O2 sensor failure
- > Powertrain control module failure
- > Connector terminals/wires

80a5571b


JTEC O2 SENSOR CONFIGURATION

TJ2.5L	1/1	UPSTREAM	XJ2.5L	1/1	UPSTREAM
TJ2.5L	1/2	DOWNSTREAM	XJ2.5L	1/2	DOWNSTREAM
TJ4.0L	1/1	UPSTREAM	XJ4.0L	1/1	UPSTREAM
TJ4.0L	1/2	DOWNSTREAM	XJ4.0L	1/2	DOWNSTREAM


80b76ec3

FIG. 1

TJ BODY




XJ BODY



TEST TC-156A

REPAIRING - 1/2 O2 SENSOR SHORTED TO GROUND

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**



****Check connectors - Clean / repair as necessary.**

TJ BODY

BLACK



GREY



80b76ec5

POWERTRAIN CONTROL MODULE CONNECTORS

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A24	BK/DG	UPSTREAM OXYGEN SENSOR SIGNAL
C12	DG/PK	ASD RELAY OUTPUT


UPSTREAM OXYGEN SENSOR CONNECTOR (HARNES SIDE)

CAV	COLOR	FUNCTION
1	OR/DG	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	BK/DG	OXYGEN SENSOR SIGNAL



FIG. 1

XJ BODY

BLACK



GREY



80b76ec4


POWERTRAIN CONTROL MODULE CONNECTORS

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A24	BK/DG	UPSTREAM OXYGEN SENSOR SIGNAL
C12	DG/OR	ASD RELAY OUTPUT

UPSTREAM OXYGEN SENSOR CONNECTOR (HARNES SIDE)

CAV	COLOR	FUNCTION
1	DG/WT	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	BK/DG	OXYGEN SENSOR SIGNAL

FIG. 2



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TEST TC-157A REPAIRING - INTERMITTENT LOSS OF CMP OR CKP


Perform TEST DTC Before Proceeding

Name of code: Intermittent Loss of CMP or CKP**When Monitored:** Engine running or cranking.**Set Condition:** When the failure counter reaches 96 for 2 consecutive trips.**Theory of operation:** A failure counter is incremented whenever the correct number of crank signals is not seen between two cam signals. A bad trip is stored when the failure counter reaches 96. Two consecutive bad trips are required to set the fault.**Possible Causes:**

- > Open or shorted 5 volt supply circuit
- > Open sensor ground
- > Open or shorted signal circuit
- > Excessive crankshaft sensor clearance
- > Excessive camshaft sensor clearance
- > Damaged crankshaft sensor rotating component
- > Damaged camshaft sensor rotating component
- > Failed sensor
- > Failed PCM

80a5574d


FIG. 1

TJ/XJ BODY

80a4eff4

TEST TC-157A REPAIRING - INTERMITTENT LOSS OF CMP OR CKP


Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ/XJ BODY





***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

Name of code: Intermittent Loss of CMP or CKP

When Monitored: Engine running or cranking.

Set Condition: When the failure counter reaches 96 for 2 consecutive trips.

Theory of operation: A failure counter is incremented whenever the correct number of crank signals is not seen between two cam signals. A bad trip is stored when the failure counter reaches 96. Two consecutive bad trips are required to set the fault.


Possible Causes:

- > Open or shorted 5 volt supply circuit
- > Open sensor ground
- > Open or shorted signal circuit
- > Excessive crankshaft sensor clearance
- > Excessive camshaft sensor clearance
- > Damaged crankshaft sensor rotating component
- > Damaged camshaft sensor rotating component
- > Failed sensor
- > Failed PCM


80a5574d

FIG. 1

TJ/XJ BODY



80a4eff4



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TEST TC-157B REPAIRING - INTERMITTENT LOSS OF CMP OR CKP


Perform TEST TC-157A Before Proceeding

Name of code: Intermittent Loss of CMP or CKP**When Monitored:** Engine running or cranking.**Set Condition:** When the failure counter reaches 96 for 2 consecutive trips.**Theory of operation:** A failure counter is incremented whenever the correct number of crank signals is not seen between two cam signals. A bad trip is stored when the failure counter reaches 96. Two consecutive bad trips are required to set the fault.**Possible Causes:**

- > Open or shorted 5 volt supply circuit
- > Open sensor ground
- > Open or shorted signal circuit
- > Excessive crankshaft sensor clearance
- > Excessive camshaft sensor clearance
- > Damaged crankshaft sensor rotating component
- > Damaged camshaft sensor rotating component
- > Failed sensor
- > Failed PCM

80a5574d


FIG. 1

TJ/XJ BODY

80a4eff4

TEST TC-157B REPAIRING - INTERMITTENT LOSS OF CMP OR CKP

Perform TEST TC-157A Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TEST TC-157C

REPAIRING - INTERMITTENT LOSS OF CMP OR CKP

Perform TEST TC-157A Before Proceeding





FIG. 1

1070304

TJ/XJ BODY




80a4eff4

TEST TC-157C

REPAIRING - INTERMITTENT LOSS OF CMP OR CKP

Perform TEST TC-157A Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TEST TC-157D


REPAIRING - INTERMITTENT LOSS OF CMP OR CKP

Perform TEST TC-157A Before Proceeding

TJ/XJ BODY 2.5L AND 4.0L

**ELECTRICAL
CONNECTOR**

**CRANKSHAFT
POSITION
SENSOR**




80a9297e

FIG. 1

TEST TC-157D

REPAIRING - INTERMITTENT LOSS OF CMP OR CKP

Perform TEST TC-157A Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TEST TC-225A

REPAIRING - NO CDD BUS MESSAGE FROM THE MIC

Perform TEST DTC Before Proceeding

TJ BODY




FIG. 1

XJ BODY





FIG. 2

TEST TC-225A

REPAIRING - NO CDD BUS MESSAGE FROM THE MIC

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ BODY

**INSTRUMENT
CLUSTER HARNESS
CONNECTOR C1**

CAV	COLOR	FUNCTION
1	WT/BK	CCD BUS (-)
2	VT/BR	CCD BUS (+)



**POWERTRAIN
CONTROL MODULE
HARNESS
CONNECTOR**

CAV	COLOR	FUNCTION
C28	WT/BK	CCD BUS (-)
C30	VT/BR	CCD BUS (+)





FIG. 1

80b6b37c

XJ BODY

**INSTRUMENT
CLUSTER HARNESS
CONNECTOR C2**

CAV	COLOR	FUNCTION
1	WT/BK	CCD BUS (-)
2	VT/BR	CCD BUS (+)



**POWERTRAIN
CONTROL MODULE
HARNESS
CONNECTOR**

CAV	COLOR	FUNCTION
C28	WT/BK	CCD BUS (-)
C30	VT/BR	CCD BUS (+)





FIG. 2

80b6b37e




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


TEST TC-226A

REPAIRING - NO CCD BUS MESSAGE RECEIVED FROM SKIM

Perform TEST DTC Before Proceeding

TJ BODY

80b6f0cc

XJ BODY

80b6f0d2

Name of code: No CCD Message From SKIM Module**When Monitored:** With ignition on.**Set Condition:** The PCM does not receive a CCD Bus message from the SKIM module when expected.

Theory of operation: At ignition on, the SKIM module sends a message to the PCM verifying the correct ignition key. If the PCM receives a correct message, it will allow the engine to start and continue to run. If the PCM does not receive a message or receives an incorrect key message the PCM will allow the engine to start and run for two seconds. If the PCM does not receive a valid key message in six start attempts the PCM will disable the starter relay until a valid key message is received.

Possible causes:

- > Open or shorted CCD Bus circuit(s)
- > Failed SKIM module
- > Failed PCM
- > Connector terminals
- > Connector wires


80b118e6

FIG. 1

TEST TC-226A

REPAIRING - NO CCD BUS MESSAGE RECEIVED FROM SKIM

Perform TEST DTC Before Proceeding



***Perform Verification TEST VER-1A.**

****Check connectors - Clean / repair as necessary.**

TJ BODY




FIG. 1

80b6f0cc

XJ BODY





FIG. 2

80b6f0d2




***Perform Verification TEST VER-1A.**

****Check connectors - Clean / repair as necessary.**


TEST TC-232A

REPAIRING - INVALID OR WRONG KEY MESSAGE FROM SKIM

Perform TEST DTC Before Proceeding

TJ BODY

80b6f0cc

XJ BODY

80b6f0d2

Name of code: Invalid or Wrong Key Message From SKIM**When Monitored:** With ignition on.**Set Condition:** The PCM does not receive a valid key message from the SKIM module.

Theory of operation: At ignition on, the SKIM module sends a message to the PCM verifying the correct ignition key. If the PCM receives a correct message, it will allow the engine to start and continue to run. If the PCM does not receive a message or receives an incorrect message the PCM will allow the engine to start and run for two seconds. If the PCM does not receive a valid key message in six start attempts the PCM will disable the starter relay until a valid key message is received.

Possible causes:

- > Ignition key not programmed
- > Wrong ignition key
- > Incorrect VIN stored in PCM
- > Failed SKIM module
- > Failed PCM


80b118e7

FIG. 1

TEST TC-232A

REPAIRING - INVALID OR WRONG KEY MESSAGE FROM SKIM

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-1A.**


****Check connectors - Clean / repair as necessary.**

TEST TC-232A

REPAIRING - INVALID OR WRONG KEY MESSAGE FROM SKIM

TJ BODY

80b6f0cc

XJ BODY

80b6f0d2

Name of code: Invalid or Wrong Key Message From SKIM**When Monitored:** With ignition on.**Set Condition:** The PCM does not receive a valid key message from the SKIM module.

Theory of operation: At ignition on, the SKIM module sends a message to the PCM verifying the correct ignition key. If the PCM receives a correct message, it will allow the engine to start and continue to run. If the PCM does not receive a message or receives an incorrect message the PCM will allow the engine to start and run for two seconds. If the PCM does not receive a valid key message in six start attempts the PCM will disable the starter relay until a valid key message is received.

Possible causes:


- > Ignition key not programmed
- > Wrong ignition key
- > Incorrect VIN stored in PCM
- > Failed SKIM module
- > Failed PCM

80b118e7

FIG. 1

TEST TC-232A

REPAIRING - INVALID OR WRONG KEY MESSAGE FROM SKIM



***Perform Verification TEST VER-1A.**

****Check connectors - Clean / repair as necessary.**

TEST TC-235A

REPAIRING - OIL PRESSURE SENSOR LOW EXCEEDED

Perform TEST DTC Before Proceeding

TJ/XJ BODY**Name of code:** Oil Pressure Sensor Low Exceeded**When monitored:** With the ignition switch on.**Set condition:** The PCM detects voltage on the oil pressure sensor signal circuit below 0.1 volts.


Theory of operation: The sensor consists of dual ceramic plates that vary resistance with applied oil pressure. The PCM sends a 5.0 volt supply to the sensor. The change in signal voltage is proportional to the change in distance between the ceramic plates (which varies with applied oil pressure). The PCM uses this input to determine oil pressure and provides this information to the instrument cluster for oil pressure gauge operation. The signal voltage is provided at PCM cavity B23. Ground is provided at PCM cavity A4. The 5-volt supply is provided at PCM cavity A17.

Possible cause:

- > Sensor signal circuit shorted to ground
- > Failed oil pressure sensor
- > Failed PCM
- > Connector terminals
- > Connector wires

80b76fed

FIG. 1

TJ/XJ BODY


80b76fef

FIG. 2

TEST TC-235A

REPAIRING - OIL PRESSURE SENSOR LOW EXCEEDED

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ/XJ BODY

ENGINE OIL PRESSURE SENSOR CONNECTOR




CAV	COLOR	FUNCTION
1	VT/OR	5-VOLT SUPPLY (TJ)
1	OR	5-VOLT SUPPLY (XJ)
2	GY/YL	OIL PRESSURE SENSOR SIGNAL
3	BR/YL	SENSOR GROUND

80b6b37f

FIG. 1

TEST TC-235A

CONTINUED - REPAIRING - OIL PRESSURE SENSOR LOW EXCEEDED



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TEST TC-236A

REPAIRING OIL PRESSURE SENSOR HIGH EXCEEDED


Perform TEST DTC Before Proceeding

TJ/XJ BODY**Name of code:** Oil Pressure Sensor High Exceeded**When monitored:** With the ignition switch on.**Set condition:** The PCM detects voltage on the oil pressure sensor signal circuit above 4.8 volts.**Theory of operation:** The sensor consists of dual ceramic plates that vary resistance with applied oil pressure. The PCM sends a 5.0 volt supply to the sensor. The change in signal voltage is proportional to the change in distance between the ceramic plates (which varies with applied oil pressure). The PCM uses this input to determine oil pressure and provides this information to the instrument cluster for oil pressure gauge operation. The signal voltage is provided at PCM cavity B23. Ground is provided at PCM cavity A4. The 5-volt supply is provided at PCM cavity A17.**Possible cause:**

- > Sensor signal circuit shorted to voltage
- > Sensor signal circuit open
- > Sensor ground circuit open
- > Failed oil pressure sensor
- > Failed PCM
- > Connector terminals
- > Connector wires

80b76fee

FIG. 1

TJ/XJ BODY**POWERTRAIN
CONTROL
MODULE****OIL
PRESSURE
SENSOR**


80b76fef

FIG. 2

TEST TC-236A

REPAIRING OIL PRESSURE SENSOR HIGH EXCEEDED

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ/XJ BODY


ENGINE OIL PRESSURE SENSOR CONNECTOR



CAV	COLOR	FUNCTION
1	VT/OR	5-VOLT SUPPLY (TJ)
1	OR	5-VOLT SUPPLY (XJ)
2	GY/YL	OIL PRESSURE SENSOR SIGNAL
3	BR/YL	SENSOR GROUND

80b6b37f

FIG. 1




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ/XJ BODY

ENGINE OIL PRESSURE SENSOR CONNECTOR



CAV	COLOR	FUNCTION
1	VT/OR	5-VOLT SUPPLY (TJ)
1	OR	5-VOLT SUPPLY (XJ)
2	GY/YL	OIL PRESSURE SENSOR SIGNAL
3	BR/YL	SENSOR GROUND


80b6b37f

FIG. 1


TJ/XJ BODY

BLACK

POWERTRAIN CONTROL MODULE CONNECTORS




WHITE



CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A17	OR	5-VOLT SUPPLY
B24	GY/YL	OIL PRESSURE SENSOR SIGNAL


ENGINE OIL PRESSURE SENSOR CONNECTOR



CAV	COLOR	FUNCTION
1	VT/OR	5-VOLT SUPPLY (TJ)
1	OR	5-VOLT SUPPLY (XJ)
2	GY/YL	OIL PRESSURE SENSOR SIGNAL
3	BR/YL	SENSOR GROUND

80b6b38a

FIG. 2



*Perform Verification TEST VER-2A.

**Check connectors - Clean / repair as necessary.

SENTRY KEY IMMOBILIZER SYSTEM

TEST SK-1A	IDENTIFYING SENTRY KEY IMMOBILIZER SYSTEM	
Perform TEST DTC Before Proceeding		
DIAGNOSTIC TROUBLE CODE (DTC) DISPLAYED	DIAGNOSTIC TEST	
ANTENNA FAILURE	**	
COP FAILURE	**	
EEPROM FAILURE	**	
EMS STATUS FAILURE	SK-2A	
INTERNAL FAULT	**	
RAM FAILURE	**	
ROLLING CODE FAILURE	SK-3A	
SERIAL LINK EXTENERAL FAULT	SK-4A	
SERIAL LINK INTERNAL	**	
STACK OVERFLOW FAILURE	**	
TRANSPONDER COMMUNICATION FAILURE	SK-5A	
TRANSPONDER CRC (CYCLE REDUNDANCY CHECK) FAILURE	SK-6A	
TRANSPONDER ID MISMATCH	SK-7A	
TRANSPONDER RESPONSE MISMATCH	SK-8A	
VIN MISMATCH	SK-9A	
<p>**These trouble codes indicate an internal SKIM fault. Using the DRB, clear SKIM trouble code(s). Perform several key cycles, leaving the key on for a minimum of 30 seconds per cycle. Using the DRB, read SKIM trouble codes. If the trouble code is present, replace the SKIM.</p> <p>NOTE: An intermittent start and stall condition accompanied with a transponder DTC can be caused by the presence of a non-programmed key or key programmed to another vehicle, near the SKIM antenna (ignition halo). This can occur if the customer has a key holder (ring) that contains more than one key equipped with a transponder chip.</p> <p>After replacement of the Sentry Key Immobilizer Module (SKIM) see GENERAL INFORMATION SECTION 8.0 for SKIM initialization.</p> <p>NOTE: For all component locations, REFER TO GENERAL INFORMATION Section 4.0 in this manual.</p>		

TEST SK-1A

IDENTIFYING SENTRY KEY IMMOBILIZER SYSTEM

Perform TEST DTC Before Proceeding

NOTE: The Sentry Key Immobilizer System (SKIS) diagnosis may require usage of the customer's additional keys to verify the cause of the system failure. In the event that the Sentry Key Immobilizer Module (SKIM) needs replacing, all of the keys previously programmed into the SKIM's memory must be programmed into the new SKIM. **THEREFORE IT IS IMPORTANT THAT ALL OF THE CUSTOMER'S KEYS PROGRAMMED FOR THE VEHICLE BE OBTAINED PRIOR TO BEGINNING VEHICLE DIAGNOSIS.**

NOTE: It is necessary to obtain the four-digit Personal Identification Number (PIN) from the customer or the vehicle invoice. The PIN is required to perform certain SKIM tasks using the DRB.

NOTE: It is very important that the PCM is programmed with the correct Vehicle Identification Number (VIN). Incorrect VIN programming may result in incorrect diagnosis and unnecessary component replacement. Use the DRB to verify the correct VIN and country code in the SKIM.

1. The battery must be fully charged for any test in this manual.
2. Attempt to start the engine. Crank for up to 10 seconds if necessary.
3. Connect the DRB to the diagnostic connector and select "Theft Alarm" then "SKIM".
If the DRB displays "No Response"perform test 1B

NOTE: If the DRB screen is blank or has a DRB error message displayed, go to **General Information Section 3.5** in this manual.


4. With the DRB, read and record SKIM trouble codes.
5. If diagnostic trouble code(s) are displayed, refer to the diagnostic trouble code list on the next page for the appropriate test.

TEST SK-1B

SKIM COMMUNICATION


Perform TEST SK-1A Before Proceeding

TJ BODY



80b6f0cc


XJ BODY



80b6f0d2

TJ BODY

SKIM MODULE HARNESS CONNECTOR




CAV	COLOR	FUNCTION
1	TN/BK	FUSED BATTERY SUPPLY
2	BK	GROUND
3	RD/LG	FUSED IGNITION SWITCH OUTPUT
5	WT/BK	CCD BUS (-)
6	VT/BR	CCD BUS (+)

80b11874

FIG. 1

XJ BODY

SKIM MODULE HARNESS CONNECTOR



CAV	COLOR	FUNCTION
1	DB/GY	FUSED BATTERY SUPPLY
2	BK/LG	GROUND
3	WT/BK	FUSED IGNITION SWITCH OUTPUT
5	WT/BK	CCD BUS (-)
6	VT/BR	CCD BUS (+)


80b11875

FIG. 2

TEST SK-1B

SKIM COMMUNICATION

Perform TEST SK-1A Before Proceeding



***Perform Verification TEST VER-1A.**


****Check connectors - Clean / repair as necessary.**

TEST SK-2A

REPAIRING - PCM STATUS FAILURE


Perform TEST SK-1A Before Proceeding

TJ BODY



80b6f0cc

XJ BODY



80b6f0d2

Name of code: PCM Status Failure

When monitored: With the ignition on.

Set condition: The SKIM does not receive an expected PCM Status CCD BUS message from the PCM within the last 20 seconds.

Theory of operation: The PCM status message informs the SKIM whether the PCM has received a "valid key" or "invalid key" message from the SKIM. The PCM broadcasts the PCM status every 2.7 seconds on the CCD BUS.

Possible causes:

- > CCD BUS circuits open, shorted to voltage or shorted to ground
- > Failed SKIM
- > Failed PCM


FIG. 1

80b5cc6e

TEST SK-2A

REPAIRING - PCM STATUS FAILURE


Perform TEST SK-1A Before Proceeding



***Perform Verification TEST VER-1A.**


****Check connectors - Clean / repair as necessary.**

TJ BODY




80b6f0cc

XJ BODY



80b6f0d2



*Perform Verification TEST VER-1A.


**Check connectors - Clean / repair as necessary.

TEST SK-3A

REPAIRING - ROLLING CODE FAILURE


Perform TEST SK-1A Before Proceeding

TJ BODY



80b6f0cc

XJ BODY



80b6f0d2

Name of code: Rolling Code Failure

When monitored: With the ignition on.

Set condition: The SKIM does not receive an expected EMS status CCD BUS message from the PCM within 3.5 seconds of transmitting a "valid key" message to the PCM.

Theory of operation: After determining the ignition key is a valid key, the SKIM sends a coded "valid key" CCD BUS message to the PCM. The SKIM expects a CCD BUS message acknowledgment from the PCM.

Possible cause:

- > CCD BUS circuits open, shorted to voltage or shorted to ground
- > Failed SKIM
- > Failed PCM


FIG. 1

80b5cc6f

TEST SK-3A

REPAIRING - ROLLING CODE FAILURE


Perform TEST SK-1A Before Proceeding



***Perform Verification TEST VER-1A.**


****Check connectors - Clean / repair as necessary.**

TJ BODY



80b6f0cc

XJ BODY



80b6f0d2

Name of code: Rolling Code Failure

When monitored: With the ignition on.


Set condition: The SKIM does not receive an expected EMS status CCD BUS message from the PCM within 3.5 seconds of transmitting a "valid key" message to the PCM.

Theory of operation: After determining the ignition key is a valid key, the SKIM sends a coded "valid key" CCD BUS message to the PCM. The SKIM expects a CCD BUS message acknowledgment from the PCM.

Possible cause:

- > CCD BUS circuits open, shorted to voltage or shorted to ground
- > Failed SKIM
- > Failed PCM

80b5cc6f



*Perform Verification TEST VER-1A.


**Check connectors - Clean / repair as necessary.

TEST SK-4A

REPAIRING - SERIAL LINK EXTERNAL FAILURE


Perform TEST SK-1A Before Proceeding

TJ BODY



80b6f0cc

XJ BODY



80b6f0d2

Name of code: Serial Link External Fault

When monitored: With the ignition on.

Set condition: The SKIM does not receive an expected CCD BUS message transmission acknowledgment from the PCM after three transmit attempts.

Theory of operation: The SKIM expects a CCD BUS message acknowledgment from the PCM on the BUS during its communication process.

Possible cause:

- > CCD BUS circuits open, shorted to voltage or shorted to ground
- > Failed SKIM
- > Failed PCM


FIG. 1

80b5cc70

TEST SK-4A

REPAIRING - SERIAL LINK EXTERNAL FAILURE


Perform TEST SK-1A Before Proceeding



***Perform Verification TEST VER-1A.**


****Check connectors - Clean / repair as necessary.**

TJ BODY




80b6f0cc

XJ BODY



80b6f0d2



*Perform Verification TEST VER-1A.


**Check connectors - Clean / repair as necessary.

TEST SK-5A

REPAIRING - TRANSPONDER COMMUNICATION FAILURE


Perform TEST SK-1A Before Proceeding

TJ BODY



80b6f0cc

XJ BODY



80b6f0d2

Name of code: Transponder Communication Failure

When monitored: With the ignition on and during key programming operation.


Set condition: The SKIM fails to receive a valid message from the transponder after five consecutive read attempts.

Theory of operation: When the ignition is turned on or during key programming, the SKIM attempts to power up the transponder. The SKIM makes up to five attempts to communicate with the transponder. If the SKIM does not receive a response from the transponder, no further communication is attempted and a code is stored in memory.

Possible cause:

- > Failed transponder
- > Invalid ignition key
- > Electro-magnetic interference
- > Failed SKIM

80b5cc71




80b6b145

FIG. 1

TEST SK-5A


REPAIRING - TRANSPONDER COMMUNICATION FAILURE

Perform TEST SK-1A Before Proceeding




***Perform Verification TEST VER-1A.**

****Check connectors - Clean / repair as necessary.**



80b6b145



*Perform Verification TEST VER-1A.


**Check connectors - Clean / repair as necessary.

TEST SK-6A

REPAIRING - TRANSPONDER CRC (CYCLIC REDUNDANCY CHECK) FAILURE


Perform TEST SK-1A Before Proceeding

TJ BODY



80b6f0cc

XJ BODY



80b6f0d2

Name of code: Transponder CRC (Cyclic Redundancy Check) Failure

When monitored: With the ignition on and during key programming operation.


Set condition: The SKIM receives five consecutive transponder messages that are correctly formatted but contain invalid data.

Theory of operation: When the ignition is turned on or during key programming, the SKIM attempts to power up the transponder. The SKIM makes up to five attempts to communicate with the transponder. The SKIM checks for proper communication format and valid data from the transponder.

Possible cause:

- > Failed transponder
- > Failed SKIM
- > Invalid key
- > Electro-magnetic interference

80b5cc72




80b6b145

FIG. 1

TEST SK-6A


REPAIRING - TRANSPONDER CRC (CYCLIC REDUNDANCY CHECK) FAILURE

Perform TEST SK-1A Before Proceeding




***Perform Verification TEST VER-1A.**

****Check connectors - Clean / repair as necessary.**



80b6b145



*Perform Verification TEST VER-1A.


**Check connectors - Clean / repair as necessary.

TEST SK-7A

REPAIRING - TRANSPONDER ID MISMATCH


Perform TEST SK-1A Before Proceeding

TJ BODY



80b6f0cc

XJ BODY



80b6f0d2

Name of code: Transponder ID Mismatch

When monitored: With the ignition on and during key programming operation.


Set condition: The SKIM receives a transponder ID that does not match any ID stored in SKIM memory.

Theory of operation: When the ignition is turned on or during key programming, the SKIM attempts to power up the transponder. The SKIM makes up to three attempts to communicate with the transponder. The SKIM checks for proper communication format and valid data from the transponder.

Possible cause:

- > Invalid key
- > Failed transponder
- > Failed SKIM

80b5cc73




80b6b145

FIG. 1

TEST SK-7A


REPAIRING - TRANSPONDER ID MISMATCH

Perform TEST SK-1A Before Proceeding




***Perform Verification TEST VER-1A.**

****Check connectors - Clean / repair as necessary.**



80b6b145



***Perform Verification TEST VER-1A.**


****Check connectors - Clean / repair as necessary.**

TEST SK-8A

REPAIRING - TRANSPONDER RESPONSE MISMATCH


Perform TEST SK-1A Before Proceeding

TJ BODY



80b6f0cc

XJ BODY



80b6f0d2

Name of code: Transponder Response Mismatch

When monitored: With the ignition on and during key programming operation.


Set condition: The transponder response from the "Crypto" algorithm fails to match the SKIM "Crypto" results.

Theory of operation: When the ignition is turned on or during key programming the SKIM attempts to power up the transponder. The SKIM makes up to three attempts to communicate with the transponder. The SKIM checks for proper communication format and valid data from the transponder.

Possible cause:

- > Invalid key
- > Failed transponder
- > Failed SKIM

80b5cc74




80b6b145

FIG. 1

TEST SK-8A


REPAIRING - TRANSPONDER RESPONSE MISMATCH

Perform TEST SK-1A Before Proceeding




***Perform Verification TEST VER-1A.**

****Check connectors - Clean / repair as necessary.**



80b6b145



*Perform Verification TEST VER-1A.


**Check connectors - Clean / repair as necessary.

TEST SK-9A

REPAIRING - VIN MISMATCH


Perform TEST SK-1A Before Proceeding

TJ BODY



80b6f0cc

XJ BODY



80b6f0d2

Name of code: VIN Mismatch

When monitored: With the ignition on.

Set condition: The VIN received from the PCM does not match the VIN stored in the SKIM EEPROM.

Theory of operation: The PCM broadcasts the Vehicle Identification Number (VIN) on the CCD BUS. The SKIM receives and compares this number to the number stored in SKIM EEPROM.

Possible cause:

- > Incorrect VIN stored in PCM memory
- > Incorrect VIN stored in SKIM memory
- > Failed SKIM


FIG. 1

80b5cc77

TEST SK-9A

REPAIRING - VIN MISMATCH


Perform TEST SK-1A Before Proceeding



***Perform Verification TEST VER-1A.**


****Check connectors - Clean / repair as necessary.**

TJ BODY




80b6f0cc

XJ BODY



80b6f0d2



*Perform Verification TEST VER-1A.

**Check connectors - Clean / repair as necessary.

TEST NTC-1A

NO TROUBLE CODE TEST MENU

Perform TEST DTC Before Proceeding

NOTE: For all component locations, REFER TO GENERAL INFORMATION SECTION 4.0 in this manual.

First, check all Technical Service Bulletins that relate to this problem. Perform corrective actions if indicated, otherwise continue.

Second, read Diagnostics Trouble Codes, and repair any Diagnostic Trouble codes before continuing.

1. **No Trouble Code Complete Test** (non-monitored circuits and monitored circuits). Perform Tests NTC-2A through NTC-19A in sequence for Driveability problem.
2. **No Trouble Code Quick Individual Test.** If you suspect a symptom is directly related to a component or system perform the associated NTC-Test(s) individually. Symptom check cannot be used properly unless the Driveability problem actually happens while the vehicle is being tested. Review of the appropriate General Information sections is essential before attempting to diagnose any symptom. Return to No Trouble Code Menu if driveability problem still exists, or perform No Trouble Code Complete Test.
3. **No Trouble Code** Tests NTC-20A through NTC-27A are intended to be performed according to the component or system malfunction.

NO TROUBLE CODE MENU

CHECKING SECONDARY IGNITION AND TIMING	NTC-2A
CHECKING THE PCM POWER AND GROUND CIRCUITS	NTC-3A
CHECKING THE ENGINE VACUUM	NTC-4A
CHECKING THE FUEL DELIVERY	NTC-5A
CHECKING THE COOLANT SENSOR	NTC-6A
CHECKING THE THROTTLE POSITION SENSOR	NTC-7A
CHECKING THE MAP SENSOR	NTC-8A
CHECKING THE OXYGEN SENSOR SWITCHING	NTC-10A
CHECKING THE OXYGEN SENSOR HEATER	NTC-11A
CHECKING THE IDLE AIR CONTROL MOTOR	NTC-12A
CHECKING ENGINE MECHANICAL	NTC-13A
CHECKING THE BATTERY TEMP SENSOR	NTC-15A
CHECKING THE EVAPORATIVE EMISSION SYSTEM	NTC-17A
CHECKING THE INTAKE AIR TEMP SENSOR	NTC-19A
CHECKING THE PARK/NEUTRAL POSITION SWITCH	NTC-20A
CHECKING THE OIL PRESSURE SENDING UNIT	NTC-21A
CHECKING THE FUEL LEVEL SENSOR	NTC-25A
CHECKING THE A/C SYSTEM	NTC-26A
CHECKING THE RADIATOR FAN OPERATION	NTC-27A


TEST NTC-1A	NO TROUBLE CODE TEST MENU
Perform TEST DTC Before Proceeding	
SYMPTOM	DIAGNOSTIC TEST ROUTINE
HARD START	NTC-4A, 5A, 6A, 7A, 8A, 9A, 10A, 12A, 13A, 17A, 18A, 19A
START AND STALL	NTC-3A, 5A, 6A, 7A, 8A, 9A, 12A
HESITATION/SAG/STUMBLE	NO TROUBLE CODE COMPLETE TEST (STEP 1)
SURGE	NTC-3A, 5A, 6A, 7A, 8A, 9A, 10A, 12A, 17A
LACK OF POWER/SLUGGISH	NTC-3A, 5A, 6A, 7A, 8A, 9A, 10A, 12A, 18A
SPARK KNOCK/ DETONATION	NTC-3A, 5A, 6A, 7A, 8A, 9A, 10A, 12A, 17A
CUT OUTS/MISSES	NTC-3A, 5A, 9A, 10A, 18A
BACKFIRE/POPBACK	NTC-3A, 5A, 8A, 9A, 10A, 18A
RUNS ROUGH/UNSTABLE/ ERRATIC IDLE	NO TROUBLE CODE COMPLETE TEST (STEP 1)
POOR FUEL ECONOMY	NO TROUBLE CODE COMPLETE TEST (STEP 1)

TEST NTC-2A

CHECKING SECONDARY IGNITION AND TIMING

Perform TEST NTC-1A Before Proceeding

2.5L




TYPICAL SCOPE PATTERN

2460401

FIG. 1

4.0L




TYPICAL SCOPE PATTERN

3250303

FIG. 2

TEST NTC-2A **CHECKING SECONDARY IGNITION AND TIMING**

Perform TEST NTC-1A Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


TEST NTC-3A

CHECKING - THE PCM POWER AND GROUND CIRCUITS

Perform TEST NTC-1A Before Proceeding

TJ BODY


POWERTRAIN CONTROL MODULE



80b76ef3

XJ BODY


POWERTRAIN CONTROL MODULE



80b76ef4

TJ BODY

POWERTRAIN CONTROL MODULE BLACK CONNECTOR




CAV	COLOR	FUNCTION
A2	DB	IGNITION SWITCH OUTPUT
A4	BR/YL	SENSOR GROUND
A22	RD/WT	FUSED B(+)
A31	BK/TN	GROUND
A32	BK/TN	GROUND

80b76ef5

FIG. 1

XJ BODY


POWERTRAIN CONTROL MODULE BLACK CONNECTOR



CAV	COLOR	FUNCTION
A2	DB/WT	IGNITION SWITCH OUTPUT
A4	BR/YL	SENSOR GROUND
A22	DG/BK	FUSED B(+)
A31	BK/TN	GROUND
A32	BK/TN	GROUND

80aafae7


FIG. 2



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

Perform TEST NTC-1A Before Proceeding




**NORMAL READING
RANGE AT IDLE
@ SEA LEVEL**

0920605

FIG. 1

TEST NTC-4A **CHECKING THE ENGINE VACUUM**


Perform TEST NTC-1A Before Proceeding



**Perform Verification TEST VER-2A.*

***Check connectors - Clean / repair as necessary.*


Perform TEST NTC-1A Before Proceeding



1190305

TEST NTC-5A CHECKING THE FUEL DELIVERY

Perform TEST NTC-1A Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


TEST NTC-6A

CHECKING THE COOLANT SENSOR

Perform TEST NTC-1A Before Proceeding

TJ/XJ BODY

**POWERTRAIN
CONTROL
MODULE**




BR/YL
SENSOR GROUND


TO OTHER
SENSORS

TN/BK
ENGINE COOLANT TEMPERATURE
SENSOR SIGNAL

**ENGINE
COOLANT
TEMPERATURE
SENSOR**



80b0d638



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

TEST NTC-7A

CHECKING THE THROTTLE POSITION SENSOR

Perform TEST NTC-1A Before Proceeding


TJ/XJ BODY



80b098a4

TJ/XJ BODY

THROTTLE POSITION SENSOR CONNECTOR




CAV	COLOR	FUNCTION
1	BR/YL	SENSOR GROUND
2	OR/DB	TP SENSOR SIGNAL
3	OR	5-VOLT SUPPLY

80b610e7

FIG. 1

TEST NTC-7A CHECKING THE THROTTLE POSITION SENSOR

Perform TEST NTC-1A Before Proceeding



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

TEST NTC-8A

CHECKING THE MAP SENSOR

Perform TEST NTC-1A Before Proceeding


TJ/XJ BODY



80a4d2e2

TEST NTC-8A **CHECKING THE MAP SENSOR**

Perform TEST NTC-1A Before Proceeding



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

TEST NTC-10A CHECKING THE OXYGEN SENSOR SWITCHING

Perform TEST NTC-1A Before Proceeding

TJ BODY


POWERTRAIN CONTROL MODULE



80b118a1

XJ BODY


POWERTRAIN CONTROL MODULE



80b118a2

TEST NTC-10A CHECKING THE OXYGEN SENSOR SWITCHING

Perform TEST NTC-1A Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TEST NTC-10B

CHECKING THE OXYGEN SENSOR SWITCHING

Perform TEST NTC-10A Before Proceeding





FIG. 1

0920606

TJ 1/1 O2


BLACK



POWERTRAIN CONTROL MODULE CONNECTORS

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A24	BK/DG	UPSTREAM OXYGEN SENSOR SIGNAL
C12	DG/PK	ASD RELAY OUTPUT

GREY



UPSTREAM OXYGEN SENSOR CONNECTOR (HARNESS SIDE)


CAV	COLOR	FUNCTION
1	OR/DG	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	BK/DG	OXYGEN SENSOR SIGNAL

80b76ec5

FIG. 2

XJ 1/1 O2


BLACK



POWERTRAIN CONTROL MODULE CONNECTORS

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A24	BK/DG	UPSTREAM OXYGEN SENSOR SIGNAL
C12	DG/OR	ASD RELAY OUTPUT

GREY



UPSTREAM OXYGEN SENSOR CONNECTOR (HARNESS SIDE)


CAV	COLOR	FUNCTION
1	DG/WT	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	BK/DG	OXYGEN SENSOR SIGNAL

80b76ec4

FIG. 3

TJ 1/2 O2


BLACK



POWERTRAIN CONTROL MODULE CONNECTORS

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A25	TN/WT	DOWNSTREAM OXYGEN SENSOR SIGNAL
C12	DG/PK	ASD RELAY OUTPUT

GREY



DOWNSTREAM OXYGEN SENSOR CONNECTOR (HARNESS SIDE)

CAV	COLOR	FUNCTION
1	OR/DG	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	TN/WT	DOWNSTREAM OXYGEN SENSOR SIGNAL




80b118a8

FIG. 4

XJ 1/2 O2


BLACK



POWERTRAIN CONTROL MODULE CONNECTORS

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A25	TN/WT	DOWNSTREAM OXYGEN SENSOR SIGNAL
C12	DG/OR	ASD RELAY OUTPUT

GREY



DOWNSTREAM OXYGEN SENSOR CONNECTOR (HARNESS SIDE)

CAV	COLOR	FUNCTION
1	DG/WT	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	TN/WT	DOWNSTREAM OXYGEN SENSOR SIGNAL




80b118a9

FIG. 5

TEST NTC-10B

CHECKING THE OXYGEN SENSOR SWITCHING

Perform TEST NTC-10A Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ BODY


POWERTRAIN CONTROL MODULE



80b118a1

XJ BODY


POWERTRAIN CONTROL MODULE



80b118a2

TEST NTC-10B

CONTINUED - CHECKING THE OXYGEN SENSOR SWITCHING




**Perform Verification TEST VER-2A.*

***Check connectors - Clean / repair as necessary.*

TEST NTC-11A CHECKING THE OXYGEN SENSOR HEATER


Perform TEST NTC-1A Before Proceeding

**TJ BODY
POWERTRAIN
CONTROL
MODULE**



80b118a1




**XJ BODY
POWERTRAIN
CONTROL
MODULE**



80b118a2

TJ 1/1 O2

BLACK



80b76ec5

**POWERTRAIN
CONTROL MODULE
CONNECTORS**

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A24	BK/DG	UPSTREAM OXYGEN SENSOR SIGNAL
C12	DG/PK	ASD RELAY OUTPUT




**UPSTREAM OXYGEN
SENSOR CONNECTOR
(HARNES SIDE)**

CAV	COLOR	FUNCTION
1	OR/DG	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	BK/DG	OXYGEN SENSOR SIGNAL

FIG. 1

XJ 1/1 O2

BLACK



80b76ec4

**POWERTRAIN
CONTROL MODULE
CONNECTORS**

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A24	BK/DG	UPSTREAM OXYGEN SENSOR SIGNAL
C12	DG/OR	ASD RELAY OUTPUT




**UPSTREAM OXYGEN
SENSOR CONNECTOR
(HARNES SIDE)**

CAV	COLOR	FUNCTION
1	DG/WT	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	BK/DG	OXYGEN SENSOR SIGNAL

FIG. 2

TJ 1/2 O2

BLACK



80b118a8

**POWERTRAIN
CONTROL MODULE
CONNECTORS**

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A25	TN/WT	DOWNSTREAM OXYGEN SENSOR SIGNAL
C12	DG/PK	ASD RELAY OUTPUT




**DOWNSTREAM OXYGEN
SENSOR CONNECTOR
(HARNES SIDE)**

CAV	COLOR	FUNCTION
1	OR/DG	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	TN/WT	DOWNSTREAM OXYGEN SENSOR SIGNAL

FIG. 3

XJ 1/2 O2

BLACK



80b118a9

**POWERTRAIN
CONTROL MODULE
CONNECTORS**

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A25	TN/WT	DOWNSTREAM OXYGEN SENSOR SIGNAL
C12	DG/OR	ASD RELAY OUTPUT


**DOWNSTREAM OXYGEN
SENSOR CONNECTOR
(HARNES SIDE)**

CAV	COLOR	FUNCTION
1	DG/WT	ASD RELAY OUTPUT
2	BK	GROUND (HEATER)
3	BR/YL	SENSOR GROUND
4	TN/WT	DOWNSTREAM OXYGEN SENSOR SIGNAL

FIG. 4

TEST NTC-11A CHECKING THE OXYGEN SENSOR HEATER

Perform TEST NTC-1A Before Proceeding



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

TEST NTC-12A

CHECKING THE IDLE AIR CONTROL MOTOR


Perform TEST NTC-1A Before Proceeding

TJ/XJ BODY



**POWERTRAIN
CONTROL MODULE
BLACK CONNECTOR**

CAV	COLOR	FUNCTION
A10	YL/BK	IAC #3 DRIVER
A11	BR/WT	IAC #2 DRIVER
A19	GY/RD	IAC #4 DRIVER
A20	VT/BK	IAC #1 DRIVER



**IDLE AIR
CONTROL MOTOR
CONNECTOR**

CAV	COLOR	FUNCTION
1	VT/BK	IAC #1 DRIVER
2	BR/WT	IAC #2 DRIVER
3	YL/BK	IAC #3 DRIVER
4	GY/RD	IAC #4 DRIVER

80b898b3


Theory of operation: The idle air control motor is used by the PCM to help regulate idle speed. The motor controls the amount of air allowed to bypass the throttle blade. The PCM controls the motor using four driver circuits to position the stepper motor.

2640605

TEST NTC-12A

CHECKING THE IDLE AIR CONTROL MOTOR

Perform TEST NTC-1A Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TEST NTC-13A

CHECKING THE ENGINE MECHANICAL

Perform TEST NTC-1A Before Proceeding

The components and systems that you have checked before this are operating properly. Here are additional non-monitored components or systems to check, that could cause a driveability problem.

1. **DISTRIBUTOR POSITION** — must be within specifications
2. **ENGINE VACUUM** — must be at least 13 inches in neutral (see below) †
3. **ENGINE VALVE TIMING** — must be within specifications
4. **ENGINE COMPRESSION** — must be within specifications
5. **ENGINE EXHAUST SYSTEM** — must be free of any restrictions
6. **ENGINE PCV SYSTEM** — must flow freely
7. **ENGINE DRIVE SPROCKET** — must be properly positioned
8. **TORQUE CONVERTER STALL SPEED** — must be within specifications (auto only)
9. **POWER BRAKE BOOSTER** — no internal vacuum leaks
10. **FUEL** — must be free of contamination
11. **FUEL INJECTOR** — plugged or restricted injector; control wire not connected to correct injector

NOTE: If you came to this test from the oxygen sensor, and the rich or lean condition is not caused by one of the first items above, replace the powertrain control module and perform TEST VER-2A (Road Test Verification)

Checking Distributor Position With DRBIII®

§Connect the DRB to the data link connector and select SET SYNC from the menu. **WARNING:** The following test will be performed with the engine running: avoid contact with rotating components.

Start the engine and observe the DRB display. When the distributor is correctly positioned, the IN RANGE message should appear along with 0°. If the distributor needs to be adjusted, loosen the distributor hold-down clamp bolt. Rotate the distributor until reading is as close to 0° as possible and the IN RANGE message displayed. Tighten the clamp bolt to 22.5 N·m (200 in. lbs.) torque.

NOTE: Setting the distributor position does not adjust the ignition timing. Ignition timing valves are determined by the powertrain control module:


† The readings below are only indicators of possible mechanical engine problems.



**NORMAL
READING
RANGE
AT IDLE**



**BLOWN
HEAD
GASKET
AT IDLE**



**NORMAL
READING
RAPID
ACCELERATION/
DECELERATION**



**WORN
RINGS OR
DILUTED OIL
RAPID
ACCELERATION/
DECELERATION**



**LATE VALVE
TIMING,
VACUUM
LEAK AT
IDLE**



**RESTRICTED
EXHAUST
(DROPS
TOWARD
ZERO AS
ENGINE RPM
INCREASES)**



**POOR
VALVE
SEATING
AT IDLE**



**STICKING
VALVE
AT IDLE**



**WORN VALVE
GUIDES
(STEADIES AS
ENGINE
SPEED
INCREASES)**




**WORN VALVE
SPRINGS
(MORE
PRONOUNCED
AS ENGINE
SPEED
INCREASES)**

TEST NTC-15A

CHECKING BATTERY TEMP SENSOR

Perform TEST NTC-1A Before Proceeding




80b118ad

TEST NTC-15A

CHECKING BATTERY TEMP SENSOR

Perform TEST NTC-1A Before Proceeding



*Perform Verification TEST VER-2A.


**Check connectors - Clean / repair as necessary.

TEST NTC-17A CHECKING THE EVAPORATIVE EMISSION SYSTEM

Perform TEST NTC-1A Before Proceeding

TJ BODY

POWERTRAIN CONTROL MODULE



PK/BK
EVAP SOLENOID CONTROL

RD/LG
FUSED IGNITION SWITCH OUTPUT

TO
IGNITION
SWITCH

EVAP SOLENOID





FIG. 1

80d09ab9

XJ BODY

POWERTRAIN CONTROL MODULE



PK/BK
Evap Solenoid Control

WT
Fused Ignition Switch Output

15 AMP

TO
IGNITION
SWITCH

EVAP SOLENOID





FIG. 2

80b6f0d5

TEST NTC-17A


CHECKING THE EVAPORATIVE EMISSION SYSTEM

Perform TEST NTC-1A Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**




80b27d34



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

Perform TEST NTC-17A Before Proceeding




80b27d34

TEST NTC-17B

CHECKING THE EVAPORATIVE EMISSION SYSTEM

Perform TEST NTC-17A Before Proceeding



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

TEST NTC-19A

CHECKING THE INTAKE AIR TEMPERATURE SENSOR

Perform TEST NTC-1A Before Proceeding


TJ BODY



80524e3c

FIG. 1

XJ BODY




80a87223

FIG. 2

TEST NTC-19A

CHECKING THE INTAKE AIR TEMPERATURE SENSOR

Perform TEST NTC-1A Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TEST NTC-20A CHECKING THE PARK/NEUTRAL POSITION SWITCH

Perform TEST NTC-1A Before Proceeding


XJ BODY 4.0L AUTO TRANS



80b76ec9


XJ BODY 4.0L AUTO TRANS

POWERTRAIN CONTROL MODULE BLACK CONNECTOR



CAV	COLOR	FUNCTION
A6	BK/WT	PARK/NEUTRAL POSITION SWITCH SENSE

TRANSMISSION RANGE SENSOR CONNECTOR



CAV	COLOR	FUNCTION
7	BK/WT	PARK/NEUTRAL POSITION SWITCH SENSE
8	BK	GROUND


80ab373a

FIG. 1

TEST NTC-20A

CHECKING THE PARK/NEUTRAL POSITION SWITCH

Perform TEST NTC-1A Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


XJ BODY 4.0L AUTO TRANS

**POWERTRAIN
CONTROL MODULE
BLACK CONNECTOR**



CAV	COLOR	FUNCTION
A6	BK/WT	PARK/NEUTRAL POSITION SWITCH SENSE

**TRANSMISSION
RANGE SENSOR CONNECTOR**




CAV	COLOR	FUNCTION
7	BK/WT	PARK/NEUTRAL POSITION SWITCH SENSE
8	BK	GROUND

80ab373a

FIG. 1

TEST NTC-20A

CONTINUED - CHECKING THE PARK/NEUTRAL POSITION SWITCH




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TEST NTC-20B CHECKING THE PARK/NEUTRAL POSITION SWITCH


Perform TEST NTC-21A Before Proceeding

TJ BODY 2.5L AND 4.0L AUTO TRANS




80b11885

XJ BODY 2.5L AUTO TRANS



80b6f0d6


TJ/XJ 3 SPEED AUTO TRANS



A6

POWERTRAIN CONTROL MODULE BLACK CONNECTOR

CAV	COLOR	FUNCTION
A6	BK/WT	PARK/NEUTRAL POSITION SW SENSE (XJ 2.5L)
A6	BR/LB	PARK/NEUTRAL POSITION SW SENSE (TJ 2.5L, 4.0L)



PARK/NEUTRAL POSITION SWITCH CONNECTOR

XJ 2.5L A/T

CAV	COLOR	FUNCTION
1	WT	FUSED IGNITION SWITCH-H OUTPUT
2	BK/WT	PARK/NEUTRAL POSITION SW SENSE
3	BR/LG	BACK-UP LAMPS FEED

TJ 2.5L AND 4.0L A/T

CAV	COLOR	FUNCTION
1	VT/WT	FUSED IGNITION SWITCH-H OUTPUT
2	BR/LB	PARK/NEUTRAL POSITION SW SENSE
3	VT/BK	BACK-UP LAMPS FEED


FIG. 1

80b76ec8

TEST NTC-20B

CHECKING THE PARK/NEUTRAL POSITION SWITCH


Perform TEST NTC-21A Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


TJ/XJ 3 SPEED AUTO TRANS



POWERTRAIN CONTROL MODULE BLACK CONNECTOR

CAV	COLOR	FUNCTION
A6	BK/WT	PARK/NEUTRAL POSITION SW SENSE (XJ 2.5L)
A6	BR/LB	PARK/NEUTRAL POSITION SW SENSE (TJ 2.5L, 4.0L)

A6



PARK/NEUTRAL POSITION SWITCH CONNECTOR

XJ 2.5L A/T

CAV	COLOR	FUNCTION
1	WT	FUSED IGNITION SWITCH-I OUTPUT
2	BK/WT	PARK/NEUTRAL POSITION SW SENSE
3	BR/LG	BACK-UP LAMPS FEED

TJ 2.5L AND 4.0L A/T


CAV	COLOR	FUNCTION
1	VT/WT	FUSED IGNITION SWITCH-I OUTPUT
2	BR/LB	PARK/NEUTRAL POSITION SW SENSE
3	VT/BK	BACK-UP LAMPS FEED

80b76ec8

FIG. 1

TEST NTC-20B

CONTINUED - CHECKING THE PARK/NEUTRAL POSITION SWITCH



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TEST NTC-21A

CHECKING THE OIL PRESSURE SENDING UNIT

Perform TEST NTC-1A Before Proceeding

CLUSTER SYSTEM TEST CALIBRATION POINTS


Gauge	cal. point #1	cal. point #2	cal. point #3	cal. point #4	cal. point #5
Speedometer	0	20	55	80	100
Tachometer	0	2000	5000	6000	
Fuel	Empty	1/2	Full		
Volts	9	14	19		
Oil	0	40	80		
Temperature	100	210	260		

FIG. 1

80a4d35f

TJ/XJ BODY

ENGINE OIL PRESSURE SENSOR CONNECTOR




CAV	COLOR	FUNCTION
1	VT/OR	5-VOLT SUPPLY (TJ)
1	OR	5-VOLT SUPPLY (XJ)
2	GY/YL	OIL PRESSURE SENSOR SIGNAL
3	BR/YL	SENSOR GROUND

FIG. 2


80b6b37f

TJ/XJ BODY

BLACK




WHITE



POWERTRAIN CONTROL MODULE CONNECTORS

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A17	OR	5-VOLT SUPPLY
B24	GY/YL	OIL PRESSURE SENSOR SIGNAL

ENGINE OIL PRESSURE SENSOR CONNECTOR




CAV	COLOR	FUNCTION
1	VT/OR	5-VOLT SUPPLY (TJ)
1	OR	5-VOLT SUPPLY (XJ)
2	GY/YL	OIL PRESSURE SENSOR SIGNAL
3	BR/YL	SENSOR GROUND

FIG. 3

80b6b38a

TEST NTC-21A CHECKING THE OIL PRESSURE SENDING UNIT

Perform TEST NTC-1A Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TJ/XJ BODY

ENGINE OIL PRESSURE SENSOR CONNECTOR




CAV	COLOR	FUNCTION
1	VT/OR	5-VOLT SUPPLY (TJ)
1	OR	5-VOLT SUPPLY (XJ)
2	GY/YL	OIL PRESSURE SENSOR SIGNAL
3	BR/YL	SENSOR GROUND

80b6b37f

FIG. 1

TJ/XJ BODY


BLACK




POWERTRAIN CONTROL MODULE CONNECTORS

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
A17	OR	5-VOLT SUPPLY
B24	GY/YL	OIL PRESSURE SENSOR SIGNAL

WHITE



ENGINE OIL PRESSURE SENSOR CONNECTOR




CAV	COLOR	FUNCTION
1	VT/OR	5-VOLT SUPPLY (TJ)
1	OR	5-VOLT SUPPLY (XJ)
2	GY/YL	OIL PRESSURE SENSOR SIGNAL
3	BR/YL	SENSOR GROUND

80b6b38a

FIG. 2


TEST NTC-21A

CONTINUED - CHECKING OIL PRESSURE SENDING UNIT



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**




**Perform Verification TEST VER-2A.*

***Check connectors - Clean / repair as necessary.*

TEST NTC-25A CHECKING THE FUEL LEVEL SENSOR


Perform TEST NTC-1A Before Proceeding

TJ BODY



80b6f0ce


XJ BODY



80b6f0d4

TJ BODY

FUEL PUMP CONNECTOR




CAV	COLOR	FUNCTION
1	DG/WT	FUEL PUMP RELAY OUTPUT
3	DB/LG	FUEL LEVEL SENSOR SIGNAL
4	BR/YL	SENSOR GROUND
6	BK	GROUND

80b6f0e8

FIG. 1

XJ BODY

FUEL PUMP MODULE CONNECTOR



CAV	COLOR	FUNCTION
1	DG/WT	FUEL PUMP RELAY OUTPUT
3	DB/LG	FUEL LEVEL SENSOR SIGNAL
4	BR/YL	SENSOR GROUND
6	BK	GROUND


80aafa16

FIG. 2

TEST NTC-25A

CHECKING THE FUEL LEVEL SENSOR

Perform TEST NTC-1A Before Proceeding



***Perform Verification TEST VER-2A.**


****Check connectors - Clean / repair as necessary.**

TEST NTC-26A CHECKING THE A/C SYSTEM

Perform TEST NTC-1A Before Proceeding

TJ/XJ BODY

A/C COMPRESSOR CLUTCH COIL CONNECTOR




CAV	COLOR	FUNCTION
A	DB/BK	A/C CMP CLUTCH RELAY OUTPUT

FIG. 1

80b09803

TJ BODY

POWER DISTRIBUTION CENTER (PDC) (RELAY SECTION)



CAV	COLOR	FUNCTION
6(30)	RD/GY	FUSED B(+)
7(87)	DB/BK	A/C CMP CLUTCH RELAY OUTPUT
8(86)	VT/WT	FUSED IGNITION SWITCH OUTPUT
10(85)	DB/OR	A/C CMP CLUTCH RELAY CONTROL


FIG. 2

80b6f108

XJ BODY

POWER DISTRIBUTION CENTER

A/C CLUTCH RELAY CONNECTOR




CAV	COLOR	FUNCTION
1 (30)	RD/BK	FUSED B(+)
2 (87)	DB/BK	A/C CLUTCH RELAY OUTPUT
3 (85)	DB/OR	A/C CLUTCH RELAY CONTROL
5 (86)	DB/WT	FUSED IGNITION SWITCH OUTPUT

FIG. 3

80b6f0de

TEST NTC-26A CHECKING THE A/C SYSTEM

Perform TEST NTC-1A Before Proceeding




***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**

TEST NTC-27A CHECKING THE RADIATOR FAN OPERATION

Perform TEST NTC-1A Before Proceeding


XJ BODY



80b6f0d3

XJ BODY

RADIATOR FAN MOTOR CONNECTOR




CAV	COLOR	FUNCTION
1	LB	RADIATOR FAN RELAY OUTPUT
2	BK	GROUND

FIG. 1

80b6b3c0

XJ BODY

POWER DISTRIBUTION CENTER




CAV	COLOR	FUNCTION
10 (30)	LG/RD	FUSED B(+)
11 (86)	WT	FUSED IGNITION SWITCH OUTPUT
13 (85)	DB/PK	RAD FAN RELAY CONTROL
14 (87)	LB	RAD FAN RELAY OUTPUT

FIG. 2

80b76e94

TEST NTC-27A CHECKING THE RADIATOR FAN OPERATION


Perform TEST NTC-1A Before Proceeding



***Perform Verification TEST VER-2A.**

****Check connectors - Clean / repair as necessary.**


**RADIATOR FAN
MOTOR
CONNECTOR**



CAV	COLOR	FUNCTION
1	LB	RADIATOR FAN RELAY OUTPUT
2	BK	GROUND

80b6b3c0

FIG. 1



**Perform Verification TEST VER-2A.*


***Check connectors - Clean / repair as necessary.*

TEST SC-1A

CHECKING THE SPEED CONTROL SYSTEM

Perform TEST DTC Before Proceeding

TJ/XJ BODY




80b099e0

TEST SC-1A

CHECKING THE SPEED CONTROL SYSTEM

Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-4A.**

****Check connectors - Clean / repair as necessary.**

Perform TEST SC-1A Before Proceeding

SPEED CONTROL SERVO CONNECTOR



CAV	COLOR	FUNCTION
1	TN/RD	S/C VACUUM SOLENOID CONTROL
2	LG/RD	S/C VENT SOLENOID CONTROL
3	DB/RD	S/C BRAKE SWITCH OUTPUT
4	BK	GROUND


80b04fe4

FIG. 1

TEST SC-1B

CHECKING THE SPEED CONTROL SYSTEM

Perform TEST SC-1A Before Proceeding



***Perform Verification TEST VER-4A.**

****Check connectors - Clean / repair as necessary.**


TEST SC-1C

CHECKING THE SPEED CONTROL SYSTEM

Perform TEST SC-1A Before Proceeding


TJ/XJ BODY

BLACK



A4

GREY




C11

C32

C5

C4

C24



4

3

2

1

POWERTRAIN CONTROL MODULE CONNECTORS

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
C4	TN/RD	S/C VACUUM SOL CONTROL
C5	LG/RD	S/C VENT SOL CONTROL
C11	YL/RD	12-VOLT SUPPLY
C24	WT/PK	BRAKE SWITCH SENSE
C32	RD/LG	S/C SWITCH SIGNAL

SPEED CONTROL SERVO CONNECTOR


CAV	COLOR	FUNCTION
1	TN/RD	S/C VACUUM SOL CONTROL
2	LG/RD	S/C VENT SOL CONTROL
3	DB/RD	S/C BRAKE SWITCH OUTPUT
4	BK	GROUND

FIG. 1

80b099e2

TJ/XJ BODY

SPEED CONTROL SERVO CONNECTOR



4

3

2

1

CAV	COLOR	FUNCTION
1	TN/RD	S/C VACUUM SOLENOID CONTROL
2	LG/RD	S/C VENT SOLENOID CONTROL
3	DB/RD	S/C BRAKE SWITCH OUTPUT
4	BK	GROUND


FIG. 2

80b04fe4

TEST SC-1C

CHECKING THE SPEED CONTROL SYSTEM

Perform TEST SC-1A Before Proceeding



***Perform Verification TEST VER-4A.**

****Check connectors - Clean / repair as necessary.**


TEST SC-1D

CHECKING THE SPEED CONTROL SYSTEM

Perform TEST SC-1A Before Proceeding

TJ/XJ BODY

SPEED CONTROL SERVO CONNECTOR




CAV	COLOR	FUNCTION
1	TN/RD	S/C VACUUM SOLENOID CONTROL
2	LG/RD	S/C VENT SOLENOID CONTROL
3	DB/RD	S/C BRAKE SWITCH OUTPUT
4	BK	GROUND

FIG. 1

80b04fe4

TJ BODY

BRAKE LAMP SWITCH CONNECTOR




CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SWITCH SENSE
2	BK	GROUND
3	YL/RD	12-VOLT SUPPLY
4	DB/RD	S/C BRAKE SWITCH OUTPUT
5	PK/DB	FUSED B(+)
6	WT/TN	BRAKE LAMP SWITCH OUTPUT

FIG. 2

80b099e1

XJ BODY

BRAKE LAMP SWITCH CONNECTOR



CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SWITCH SENSE
2	BK	GROUND
3	YL/RD	12-VOLT SUPPLY
4	DB/RD	S/C BRAKE SWITCH OUTPUT
5	WT/TN	BRAKE LAMP SWITCH OUTPUT
6	PK/DB	FUSED B(+)


FIG. 3

80b04fe6

TEST SC-1D

CHECKING THE SPEED CONTROL SYSTEM

Perform TEST SC-1A Before Proceeding



***Perform Verification TEST VER-4A.**

****Check connectors - Clean / repair as necessary.**

TJ BODY




FIG. 1

XJ BODY




FIG. 2

TJ BODY




FIG. 3

XJ BODY





FIG. 4



*Perform Verification TEST VER-4A.


**Check connectors - Clean / repair as necessary.

TEST SC-2A

CHECKING SPEED CONTROL ON/OFF SWITCH

Perform TEST SC-1A Before Proceeding


TJ/XJ BODY



80b099e0

TJ/XJ BODY

SPEED CONTROL SWITCH CONNECTOR




CAV	COLOR	FUNCTION
1	BR/YL	GROUND
2	RD/LG	SPEED CONTROL SIGNAL


FIG. 1

80ab3724


TJ/XJ BODY



POWERTRAIN CONTROL MODULE CONNECTORS



CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
C4	TN/RD	S/C VACUUM SOL CONTROL
C5	LG/RD	S/C VENT SOL CONTROL
C11	YL/RD	12-VOLT SUPPLY
C24	WT/PK	BRAKE SWITCH SENSE
C32	RD/LG	S/C SWITCH SIGNAL



SPEED CONTROL SWITCH CONNECTOR

CAV	COLOR	FUNCTION
1	BR/YL	GROUND
2	RD/LG	SPEED CONTROL SIGNAL


FIG. 2

80b6b36a

TEST SC-2A

CHECKING SPEED CONTROL ON/OFF SWITCH


Perform TEST SC-1A Before Proceeding



***Perform Verification TEST VER-4A.**


****Check connectors - Clean / repair as necessary.**

TJ/XJ BODY



80b099e0


SPEED CONTROL SWITCH CONNECTOR



CAV	COLOR	FUNCTION
1	BR/YL	GROUND
2	RD/LG	SPEED CONTROL SIGNAL

FIG. 1

80ab3724



*Perform Verification TEST VER-4A.


**Check connectors - Clean / repair as necessary.

TEST SC-3A

CHECKING THE SPEED CONTROL RESUME SWITCH

Perform TEST SC-1A Before Proceeding


TJ/XJ BODY



80b099e0

TJ/XJ BODY

SPEED CONTROL SWITCH CONNECTOR



CAV	COLOR	FUNCTION
1	BR/YL	GROUND
2	RD/LG	SPEED CONTROL SIGNAL


FIG. 1

80ab3724

TEST SC-3A

CHECKING THE SPEED CONTROL RESUME SWITCH

Perform TEST SC-1A Before Proceeding



***Perform Verification TEST VER-4A.**


****Check connectors - Clean / repair as necessary.**

TEST SC-4A

CHECKING THE BRAKE SWITCH SENSE

Perform TEST SC-1A Before Proceeding


TJXJ BODY



80b099e0

TJ BODY

BRAKE LAMP SWITCH CONNECTOR




CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SWITCH SENSE
2	BK	GROUND
3	YL/RD	12-VOLT SUPPLY
4	DB/RD	S/C BRAKE SWITCH OUTPUT
5	PK/DB	FUSED B(+)
6	WT/TN	BRAKE LAMP SWITCH OUTPUT

FIG. 1

80b099e1

XJ BODY

BRAKE LAMP SWITCH CONNECTOR



CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SWITCH SENSE
2	BK	GROUND
3	YL/RD	12-VOLT SUPPLY
4	DB/RD	S/C BRAKE SWITCH OUTPUT
5	WT/TN	BRAKE LAMP SWITCH OUTPUT
6	PK/DB	FUSED B(+)


FIG. 2

80b04fe6

TEST SC-4A

CHECKING THE BRAKE SWITCH SENSE


Perform TEST SC-1A Before Proceeding



***Perform Verification TEST VER-4A.**

****Check connectors - Clean / repair as necessary.**


TJ BODY



CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
C4	TN/RD	S/C VACUUM SOLENOID CONTROL
C5	LG/RD	S/C VENT SOLENOID
C11	YL/RD	12-VOLT SUPPLY
C24	WT/PK	BRAKE SWITCH SENSE
C32	RD/LG	S/C SWITCH SIGNAL

BRAKE LAMP SWITCH CONNECTOR

CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SWITCH SENSE
2	BK	GROUND
3	YL/RD	12-VOLT SUPPLY
4	DB/RD	S/C BRAKE SWITCH OUTPUT
5	WT/TN	BRAKE LAMP SWITCH OUTPUT
6	PK/DB	FUSED B (+)




80b6b1cd

FIG. 1


XJ BODY

POWERTRAIN CONTROL MODULE GREY CONNECTOR



CAV	COLOR	FUNCTION
C4	TN/RD	S/C VAC SOL CONTROL
C5	LG/RD	S/C VENT SOL CONTROL
C11	YL/RD	12-VOLT SUPPLY
C24	WT/PK	BRAKE SW SENSE


BRAKE LAMP SWITCH CONNECTOR



CAV	COLOR	FUNCTION
1	WT/PK	BRAKE SW SENSE
2	BK	GROUND
3	YL/RD	12-VOLT SUPPLY
4	DB/RD	S/C BRAKE SW OUTPUT
5	PK/DB	FUSED B(+)
6	WT/TN	STOP LAMP SW OUTPUT

80b6b1cc

FIG. 2



*Perform Verification TEST VER-4A.

**Check connectors - Clean / repair as necessary.

**S
P
E
E
D

C
O
N
T
R
O
L

T
E
S
T
S**

TEST SC-5A

CHECKING THE SPEED CONTROL OPERATION

Perform TEST SC-1A Before Proceeding

NOTES

TEST SC-5A

CHECKING THE SPEED CONTROL OPERATION

Perform TEST SC-1A Before Proceeding

At this time the speed control switch and servo functions appear to operate properly. Using the DRB, monitor the speed control “cutout” status. Road test the vehicle at speeds over 35 mph and attempt to set the speed control. The following items will not allow the speed control to set. The last or most recent cause for speed control not to set is indicated by the “Denied” status.

Denied Message


ON/OFF	The powertrain control module does not see an “ON” signal from the switch.
SPEED	The vehicle speed as seen by the powertrain control module is not greater than 36 mph.
RPM	The engine rpm is excessively high.
BRAKE	The brake switch sense circuit is open indicating to the powertrain control module that the brakes are applied. The sense circuit is grounded through the brake pedal switch when the brakes are released.
P/N	The park/neutral switch sense circuit is malfunctioning indicating the powertrain control module that the transmission is not in gear. The sense circuit is grounded (XJ4 SPEED A/T) or opened (TJ/XJ 3 SPEED A/T) through the park/neutral switch when the transmission is in park or neutral.
RPM/SPD	The PCM senses excessive engine rpm for a given vehicle speed.
SOL FLT	The powertrain control module senses a servo solenoid circuit trouble code that is maturing or set in memory.

TEST CH-1A


CHARGING SYSTEM NO CODE TEST

Perform TEST DTC Before Proceeding

TJ/XJ BODY



80b6f0cd



CAV	COLOR	FUNCTION
1	DG/OR	GENERATOR SOURCE
2	DG	GENERATOR FIELD
*	BK/GY	B(+)


FIG. 1

80b6b36c

TEST CH-1A

CHARGING SYSTEM NO CODE TEST


Perform TEST DTC Before Proceeding




***Perform Verification TEST VER-3A.**

****Check connectors - Clean / repair as necessary.**

TJ/XJ BODY




80b6f0cd



CAV	COLOR	FUNCTION
1	DG/OR	GENERATOR SOURCE
2	DG	GENERATOR FIELD
*	BK/GY	B(+)

FIG. 1

80b6b36c



*Perform Verification TEST VER-3A.

**Check connectors - Clean / repair as necessary.

TJ BODY

POWERTRAIN CONTROL MODULE CONNECTORS




FIG. 1

80b099df

XJ BODY

POWERTRAIN CONTROL MODULE CONNECTORS





FIG. 2

80b04fdf



**Perform Verification TEST VER-3A.*

***Check connectors - Clean / repair as necessary.*

TEST NS-SEL	NO START SELECTION MENU
--------------------	--------------------------------

Perform TEST DTC Before Proceeding

NOTE: For all component locations, REFER TO GENERAL INFORMATION section 4.0 in this manual

NOTE: The battery must be fully charged before performing any test in this manual.

NOTE: If the engine will not crank or cranks but will not run, be sure to check the SKIM module for proper communication and trouble codes.


NOTE: If there are any trouble codes present they must be repaired before continuing with the No Start Symptom diagnostics.

NOTE: If the DRB does not power up, REFER TO GENERAL INFORMATION section 3.5.1.

Below you will find a recommended procedure to correct a No Start Problem by symptom. They should be performed in the order that they are listed.

Qualifying a no start condition	NS-1A
Checking the fuel system	NS-2A
Checking engine mechanical systems	NS-3A
Repairing low fuel pressure	NS-4A
Checking the fuel pump	NS-5A
Repairing "NO RESPONSE CONDITION"	NS-6A
Engine starts and the DRB displays "NO RESPONSE"	NS-6B
Checking the idle air control motor	NS-7A
Repairing a start and stall condition	NS-8A
Repairing a no-crank condition	NS-9A

Perform TEST NS-SEL Before Proceeding




80a2432e

FIG. 1

TEST NS-1A

QUALIFYING A NO START CONDITION

Perform TEST NS-SEL Before Proceeding



*Perform Verification TEST VER-1A.

**Check connectors - Clean / repair as necessary.

SPARK PLUG CABLE RESISTANCE

MINIMUM	MAXIMUM
250 Ohms Per Inch	1000 Ohms Per Inch
3000 Ohms Per Foot	12,000 Ohms Per Foot

80b171eb

FIG. 1





FIG. 2

1070304




*Perform Verification TEST VER-1A.

**Check connectors - Clean / repair as necessary.

TJ BODY

IGNITION COIL CONNECTOR




CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT
2	GY	IGNITION COIL DRIVER

80b6f0e3

FIG. 1

XJ BODY




CAV	COLOR	FUNCTION
1	DG/OR	ASD RELAY OUTPUT
2	GY	IGNITION COIL DRIVER

80afb891


NOTE: WIRES CAN BE IN EITHER CAVITY

FIG. 2




**Perform Verification TEST VER-1A.*

***Check connectors - Clean / repair as necessary.*



80b57482

FIG. 1




*Perform Verification TEST VER-1A.

**Check connectors - Clean / repair as necessary.


TJ BODY

POWERTRAIN CONTROL MODULE BLACK CONNECTOR



CAV	COLOR	FUNCTION
A7	GY	IGNITION COIL DRIVER

IGNITION COIL CONNECTOR




CAV	COLOR	FUNCTION
1	DG/LG	ASD RELAY OUTPUT
2	GY	IGNITION COIL DRIVER

80b76ec0

FIG. 1


XJ BODY

IGNITION COIL CONNECTOR



CAV	COLOR	FUNCTION
1	GY	IGNITION COIL DRIVER
2	DG /OR	ASD RELAY OUTPUT


POWERTRAIN CONTROL MODULE BLACK CONNECTOR



CAV	COLOR	FUNCTION
A7	GY	IGNITION COIL DRIVER

80b118ae

FIG. 2



*Perform Verification TEST VER-1A.


**Check connectors - Clean / repair as necessary.

TEST NS-2A

CHECKING THE FUEL SYSTEM

**NO
START
TESTS**

Perform TEST NS-SEL Before Proceeding



***Perform Verification TEST VER-1A.**

****Check connectors - Clean / repair as necessary.**


**N
O
S
T
A
R
T

T
E
S
T
S**

TEST NS-2A

CONTINUED - CHECKING THE FUEL SYSTEM

NOTES




*Perform Verification TEST VER-1A.

**Check connectors - Clean / repair as necessary.

Perform TEST NS-SEL Before Proceeding


2.5L



1040503

FIG. 1


4.0L



1040502

FIG. 2

Perform TEST NS-SEL Before Proceeding



*Perform Verification TEST VER-1A.

**Check connectors - Clean / repair as necessary.

**N
O

S
T
A
R
T

T
E
S
T
S**

TEST NS-4A

REPAIRING LOW FUEL PRESSURE

Perform TEST NS-SEL Before Proceeding


NOTES

TEST NS-4A

REPAIRING LOW FUEL PRESSURE

**N
O
S
T
A
R
T
T
E
S
T
S**

Perform TEST NS-SEL Before Proceeding



***Perform Verification TEST VER-1A.**

****Check connectors - Clean / repair as necessary.**


TEST NS-5A

CHECKING THE FUEL PUMP

Perform TEST NS-2A Before Proceeding

TJ BODY

**POWER DISTRIBUTION CENTER (PDC)
(RELAY SECTION)**




CAV	COLOR	FUNCTION
16(30)	DG/BK	FUSED B(+)
17(87)	DG/WT	FUEL PUMP RELAY OUTPUT
18(86)	DB	FUSED IGNITION SWITCH OUTPUT
20(85)	BR	FUEL PUMP RELAY CONTROL

80b6f0e9

FIG. 1

XJ BODY

**POWER DISTRIBUTION CENTER (PDC)
(RELAY SECTION)**



CAV	COLOR	FUNCTION
2 (30)	DG/BK	FUSED B(+)
8 (87)	DG/WT	FUEL PUMP RELAY OUTPUT
4 (86)	DB/WT	FUSED IGNITION SWITCH OUTPUT
6 (85)	BR	FUEL PUMP RELAY CONTROL


80b6f0e0

FIG. 2

TEST NS-5A

CHECKING THE FUEL PUMP

Perform TEST NS-2A Before Proceeding




***Perform Verification TEST VER-1A.**

****Check connectors - Clean / repair as necessary.**


TJ BODY

GREY




**POWERTRAIN CONTROL MODULE
GREY CONNECTORS**

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
C19	BR	FUEL PUMP RELAY CONTROL
C26	DB/LG	FUEL LEVEL SENSOR SIGNAL



BLACK



**FUEL PUMP
CONNECTOR**


CAV	COLOR	FUNCTION
1	DG/WT	FUEL PUMP RELAY OUTPUT
3	DB/LG	FUEL LEVEL SENSOR SIGNAL (GAUGE)
4	BR/YL	GROUND (GAUGE)
6	BK	GROUND (PUMP)

80b76eee

FIG. 1


XJ BODY

GREY




**POWERTRAIN CONTROL MODULE
GREY CONNECTORS**

CAV	COLOR	FUNCTION
A4	BR/YL	SENSOR GROUND
C19	BR	FUEL PUMP RELAY CONTROL
C26	DB/LG	FUEL LEVEL SENSOR SIGNAL



BLACK




**FUEL PUMP
CONNECTOR**

CAV	COLOR	FUNCTION
1	DG/WT	FUEL PUMP RELAY OUTPUT
3	DB/LG	FUEL LEVEL SENSOR SIGNAL (GAUGE)
4	BR/YL	GROUND (GAUGE)
6	BK	GROUND (PUMP)

80b76e10

FIG. 2



*Perform Verification TEST VER-1A.


**Check connectors - Clean / repair as necessary.

TEST NS-6A **REPAIRING - NO RESPONSE CONDITION**

Perform TEST NS-SEL Before Proceeding

TJ BODY

**POWERTRAIN CONTROL
MODULE BLACK CONNECTOR**




CAV	COLOR	FUNCTION
A2	DB	IGNITION SWITCH OUTPUT
A4	BR/YL	SENSOR GROUND
A22	RD/WT	FUSED B(+)
A31	BK/TN	GROUND
A32	BK/TN	GROUND

FIG. 1

80b76ef5

XJ BODY

**POWERTRAIN
CONTROL MODULE
BLACK CONNECTOR**



CAV	COLOR	FUNCTION
A2	DB/WT	IGNITION SWITCH OUTPUT
A4	BR/YL	SENSOR GROUND
A22	DG/BK	FUSED B(+)
A31	BK/TN	GROUND
A32	BK/TN	GROUND


FIG. 2

80aafae7

TEST NS-6A

REPAIRING - NO RESPONSE CONDITION

Perform TEST NS-SEL Before Proceeding




***Perform Verification TEST VER-1A.**

****Check connectors - Clean / repair as necessary.**

TJ BODY


POWERTRAIN CONTROL MODULE



80b76ef3

XJ BODY


POWERTRAIN CONTROL MODULE



80b76ef4

TJ BODY

POWERTRAIN CONTROL MODULE BLACK CONNECTOR




CAV	COLOR	FUNCTION
A2	DB	IGNITION SWITCH OUTPUT
A4	BR/YL	SENSOR GROUND
A22	RD/WT	FUSED B(+)
A31	BK/TN	GROUND
A32	BK/TN	GROUND

80b76ef5

FIG. 1

XJ BODY


POWERTRAIN CONTROL MODULE BLACK CONNECTOR



CAV	COLOR	FUNCTION
A2	DB/WT	IGNITION SWITCH OUTPUT
A4	BR/YL	SENSOR GROUND
A22	DG/BK	FUSED B(+)
A31	BK/TN	GROUND
A32	BK/TN	GROUND

80aafae7


FIG. 2



*Perform Verification TEST VER-1A.

**Check connectors - Clean / repair as necessary.

TJ BODY




CAV	COLOR	FUNCTION
1(30)	RD/WT	FUSED B(+)
2(87)	DG/PK	AUTO SHUTDOWN RELAY OUTPUT
3(86)	DB	IGNITION SWITCH OUTPUT
5(85)	DB/YL	AUTO SHUTDOWN RELAY CONTROL

80b6f109

FIG. 1

XJ BODY




CAV	COLOR	FUNCTION
2 (30)	RD/LG	FUSED B(+)
4 (85)	DB/WT	FUSED IGNITION SWITCH OUTPUT
6 (86)	DB/YL	ASD RELAY CONTROL
8 (87)	RD	ASD RELAY OUTPUT

80b6f0df

FIG. 2

TJ BODY

POWERTRAIN CONTROL MODULE BLACK CONNECTOR




CAV	COLOR	FUNCTION
A2	DB	IGNITION SWITCH OUTPUT
A4	BR/YL	SENSOR GROUND
A22	RD/WT	FUSED B(+)
A31	BK/TN	GROUND
A32	BK/TN	GROUND

80b76ef5

FIG. 3

XJ BODY


POWERTRAIN CONTROL MODULE BLACK CONNECTOR



CAV	COLOR	FUNCTION
A2	DB/WT	IGNITION SWITCH OUTPUT
A4	BR/YL	SENSOR GROUND
A22	DG/BK	FUSED B(+)
A31	BK/TN	GROUND
A32	BK/TN	GROUND

80aafae7

FIG. 4




*Perform Verification TEST VER-1A.

**Check connectors - Clean / repair as necessary.

TJ BODY

**POWER DISTRIBUTION CENTER (PDC)
(RELAY SECTION)**




CAV	COLOR	FUNCTION
1(30)	RD/WT	FUSED B(+)
2(87)	DG/PK	AUTO SHUTDOWN RELAY OUTPUT
3(86)	DB	IGNITION SWITCH OUTPUT
5(85)	DB/YL	AUTO SHUTDOWN RELAY CONTROL

80b6f109

FIG. 1

XJ BODY


**POWER DISTRIBUTION
CENTER**



CAV	COLOR	FUNCTION
2 (30)	RD/LG	FUSED B(+)
4 (85)	DB/WT	FUSED IGNITION SWITCH OUTPUT
6 (86)	DB/YL	ASD RELAY CONTROL
8 (87)	RD	ASD RELAY OUTPUT

80b6f0df

FIG. 2



*Perform Verification TEST VER-1A.

**Check connectors - Clean / repair as necessary.


TEST NS-6B

REPAIRING - NO RESPONSE CONDITION

Perform TEST NS-6A Before Proceeding

TJ BODY

DATA LINK CONNECTOR




CAV	COLOR	FUNCTION
3	VT/BR	CCD BUS (+)
4	BK/LB	GROUND
5	BK/TN	GROUND
6	LG	SCI RECEIVE
7	PK	SCI TRANSMIT/ISO 9141K
11	WT/BK	CCD BUS (-)
16	PK/WT	FUSED B(+)

80a4508e

FIG. 1

XJ BODY

DATA LINK CONNECTOR




CAV	COLOR	FUNCTION
3	VT/BR	CCD Bus (+)
4	BK	Ground
5	BK/LB	Power Ground
6	LG/BK	SCI Receive
7	PK	SCI Transmit
11	WT/BK	CCD Bus (-)
16	TN/BK	Fused B (+)

80aa4c3a

FIG. 2


TJ BODY

POWERTRAIN CONTROL MODULE GREY CONNECTOR



CAV	COLOR	FUNCTION
C27	PK	SCI TRANSMIT
C28	WT/BK	CCD BUS (-)
C29	LG	SCI RECEIVE
C30	VT/BR	CCD BUS (+)

DATA LINK CONNECTOR




CAV	COLOR	FUNCTION
3	VT/BR	CCD BUS (+)
4	BK/LB	GROUND
5	BK/TN	GROUND
6	LG	SCI RECEIVE
7	PK	SCI TRANSMIT
11	WT/BK	CCD BUS (-)
16	PK/WT	FUSED B (+)

80aaaf128

FIG. 3


XJ BODY

POWERTRAIN CONTROL MODULE GREY CONNECTOR



CAV	COLOR	FUNCTION
C27	PK	SCI TRANSMIT
C28	WT/BK	CCD BUS (-)
C29	LG/BK	SCI RECEIVE
C30	VT/BR	CCD BUS (+)

DATA LINK CONNECTOR




CAV	COLOR	FUNCTION
3	VT/BR	CCD BUS (+)
4	BK	GROUND
5	BK/LB	POWER GROUND
6	LG/BK	SCI RECEIVE
7	PK	SCI TRANSMIT
11	WT/BK	CCD BUS (-)
16	TN/BK	FUSED B (+)

80caafaf2

FIG. 4


Perform TEST NS-6A Before Proceeding



*Perform Verification TEST VER-1A.


**Check connectors - Clean / repair as necessary.

TJ BODY



**POWERTRAIN
CONTROL MODULE
GREY CONNECTOR**

CAV	COLOR	FUNCTION
C27	PK	SCI TRANSMIT
C28	WT/BK	CCD BUS (-)
C29	LG	SCI RECEIVE
C30	VT/BR	CCD BUS (+)




**DATA LINK
CONNECTOR**

CAV	COLOR	FUNCTION
3	VT/BR	CCD BUS (+)
4	BK/LB	GROUND
5	BK/TN	GROUND
6	LG	SCI RECEIVE
7	PK	SCI TRANSMIT
11	WT/BK	CCD BUS (-)
16	PK/WT	FUSED B (+)

FIG. 1


80aaf128

XJ BODY



**POWERTRAIN
CONTROL MODULE
GREY CONNECTOR**

CAV	COLOR	FUNCTION
C27	PK	SCI TRANSMIT
C28	WT/BK	CCD BUS (-)
C29	LG/BK	SCI RECEIVE
C30	VT/BR	CCD BUS (+)




**DATA LINK
CONNECTOR**

CAV	COLOR	FUNCTION
3	VT/BR	CCD BUS (+)
4	BK	GROUND
5	BK/LB	POWER GROUND
6	LG/BK	SCI RECEIVE
7	PK	SCI TRANSMIT
11	WT/BK	CCD BUS (-)
16	TN/BK	FUSED B (+)

FIG. 2

80aafaf2



*Perform Verification TEST VER-1A.

**Check connectors - Clean / repair as necessary.



TEST NS-6C

REPAIRING - NO RESPONSE CONDITION

Perform TEST NS-6A Before Proceeding

TJ BODY

**POWER DISTRIBUTION CENTER (PDC)
(RELAY SECTION)**





CAV	COLOR	FUNCTION
16(30)	DG/BK	FUSED B(+)
17(87)	DG/WT	FUEL PUMP RELAY OUTPUT
18(86)	DB	FUSED IGNITION SWITCH OUTPUT
20(85)	BR	FUEL PUMP RELAY CONTROL

80b6f0e9

FIG. 1

XJ BODY

**POWER DISTRIBUTION CENTER (PDC)
(RELAY SECTION)**



CAV	COLOR	FUNCTION
2 (30)	DG/BK	FUSED B(+)
8 (87)	DG/WT	FUEL PUMP RELAY OUTPUT
4 (86)	DB/WT	FUSED IGNITION SWITCH OUTPUT
6 (85)	BR	FUEL PUMP RELAY CONTROL

80b6f0e0


FIG. 2

TEST NS-6C

REPAIRING - NO RESPONSE CONDITION

**NO
START
TESTS**

Perform TEST NS-6A Before Proceeding




***Perform Verification TEST VER-1A.**

****Check connectors - Clean / repair as necessary.**

TEST NS-6D REPAIRING - NO RESPONSE CONDITION

Perform TEST NS-6A Before Proceeding


TJ/XJ BODY



80b6f0d7

TJ/XJ BODY

THROTTLE POSITION SENSOR CONNECTOR




CAV	COLOR	FUNCTION
1	BR/YL	SENSOR GROUND
2	OR/DB	TP SENSOR SIGNAL
3	OR	5-VOLT SUPPLY

80b6f0e7


FIG. 1

Perform TEST NS-6A Before Proceeding




*Perform Verification TEST VER-1A.

**Check connectors - Clean / repair as necessary.



80b6f0d7




*Perform Verification TEST VER-1A.

**Check connectors - Clean / repair as necessary.

Perform TEST NS-SEL Before Proceeding

TJ/XJ BODY

**IDLE AIR
CONTROL MOTOR
CONNECTOR**



CAV	COLOR	FUNCTION
1	VT/BK	IDLE AIR CONTROL #1 DRIVER
2	BR/WT	IDLE AIR CONTROL #2 DRIVER
3	YL/BK	IDLE AIR CONTROL #3 DRIVER
4	GY/RD	IDLE AIR CONTROL #4 DRIVER

80b898b2


FIG. 1

TEST NS-7A

CHECKING THE IDLE AIR CONTROL MOTOR


NO START TESTS

Perform TEST NS-SEL Before Proceeding




***Perform Verification TEST VER-1A.**

****Check connectors - Clean / repair as necessary.**



1100102

FIG. 1




*Perform Verification TEST VER-1A.

**Check connectors - Clean / repair as necessary.

TJ/XJ BODY


**IDLE AIR
CONTROL MOTOR
CONNECTOR**



CAV	COLOR	FUNCTION
1	VT/BK	IDLE AIR CONTROL #1 DRIVER
2	BR/WT	IDLE AIR CONTROL #2 DRIVER
3	YL/BK	IDLE AIR CONTROL #3 DRIVER
4	GY/RD	IDLE AIR CONTROL #4 DRIVER

80b898b2

FIG. 1



*Perform Verification TEST VER-1A.

**Check connectors - Clean / repair as necessary.

**N
O
S
T
A
R
T
T
E
S
T
S**

TEST NS-8A

REPAIRING A START AND STALL CONDITION

Perform TEST NS-SEL Before Proceeding

NOTES

Perform TEST NS-SEL Before Proceeding

At this point in the diagnostic test procedure, you have determined that all of the **engine electrical systems** are operating as designed; therefore, they are **not the cause of the start and stall problem**. The following additional items should be checked as possible mechanical causes of the no start condition. Any one or more of these items can produce a no start condition; none can be overlooked as a possible cause.

1. **DISTRIBUTOR POSITION** — must be within specifications*
2. **ENGINE VALVE TIMING** — must be within specifications
3. **ENGINE COMPRESSION** — must be within specifications
4. **ENGINE EXHAUST** — must be free of any restrictions
5. **ENGINE PCV SYSTEM** — must flow freely
6. **ENGINE DRIVE SPROCKETS** — must be properly positioned
7. **FUEL** — must be free of contamination
8. **ENGINE SECONDARY IGNITION CHECK** — must exhibit a normal scope pattern

Always look for any Technical Service Bulletins that may relate to this condition.

Checking Distributor Position With DRBIII®

Connect the DRB to the Data Link Connector and select the set SYNC from the menu.

WARNING: The following test will be performed with the engine running; avoid contact with rotating components.

Start the engine and observe the DRB display. When the distributor is correctly positioned, the IN RANGE message should appear along with 0°. If the distributor needs to be adjusted, loosen the distributor hold-down clamp bolt. Rotate the distributor until reading is as close to 0° as possible and the IN RANGE message is displayed. Tighten the clamp bolt to 22.5 N·m (200 in. lbs.) torque.

NOTE: Setting the distributor position does not adjust the ignition timing. Ignition timing values are determined by the powertrain control module.



TEST NS-9A

REPAIRING A NO CRANK CONDITION

Perform TEST NS-SEL Before Proceeding

TJ BODY

**POWER DISTRIBUTION CENTER (PDC)
(RELAY SECTION)**



CAV	COLOR	FUNCTION
10(30)	PK/BK	FUSED B(+)
11(85)	YL/RD	IGNITION SWITCH OUTPUT
13(86)	BR/LB	PARK NEUTRAL SWITCH SENSE (AUTO TRANS) GROUND (MANUAL TRANS)
14(87)	BR	STARTER RELAY OUTPUT



80b6f107

FIG. 1

XJ BODY

**POWER DISTRIBUTION CENTER (PDC)
(RELAY SECTION)**

STARTER RELAY CONNECTOR




CAV	COLOR	FUNCTION
10 (30)	YL	FUSED B(+)
11 (85)	BK/WT	P/N POSITION SWITCH SENSE (AUTO TRANSMISSION)
11 (85)	BK	GROUND (MANUAL TRANSMISSION)
13 (86)	YL	FUSED IGNITION SWITCH OUTPUT
14 (87)	BR	STARTER RELAY OUTPUT

80b6f0e1

FIG. 2

TEST NS-9A REPAIRING A NO CRANK CONDITION

Perform TEST NS-SEL Before Proceeding



***Perform Verification TEST VER-1A.**



****Check connectors - Clean / repair as necessary.**

TEST NS-9B REPAIRING A NO CRANK CONDITION

Perform TEST NS-9A Before Proceeding

TJ BODY

**POWER DISTRIBUTION CENTER (PDC)
(RELAY SECTION)**



CAV	COLOR	FUNCTION
10(30)	PK/BK	FUSED B(+)
11(85)	YL/RD	IGNITION SWITCH OUTPUT
13(86)	BR/LB	PARK NEUTRAL SWITCH SENSE (AUTO TRANS) GROUND (MANUAL TRANS)
14(87)	BR	STARTER RELAY OUTPUT



80b6f107

FIG. 1

XJ BODY

**POWER DISTRIBUTION CENTER (PDC)
(RELAY SECTION)**

STARTER RELAY CONNECTOR



CAV	COLOR	FUNCTION
10 (30)	YL	FUSED B(+)
11 (85)	BK/WT	P/N POSITION SWITCH SENSE (AUTO TRANSMISSION)
11 (85)	BK	GROUND (MANUAL TRANSMISSION)
13 (86)	YL	FUSED IGNITION SWITCH OUTPUT
14 (87)	BR	STARTER RELAY OUTPUT


80b6f0e1

FIG. 2

TEST NS-9B

REPAIRING A NO CRANK CONDITION

Perform TEST NS-9A Before Proceeding



***Perform Verification TEST VER-1A.**

****Check connectors - Clean / repair as necessary.**


TEST NS-9C

REPAIRING A NO CRANK CONDITION


Perform TEST NS-9A Before Proceeding

TJ BODY

STARTER RELAY CONNECTOR (IN PDC)



CAV		FUNCTION
10 (30)	PK/BK	FUSED B(+)
11 (85)	YL/RD	IGNITION SWITCH OUTPUT
13 (86)	BR/LB	PARK NEUTRAL SW SENSE (AUTO TRANS) GROUND (MANUAL TRANS)
14 (87)	BR	STARTER RELAY OUTPUT



STARTER RELAY OUTPUT WIRE CONNECTOR (AT SOLENOID)


CAV	COLOR	FUNCTION
1	BR	STARTER RELAY OUTPUT

80b76f25


FIG. 1

XJ BODY

STARTER RELAY CONNECTOR (IN PDC)



CAV	COLOR	FUNCTION
10 (30)	YL	FUSED B(+)
11 (85)	BK/WT	PIN POSITION SW SENSE (ALTC TRANS)
11 (85)	BK	GROUND (MANUAL TRANS)
13 (86)	YL	FUSED IGNITION SW OUTPUT
14 (87)	BR	STARTER RELAY OUTPUT



STARTER RELAY OUTPUT WIRE CONNECTOR (AT SOLENOID)

CAV	COLOR	FUNCTION
1	BR	STARTER RELAY OUTPUT

80b76f26


FIG. 2

TEST NS-9C

REPAIRING A NO CRANK CONDITION

**NO
START
TESTS**

Perform TEST NS-9A Before Proceeding





***Perform Verification TEST VER-1A.**

****Check connectors - Clean / repair as necessary.**

Perform TEST NS-9A Before Proceeding

TJ BODY

**POWER DISTRIBUTION CENTER (PDC)
(RELAY SECTION)**



CAV	COLOR	FUNCTION
10(30)	PK/BK	FUSED B(+)
11(85)	YL/RD	IGNITION SWITCH OUTPUT
13(86)	BR/LB	PARK NEUTRAL SWITCH SENSE (AUTO TRANS) GROUND (MANUAL TRANS)
14(87)	BR	STARTER RELAY OUTPUT



80b6f107

FIG. 1

XJ BODY

**POWER DISTRIBUTION CENTER (PDC)
(RELAY SECTION)**

STARTER RELAY CONNECTOR




CAV	COLOR	FUNCTION
10 (30)	YL	FUSED B(+)
11 (85)	BK/WT	P/N POSITION SWITCH SENSE (AUTO TRANSMISSION)
11 (85)	BK	GROUND (MANUAL TRANSMISSION)
13 (86)	YL	FUSED IGNITION SWITCH OUTPUT
14 (87)	BR	STARTER RELAY OUTPUT

80b6f0e1

FIG. 2

Perform TEST NS-9A Before Proceeding



*Perform Verification TEST VER-1A.

**Check connectors - Clean / repair as necessary.

Important Note:

If the Powertrain Control Module has been changed and the correct VIN and mileage have not been programmed, a DTC will be set in the ABS, Airbag and SKIM modules. In addition, if the vehicle is equipped with a Sentry Key Immobilizer Module (SKIM), Secret Key data must be updated to enable starting. Refer to GENERAL INFORMATION section 8.0 for programming the Powertrain Control Module and the SKIM.

For ABS and Airbag Systems:

ACTION:

1. Enter correct VIN and Mileage in PCM.
2. Erase codes in ABS and Airbag modules.

Inspect the vehicle to ensure that all engine components are connected. Reassemble and reconnect components as necessary.

Inspect the engine oil for contamination. If it is contaminated, change the oil and filter.

Attempt to start the engine.

If the engine is **unable** to start, look for any Technical Service Bulletins that may relate to this condition. Return to **DTC TEST** if necessary.

The repair is now complete.

Important Note:

Inspect the vehicle to ensure that all engine components are connected. Reassemble and reconnect all components as necessary.

Important Note:

If the Powertrain Control Module has been changed and the correct VIN and mileage have not been programmed, a DTC will be set in the ABS, Airbag and SKIM modules. In addition, if the vehicle is equipped with a Sentry Key Immobilizer Module (SKIM), Secret Key data must be updated to enable starting. Refer to GENERAL INFORMATION section 8.0 for programming the Powertrain Control Module and SKIM.

For ABS and Airbag Systems:

ACTION:

1. Enter the correct VIN and Mileage in PCM.
2. Erase ABS and Airbag module codes.

All trouble codes should be repaired before continuing, if not, return **DTC-TEST** and follow suggested test.

Use the following methods depending on the type of test you came from, **No Trouble Code**, or **Trouble Code**.

- Connect the DRBIII to the data link connector.

No Trouble Code Repair

1. Check to see if the initial symptom still exists (use DRB freeze frame when available to assist).
2. If the initial or another symptom exists, or a Trouble Code Set, repairs are not complete. Check all pertinent Technical Service Bulletins and return to **TEST NTC-1A**, or for codes return to **DTC-TEST**.

Inspect the vehicle to ensure that all engine components are connected. Reassemble and reconnect all components as necessary.

For previously read trouble codes that have not been dealt with, return to **DTC TEST** and follow the path specified; otherwise continue.

If the powertrain control module has not been changed:

1. Connect the DRB to the PCM data link connector and erase trouble codes.
2. With the DRB, reset all values in the adaptive memory.
3. Disconnect the DRB.

Ensure no trouble code remains by doing the following:

1. If this test is for any **A/C Relay Control Circuit Code**, drive the vehicle for at least five minutes with the A/C on. For some of the drive, go at least 40 mph; at some point stop the car and turn the engine off for 10 seconds or more; then restart and continue. Ensure the transmission shifts through all gears. Upon completion of the road test, turn the engine off, and read trouble codes with the DRB.
2. If the repaired code has reset, the repair is not complete. Check all related Technical Service Bulletins and return to **DTC TEST** if necessary. If another trouble code has set, return to **DTC TEST** and follow the path specified for that trouble code. If there are no trouble codes, the repair was successful and is now complete.

Important Note:

If the Powertrain Control Module has been changed and the correct VIN and mileage have not been programmed, a DTC will be set in the ABS, Airbag and SKIM modules. In addition, if the vehicle is equipped with a Sentry Key Immobilizer Module (SKIM), Secret Key data must be updated to enable starting. Refer to GENERAL INFORMATION section 8.0 for programming the Powertrain Control Module and SKIM.

Inspect the vehicle to ensure that all engine components are connected. Reassemble and reconnect components as necessary.

If the powertrain control module has been changed, do the following:

1. If the vehicle is equipped with a factory theft alarm, start the vehicle at least 20 times so that the alarm system may be activated when desired.

Connect the DRB to the PCM data link connector and erase the codes.

Ensure no other charging system problems remain by doing the following:

1. Start the engine.
2. Raise the engine speed to 2000 rpm for at least 30 seconds.
3. Allow the engine to idle.
4. Turn the engine off.
5. Turn the ignition key on.
6. With the DRB, read trouble code messages.

If the repaired code as reset, or another one has set, check all pertinent Technical Service Bulletins and return to **DTC TEST** if necessary.

If there are no codes, the repair is now complete.

Important Note:

If the Powertrain Control Module has been changed and the correct VIN and mileage have not been programmed, a DTC will be set in the ABS, Airbag and SKIM modules. In addition, if the vehicle is equipped with a Sentry Key Immobilizer Module (SKIM), Secret Key data must be updated to enable starting. Refer to GENERAL INFORMATION section 8.0 for programming the Powertrain Control Module and SKIM.

For ABS and Airbag Systems:

ACTION:

1. Enter correct VIN and Mileage in PCM.
2. Erase codes in ABS and Airbag modules.

Inspect the vehicle to ensure that all engine components are connected. Reassemble and reconnect components as necessary.

Connect the DRB to the PCM data link connector and erase the codes.

Ensure no other speed control problems remain by doing the following:

1. Road test the vehicle at a speed above 30 mph.
2. Turn the speed control ON/OFF switch to the ON position.
3. Depress and release the SET switch. If the speed control did not engage, the repair is not complete.*
4. Quickly depress and release the RESUME/ACCEL switch. If the vehicle speed did not increase by 2 mph, the repair is not complete.*
5. Press and HOLD coast switch, vehicle speed should decrease, if no decrease, the repair is not complete.*
6. Using caution, depress and release the brake pedal. If the speed control did not disengage, the repair is not complete.*
7. Bring the vehicle speed back up to 25 mph.
8. Depress the RESUME/ACCEL switch. If the speed control did not resume the previously set speed, the repair is not complete.*
9. Hold down the SET switch. If the vehicle did not decelerate, the repair is not complete.*
10. Ensure the vehicle speed is greater than 30 mph and release the SET switch. If the vehicle did not adjust and set a new vehicle speed, the repair is not complete.*
11. Depress and release the cancel switch. If the speed control did not disengage, the repair is not complete.*
12. Bring the vehicle back up to 35 mph and engage speed control.
13. Turn the ON/OFF switch to the OFF position. If the speed control did not disengage, the repair is not complete.*

If the vehicle successfully passed all of the previous tests, the speed control system is now functioning as designed. The repair is now complete.

*Check for Technical Service Bulletins that pertain to speed control problem and then, if necessary, return to **DTC TEST**.

8.0 MAINTENANCE AND SERVICE INFORMATION

8.1 Programming the Powertrain Control Module

The SKIS “Secret Key” is an I.D. code that is unique to each SKIM. This code is programmed and stored in the SKIM, engine controller and transponder chip (ignition keys). When replacing the PCM it is necessary to program the secret key into the new PCM using the DRB. Perform the following steps to program the secret key into the engine controller.

1. Turn the ignition on (transmission in park/neutral)
2. Use the DRB and select “MISCELLANEOUS” from the main menu.
3. Select “PCM REPLACED” (GAS ENGINE).
4. Enter secured access mode by entering the vehicle four-digit PIN.

NOTE: If three attempts are made to enter secure access mode using an incorrect PIN, secured access mode will be locked out for one hour. To exit this lockout mode, turn the ignition to the RUN position for one hour then enter the correct PIN. (Ensure all accessories are turned off. Also monitor the battery state and connect a battery charger if necessary).

5. Press “ENTER” to transfer the secret key (the SKIM will send the secret key to the PCM).

8.2 Programming the Sentry Key Immobilizer Module

NOTE: If the PCM and the SKIM are replaced at the same time, program the VIN into the PCM first. All vehicle keys will need to be replaced and programmed to the new SKIM.

1. Turn the ignition on (transmission in park/neutral).
2. Use the DRB and select “THEFT ALARM”, “SKIM”, “MISCELLANEOUS”.
4. Program the vehicle four-digit PIN into SKIM.
5. Select “COUNTRY CODE” and enter the correct country.

NOTE: Be sure to enter the correct country code. If the incorrect country code is programmed into SKIM, the SKIM must be replaced.

6. Select “UPDATE VIN” (the skim will learn the VIN from the PCM).
7. Press “ENTER” to transfer the secret key (the PCM will send the secret key to the SKIM).
8. Program ignition keys to SKIM (for programming procedure, refer to **GENERAL INFORMATION SECTION 8.3**).

8.3 Programming Ignition Keys to the Sentry Key Immobilizer Module

1. Turn the ignition on (transmission in park/neutral).
2. Use the DRB and select “THEFT ALARM”, “SKIM”, “MISCELLANEOUS”.
3. Select “PROGRAM IGNITION KEYS” (Indicator lamp will begin flashing to indicate that learn mode is in progress).
4. Enter secured access mode by entering the vehicle four-digit PIN

NOTE: The PIN must be re-entered each time an additional key is learned.

5. Insert key into ignition switch and observe ALARM SET lamp. Once the key has been learned, the ALARM SET lamp will turn off.

NOTE: A maximum of eight keys can be learned to each SKIM. Once a key is learned to a SKIM it (the key) cannot be transferred to another vehicle.

If ignition key programming is unsuccessful, the DRB will display one of the following messages:

Programming Not Attempted – The DRB attempts to read the programmed key status and there are no keys programmed into SKIM memory.

Programming Key Failed (Possible Used Key From Wrong Vehicle – SKIM is unable to program key due to one of the following:

- faulty ignition key transponder
- ignition key is programmed to another vehicle.

8 Keys Already Learned, Programming Not Done – SKIM transponder ID memory is full.

1. Obtain ignition keys to be programmed from customer (8 keys maximum)
2. Using the DRB, erase all ignition keys by selecting “MISCELLANEOUS” and “ERASE ALL CURRENT IGN. KEYS”
3. Program all ignition keys.

Learned Key In Ignition – Ignition key transponder ID is currently programmed in SKIM memory.


9.0 SPECIFICATIONS

9.1 Fuel System Release Procedure (Gasoline)

1. Remove the fuel pump relay.
2. Start and run engine until it stalls.
3. Attempt to restart the engine until it will no longer run.
4. Ensure the ignition key is off.
5. With fuel pressure relieved the fuel system can now be opened for required work. Continue to use caution, fuel leakage is still possible.

10.0 SCHEMATIC DIAGRAMS


10.1 TJ Body 2.5/4.0L JTEC+




80D66387

GENERAL INFORMATION

10.2 XJ Body 2.5L JTEC+



10.3 XJ Body 4.0 JTEC+



8066b388

GENERAL INFORMATION

11.0 RECOMMENDED TOOLS AND EQUIPMENT

- DRBIII® (diagnostic read-out box)
- fuel line adapter 6523, 6539 or 6941
- fuel pressure test kit C-4799-B or 5069
- jumper wires
- ohmmeter
- oscilloscope
- vacuum gauge
- voltmeter
- pressure gauge (0-300 psi)

12.0 GLOSSARY OF TERMS

- backfire, popback** fuel ignites in either the intake or the exhaust system.
- CKP** crank position sensor
- CMP** camshaft position sensor
- cuts out, misses** a steady pulsation or the inability of the engine to maintain a consistent rpm
- DLC** data link connector (previously called “engine diagnostic connector”)
- detonation, spark knock** a mild to severe ping, especially under loaded engine conditions
- ECT** engine coolant temperature sensor
- EGR** exhaust gas recirculation valve and system
- generator** previously called “alternator”
- hard start** The engine takes longer than usual to start, even though it is able to crank normally.
- hesitation, sag, stuble** There is a momentary lack of response when the throttle is opened. This can occur at all vehicle speeds. If it is severe enough, the engine may stall.
- IAT** intake air temperature sensor
- JTEC+** Combined engine and transmission control module
- lack of power, sluggish** The engine has less than expected power, with little or no increase in vehicle speed when the throttle is opened.
- MAP** manifold absolute pressure sensor
- MTV** manifold tuning valve
- MVLPS** manual valve lever position switch (previously called “park/neutral switch”)

O2S	oxygen sensor (left oxygen sensor when there are two sensors)
O2SR	right oxygen sensor
PCM	powertrain control module
PCV	positive crankshaft ventilation
poor fuel economy	There is significantly less fuel mileage than other vehicles of the same design and configuration.
rough, unstable erratic idle stalling	The engine runs unevenly at idle and causes the engine to shake if it is severe enough. The engine idle rpm may vary (called "hunting"). This condition may cause stalling if it is severe enough.
start & stall	The engine starts but immediately dies.
SKIS	Sentry Key Immobilizer System
surge	engine rpm fluctuation without corresponding change in throttle position sensor
TPS	throttle position sensor
VSS	vehicle speed sensor

